



Operating and Installation Instructions Commercial Washing Machine PWM 514 PWM 520

Caring for the environment	6
IMPORTANT SAFETY INSTRUCTIONS	
Explanation of the safety notes and warnings on the machine	
Appropriate use	
Preventing misuse	
Technical safety	8
Correct use	(
Chlorine and component damage	1
Accessories	1
Description of the machine	12
Models with detergent drawer (DD)	
Models without detergent drawer (DD)	
Control panel	
Operation	18
Sensor controls and touch display	
Main menu	
Examples of how to operate the machine	
Operating a laundromat machine	
•	
Washing	
Preparing for use	
Emptying pockets	
Max. load	
Sorting the laundry	
Preparing mops, cleaning cloths, etc.	
Pre-treating stains	
•	
Loading and switching on the washing machine	
Washing with detergent drawer	
Adding detergent using the detergent dispenser drawer	
	2 ¹
Bleaching agent Dyes, dye removers, and descaling agents	
Detergent dispensing	
Selecting a program	
Selecting program settings	
Selecting Extras	
Pre-wash U	
Soak 🗟	
Rinse plus :::	
Rinse hold 🖂	
Filling stop III	
Intensive 🖺	
Water plus 🛨	
Program start – program end	
Timer	
Special features in the program sequence	
Spinning	29
ALUIEL LEGSE	

Changing the program sequence	30
Changing a program	30
Altering the wash program	30
Interrupting a program	30
Switching on the washing machine after a power failure	30
Adding or removing laundry	31
Frequently asked questions	32
Troubleshooting	32
Contact in case of fault	34
Frequently asked questions	34
The wash program will not start	34
Program cancellation and fault message	35
The display shows a message	35
Insufficient wash results	36
General problems with the washing machine	
The door will not open	38
Continuing a program after a power failure	39
Cleaning and care	40
Build-up of rust	40
Cleaning the detergent drawer, detergent compartments, and siphons	41
Installation	43
Installing the washing machine	43
Securing the machine	43
General operating conditions	43
Performing maintenance	44
Installation on a base	44
Shipping struts	45
Removing the shipping struts	
Water connection	46
Dispensing-agent connection to the liquid-dispensing mixer compartment	47
Drainage	48
Electrical connection	48
Optional accessories	48
Connector Box	48
Wi-Fi/LAN interface	49
Base (APWM 031/035)	49
Vapor and suds venting kit (APWM 063)	49
Supervisor level	50
Opening the supervisor level	50
Opening the supervisor level (self-service)	50
Code-based access	50
Changing the code	50
Closing the Settings menu	50

Operation/display	51
Language	51
Language menu	51
Set languages	51
Time	51
Date	51
Display brightness	52
Volume	52
Visibility parameters	52
Sorting extra options	52
Display off status	52
Delay start	52
Memory	52
Temperature unit	52
Weight unit	52
Supervisor code	53
WiFi	53
Program selection	53
Controls	53
Program packages	54
Favorite programs	54
Sort programs	54
Program color allocation	54
Expert code	54
Process technology	55
Anti-crease	55
Automatic drainage	55
Service	55
Service interval	55
External applications	55
Payment system lock	55
Connector box	
Automatic dispensing	56
Dosage	56
Peak load prevention	56
Machine parameters	56
Maximum spin speed	56
Max. adjust. temperature	56
Legal Information	56
Networking	57
	57
Pairing instructions	57
Establishing the network connection via WPS	57
Establishing the network connection via soft AP	57
Establishing the network connection using a LAN cable	57
Tachnical data	57

Technical details	59
Machine data PWM 514	59
Electrical connection	59
Installation dimensions	59
Weight and floor load	59
	59
Product safety	59
WiFi	59
PWM 520 machine data	60
Electrical connection	60
	60
Weight and floor load	60
	60
Product safety	60
WiFi	60
WiFi data protection	62
Data protection and data security	62
·	62
Convrights and licenses	62

Disposal of the packaging material

The packaging is designed to protect the washing machine against damage during transportation. The packaging materials used are selected from materials which are environmentally friendly for disposal and can therefore be recycled.

Recycling the packaging material reduces the use of raw materials in the manufacturing process and also reduces the amount of waste in landfill sites. Your dealer will take the packaging material away.

Disposing of your old machine

Old electrical and electronic machines often contain valuable materials. However, they also contain harmful substances which were essential for their correct functioning and safety. These could be hazardous to human health and to the environment if disposed of with household waste or if handled incorrectly. Therefore, please do not dispose of your old machine with household waste.



Please dispose of it at your local community waste collection/recycling center for electrical and electronic machines. Consult your dealer if necessary.

Please ensure that your old machine poses no risk to children while being stored for disposal.

▶ Ensure that the door locks are unusable when disposing of or scrapping old washing machines. This will prevent the risk of anyone or anything accidentally locking themselves in while playing and endangering their lives.

Miele cannot be held liable for damage caused by failure to comply with these IMPORTANT SAFETY INSTRUCTIONS.

Energy saving tips

Energy and water consumption

- Make use of the **maximum** load size that the wash program can accommodate.

The most efficient use of energy and water is achieved when a full load is washed.

Detergent

- Do not exceed the amounts of detergent recommended on the packaging.
- Reduce the amount of detergent for smaller load sizes.

When drying with a tumble dryer

Select the highest possible spin speed for the wash program to save energy in the subsequent drying cycle.

Explanation of the safety notes and warnings on the machine

Дi)	Read the operating instructions
	Read all the instructions, e.g., the installation instructions
	Warning, hot surfaces
A	Warning, voltage up to 1,000 volts
=	Protective grounding
\Diamond	Protective equipotential bonding

This washing machine complies with all current local and national safety requirements. Inappropriate use can, however, lead to personal injury and material damage.

Read the operating instructions carefully before using the washing machine. They contain important information on safety, installation, use, and maintenance. This prevents both personal injury and damage to the washing machine.

Miele expressly and strongly advises that you read and follow the instructions in the section on installing the washing machine as well as the IMPORTANT SAFETY INSTRUCTIONS.

Miele cannot be held liable for injury or damage caused by non-compliance with these instructions.

Keep these operating instructions in a safe place and pass them on to any future user.

When instructing other people how to use the washing machine, they must be made aware of these IMPORTANT SAFETY INSTRUCTIONS.

Appropriate use

- ▶ The washing machine is only suitable for washing fabrics with a care label stating that they are suitable for machine washing. Any other applications may be dangerous. The manufacturer cannot be held liable for damage resulting from incorrect or improper use or operation of the machine.
- ▶ This washing machine must be used as described in the operating instructions and must be checked on a regular basis to make sure it is functioning correctly. Maintenance must be carried out when necessary.
- The washing machine is not suitable for outdoor use.
- ▶ Do not install the washing machine in a room where there is a risk of frost. Frozen hoses are at risk of tearing or bursting. The reliability of the electronic may be impaired at temperatures below freezing point.

- This washing machine is intended only for use in a commercial environment.
- ➤ The machine may only be operated by trained or qualified personnel. This machine is not intended to be used in a place open to the public.
- The washing machine must not be used in a non-stationary installation site (e.g., on a ship).
- ▶ This washing machine should not be used by persons with reduced physical, sensory, or mental capabilities, or a lack of experience and knowledge, unless they are supervised or instructed on its use by a responsible person.
- Children must not be allowed near the washing machine.
- Disinfection programs must not be interrupted, as this can have a limiting effect on the disinfection result. It is the operator's responsibility to ensure that the standard of disinfection in thermal as well as chemo-thermal procedures is maintained by carrying out suitable validation tests.

Preventing misuse

- Never use solvent-based cleaning agents, e.g., those containing benzine, in this washing machine. This may result in damage to component parts and create toxic fumes. **Risk of fire and explosion!**
- ▶ When washing with high temperatures, remember that the porthole glass becomes hot. Do not touch it during the wash process.

Danger of injury by burning!

- ▶ Do not damage, remove, or bypass the safety features or control elements of this washing machine.
- ▶ Machines with a damaged control panel, wires, or cords must not be used until they have been repaired.
- ▶ Water used for washing in this machine consists of suds and is not drinking water! Drain the suds into a proper drainage system.
- Always make sure that the drum is stationary before reaching in to remove laundry. Reaching into a rotating drum is extremely dangerous and may result in injury.
- ▶ Be careful not to put your hands in the gap between the door and frame when closing the drum door.

Please note: The drum door is locked automatically as soon as the washing machine starts.

▶ It is particularly important to observe the manufacturer's instructions when using a combination of cleaning agents and special application products. Products must only be used for applications approved by the manufacturer to avoid any material damage or the occurrence of strong chemical reactions.

Technical safety

- ▶ Before installing the washing machine, check it for visible signs of damage. Do not install or use a damaged washing machine.
- ▶ The electrical safety of this washing machine can only be guaranteed when correctly grounded. It is essential that this standard safety requirement is observed and regularly tested. If in any doubt, please have the electrical installation inspected by a specialist. Miele cannot be held liable for the consequences of an inadequate grounding system.

- ▶ Unauthorized repairs could result in unforeseen dangers for the user, for which the manufacturer cannot accept liability. Repairs must only be carried out by a Miele authorized technician, otherwise any subsequent damage will not be covered by the warranty.
- Do not make any alterations to the machine, unless authorized to do so by Miele.
- ▶ Disconnect the washing machine from the power supply in the event of a fault and for cleaning and maintenance. The washing machine is only electrically disconnected from the power supply when
- the electrical plug of the washing machine is unplugged, or
- the fuse is disconnected, or
- the screw-in fuse has been completely removed.

For more information, see "Installation – Electrical connection".

- ▶ The washing machine may only be connected to the water supply using the set of hoses supplied with the machine. Old sets of hoses must not be re-used. Check the sets of hoses regularly for signs of wear. Change the sets of hoses ahead of time to avoid the risk of leaks and subsequent water damage.
- ▶ The cause of any leaks must be dealt with before the washing machine is restarted. Disconnect the washing machine immediately if any water leaks out.
- ▶ In the case of a fault with the steam heating there can be increased temperatures in the vicinity of the door, the detergent compartment panel and in the drum interior (especially at the edges). Danger of burning.

This only applies for machines with steam heating.

- ▶ Faulty components must only be replaced by genuine Miele replacement parts. Miele can only guarantee the safety standards of the machine when Miele replacement parts are used.
- ▶ All relevant national provisions and regulations (DGUV in Germany) relating to accident insurance are applicable to this machine. It is recommended to carry out testing in accordance with the regulatory framework described in DGUV 100-500/Chapter 2.6/Section 4. The test book required for the documentation is available from Miele Customer Service.
- ▶ Please observe the instructions in "Installation and connection" and "Technical data".
- ▶ The electrical plug for the washing machine must always be kept accessible so that the washing machine can be easily disconnected from the power supply.
- ▶ If the washing machine is to be hard-wired, there must be a means of disconnecting all poles from the power supply. The disconnection switch must be close to the washing machine and be clearly identifiable, unhindered, and easily accessible at all times.
- A central Emergency shut off device must be available for models without an Emergency shut off.

Correct use

▶ The maximum dry-laundry weight for the PW 514 is 30 lb (14 kg), and for the PW 520 it is 45 lb (20 kg). See the "Program chart" for the maximum recommended loads for individual programs.

- ▶ Before using the washing machine for the first time, check that the shipping struts have been removed (see "Installation Removing the shipping struts"). During spinning, a shipping strut which is still in place may result in damage to both the washing machine and adjacent furniture or machines.
- Never try to open the drum door of the washing machine using force. The door can only be opened when a corresponding message appears in the display.
- ▶ Do not push back the soft mount drum of the machine while the machine is running.
- ▶ When closing the drum door there is a danger of crushing and shearing between the door frame and the drum opening and also at the hinges.

Caution: The drum door locks automatically when the machine is started.

- ➤ Turn off the water inlet if the washing machine is to be left for any length of time (e.g., during vacation), especially if there is no floor drain (gully) in the immediate vicinity.
- ► Take care to ensure that foreign objects (e.g., nails, pins, coins, paper clips) do not find their way into the machine with the laundry. These may damage components of the machine (e.g., suds container, drum). Damaged components can damage the laundry.
- ▶ If the correct amount of detergent is dispensed, the washing machine should not need to be descaled. If, however, you do wish to descale your washing machine, only use proprietary non-corrosive descaling agents. Special descaling agent is available from your Miele dealer or from Miele Customer Service. Strictly observe the instructions for the descaler.
- Solvent-based cleaning agents must not be used.
- ▶ Do not store or use gasoline, paraffin, or any easily flammable substances near the washing machine. Do not use the machine lid as storage space.

Risk of fire and explosion!

- ▶ Do not store chemicals (liquid detergents, additives) on the machine lid. They may cause discoloration or lacquer damage. Accidentally spilled chemicals should be removed from the surface immediately with a wet cloth.
- ▶ The fan casing is located on the back of the machine. The casing must never be covered or blocked. Observe the minimum distance on the installation plan.
- ▶ Only use dyes, dye removers, and descaling agents suitable for use in a washing machine. The manufacturer's instructions on the packaging must be observed.
- Dye removers contain sulfur compounds which can cause damage such as corrosion. Do not use these products in this washing machine.
- Avoid contact of stainless steel surfaces with liquid cleaning and disinfecting agents which contain chlorine or sodium hypochlorite. These agents can cause corrosion on stainless steel. Aggressive chlorine bleach vapors can also be corrosive. Do not store open containers of these agents near the machine.
- ▶ Do not use a power washer or hose to clean the washing machine.

Chlorine and component damage

- ▶ Frequent use of chlorine products increases the risk of damage to components.
- ▶ The use of substances containing chlorine, such as sodium hypochlorite and chlorine bleach in powder form, can result in damage to the protective layer of stainless steel and corrosion on components. Therefore, refrain from using substances containing chlorine. Use oxygen-based bleaching agents instead.
- If, however, chlorine bleaching agents are used, an anti-chlorine treatment must always be carried out. Otherwise, both the washing machine components and the laundry may suffer persistent and irreparable damage.
- ▶ Anti-chlorine treatment must be carried out immediately after chlorine bleaching agents have been used. Hydrogen peroxide as well as oxygen-based detergents and bleaching agents are suitable for anti-chlorine treatment. The suds must not be drained in between.


Treatments with thiosulfates can result in gypsum-like deposits particularly when used in combination with hard water. This gypsum can build up in the washing machine or cause incrustations on the laundry. Treatment with hydrogen peroxide is recommended over treatment with thiosulfates because hydrogen peroxide neutralizes chlorine.

The exact dispensing quantities and the treatment temperatures required must be set and tested on site in accordance with the dispensing recommendations of the detergent and cleaning agent manufacturers. The laundry must also be tested to check whether it contains any active chlorine residues.

Accessories

Only use genuine Miele spare parts and accessories with this machine. Using parts or accessories from other manufacturers will invalidate the warranty, and Miele cannot accept liability.


Models with detergent drawer (DD)



- ① **Display** see "Control panel"
- 2 Emergency shut-off switch see "Control panel"
- **3 Door handle**
- **4** Drum door
- **5** 4 adjustable feet
- **6** Detergent drawer
- **7 Electrical connection**
- ® Cold water connection
- Hot water connection
- ② 2 x hard water connection
 (Optional)

- (1) Connections for external dispenser pumps
- Vapor extraction/free outlet Type AB
- 13 Drainage
- ⁽⁴⁾ Cold water connection for liquid dispensing
- 15 Fan casing
- Gonnection option for direct/indirect steam (depending on model)
- ① 🖒 button
- ® Ethernet interface RJ45, for external communication
- © Connection for Connector Box (1 x model series, 2 x optional)

Models without detergent drawer (DD)




- ① **Display** see "Control panel"
- 2 Emergency shut-off switch see "Control panel"
- **3 Door handle**
- **4** Drum door
- **5** 4 adjustable feet
- **6** Electrical connection
- **7 Cold water connection**
- ® Hot water connection
- ② 2 x hard water connection (Optional)
- **10** Connections for dispenser pumps

- 11 Vapor extraction/free outlet Type AB
- 12 Drainage
- [®] Cold water connection for liquid dispensing
- 14 Fan casing
- © Connection option for direct/indirect steam (depending on model)
- 16 (button
- ① Interface for communicating with external devices
- ® Connection for Connector Box (1 x model series, 2 x optional)

Description of the machine

Control panel



① Language sensor control ≅©≅

For selecting the current user language. For Miele The supervisor language is displayed again at the end of the program.

- ② Back sensor control ← Takes you back one level in a menu.
- **3 Touch display**
- Start/Stop sensor control

For starting the wash program selected and canceling a program once it has started. The program selected can be started as soon as the sensor control starts flashing.

- 5 **Optical interface**For Miele Service.
 - For switching the washing machine on and

Sensor controls and touch display

The sensor controls ≅□등, ←, and Start/Stop and the elements in the display respond to finger tip contact. Every tap of a sensor control is confirmed with an audible keypad tone. You can adjust the volume of the keypad tone or switch it off (see "Supervisor level").


The control field with sensor controls and the touch display can be scratched by pointed or sharp objects, e.g., pens.
Only touch the control field with your fingers.

Main menu

After switching on the washing machine, the main menu will appear in the display.

You can access all the important submenus from the main menu.

Touch the \bigcirc symbol at any time to return to the main menu. Values set previously are not saved.



"☐ Programs" menu

In this menu, you can select the wash programs.

"☆ Favorites" menu

In this menu, you can select 1 favorite program from a total of 24 favorite programs. The wash programs can be set up and saved by the supervisor in the Favorites menu (see "Favorite programs" under "Supervisor level").

"۞_■ Supervisor" menu You can alter the washing machine's user interface to suit changing requirements in the supervisor level (see "Supervisor level").

Examples of how to operate the machine

Lists

"Programs" menu (single selection)



You can scroll right or left by swiping your finger across the screen. To do this, place your finger on the touch display and swipe it in the direction you want.

The orange scroll bar indicates that there are further options to choose from.


Operation

Touch a program name to select the wash program.

The display will change to the standard menu for that program.

"Extras" menu (multiple selection)

To access the level for selecting Extras, you first need to select a program, e.g., Whites.



Touch one or several Extras to select it/them.

Currently selected Extras are highlighted orange.


To deselect an Extra, simply touch the Extra again.

Use the *OK* symbol to activate all selected *Extras*.

Setting numerical values

You can set numerical values in some menus.


The following example shows how to set the time of day. The "Supervisor level" section describes how to get to this level.




Enter the numbers by swiping upward or downward.

Place your finger on the number that you want to change and move your finger in the direction you want. Use the *OK* symbol to accept the set numerical value.

Tip: A numerical keypad may also appear to adjust the value for some settings.



Briefly touching a number between the two lines will bring up the numerical keypad.



Once a valid number has been entered, the *OK* symbol will be highlighted green.

Pull-down menu

The following example describes the display for an ongoing wash program. The "Program start – program end" section describes how to get to this level.



If an orange bar appears at the top of the screen in the middle of the display, you can open the pull-down menu. Touch the bar and drag down with your finger.

Exiting a menu level

■ Touch the \hookrightarrow symbol to return to the previous screen.

Entries you have made before this which have not yet been confirmed with *OK* will not be saved.

Help display

With some menus, Help appears along the bottom line of the display.

- Touch the Help sensor control to display the text.
- Touch the Close sensor control to return to the previous screen.

Operating a laundromat machine

The main menu will vary depending on the programming status (see "Supervisor level").

Shortcuts are the easiest way to operate the machine. Operating staff are unable to change pre-set programs.

Laundromat, basic



Between 4 and 24 pre-set programs are available. These programs cannot be changed by the user.


Laundromat logo



Up to 24 pre-set programs are available. The first 3 programs can be selected directly. The remaining programs are selected from a list \blacksquare . These programs cannot be changed by the user.

Preparing for use

Emptying pockets



Empty all pockets.

Damage due to foreign objects.

Nails, coins, paper clips, and so on can cause damage to garments and components in the machine.

Check the laundry before washing and remove any such foreign objects.

Max. load

(dry laundry)

PWM 514	PWM 520
max. 30 lb (14 kg)	max. 45 lb (20 kg)

Maximum load weights are given in the program chart.

Sorting the laun-

Preparing mops, cleaning cloths,

■ Sort the laundry according to color and the garment care label.

■ Shake mops, cleaning cloths, and pads out well to get rid of coarse soiling before placing them in the washing machine drum.

Pre-treating stains Badly soiled areas and stains should be cleaned as soon as possible. Stains should be carefully dabbed off using a soft, colorfast cloth.

General tips

- Do not machine wash items which are specified by the manufacturer as not washable on the care label (\square).
- Curtains: remove rollers and lead weights or place in a laundry bag.
- Sew in or remove any loose underwiring in bras.
- Turn garments inside out, if recommended by the manufacturer.
- Zip up or close any jackets with velcro or hook and eye fastenings before washing.
- Fasten duvet covers and pillow cases to prevent small items from becoming rolled up inside them.
- Please refer to the Program chart for more tips and tricks.

Loading and switching on the washing machine

Loading the washing machine

- Switch on the washing machine with the 🖒 button.
- Pull the door handle to open the drum door.

Washing

■ Unfold the laundry and load loosely into the drum. Mixing both large and small items gives better wash results and also helps distribute the load evenly during spinning.

The most efficient energy and water consumption is achieved when a full load is washed. However, do not overload as this makes cleaning less effective and causes creases.

Closing the drum door


■ Close the drum door by pressing it until the pre-latch engages.

Make sure that no items are caught between the drum door and the sealing ring.


The drum door engages, but is not securely locked yet. The drum door locks automatically as soon as the machine starts.

Washing with detergent drawer


Adding detergent using the detergent dispenser drawer



■ For standard wash programs, add powder detergent for the main wash to the Ш compartment and if desired, add detergent for a pre-wash to the U compartment. Add fabric softener to the front of the 🖹 compartment.



■ Add any other liquid agents to the back of compartment $\mbox{$\stackrel{\otimes}{\longrightarrow}$}$ (if this has been programmed).




Do not fill the $\fill \$ compartments above the level marker with liquid agents.

They will otherwise run through the siphon and into the suds container before they are needed.

Bleaching agent

Only use bleach on fabrics with the Δ symbol on the care label.



Liquid bleaching agents must only be dispensed through the designated dispenser drawer compartment. Only then it is ensured that the agent is added in to the second rinse cycle automatically. Liquid bleaching agents should only be used on colored textiles which have a wash care label stating that they are suitable for bleaching.

⚠ Frequent use of chlorine products increases the risk of damage to components.

Dyes, dye removers, and descaling agents Proprietary dyes, dye removers, and descaling agents may only be used in this machine if the manufacturer expressly states that they are suitable for use in a washing machine. The manufacturer's instructions on the packaging must be observed.

Washing

Detergent dispensing

Avoid dispensing more than the required amount as this can cause excessive foaming.

- Only use low-foaming detergents.
- Follow the detergent manufacturer's recommendations.

The amount to dispense will depend on:

- the amount of laundry
- the water hardness
- the degree of soiling of the laundry

Amount of detergent

Please dispense according to water hardness levels and follow the detergent manufacturer's instructions.

Water hardness levels


Water hardness level	Total hardness in gpg	German scale °dH
Soft (I)	0-8.7	0-8.4
Medium (II)	8.7-14.6	8.4–14
Hard (III)	Above 14.6	Above 14

Check with your local water supplier if you do not know the water hardness level in your area.

Selecting a program

Programs

There are different ways to select a program.



You can select a program from the Programs menu.

■ Touch the Programs selection area.




- Scroll to the right in the display until the program you want appears.
- Touch the system-specific symbols on the touch display.


The display will change to the standard menu for that wash program.

Favorites

Alternatively, you can select a program from the Favorites menu.



■ Touch the Favorites selection area.



- Scroll to the right in the display until the program you want appears.
- Touch the system-specific symbols on the touch display.

The display will change to the standard menu for that wash program.


In the case of favorite programs, the majority of the program settings are already fixed and cannot be changed.

Selecting program settings


Selecting the load size

To enable load-specific external dispensing and an adapted program sequence, you can specify the load size for some programs.

■ Touch the Weight (kg) selection area.



■ Enter a valid value for the load size.




■ Press the OK symbol.

The display will change to the Overview menu.

Selecting a temperature

You can alter the pre-set temperature of a wash program.

■ Touch the Temperature (°C) selection area.



Select the desired temperature from the presets.

The display will change back to the Overview menu.

If you select the Finer adjustment selection area, you can set additional temperatures within the available temperature range by entering them directly.



- Select the desired value using the keypad.
- Press the OK symbol.


The display will change back to the Overview menu.


The temperature can only be selected within the range specified below the current setting (e.g., 57-195°F/14-90°C).

Selecting a spin speed

You can alter the pre-set spin speed of a wash program.

■ Touch the Spin speed (rpm) selection area.






■ Select the spin speed you want from the presets.

The display will change back to the Overview menu.

If you select the Finer adjustment selection area, you can set additional speeds within the available speed range.



- Select the desired value using the keypad.
- Press the OK symbol.

The display will change back to the Overview menu.


The speed can only be selected within the range specified below the current setting (e.g., 0/300–1025 rpm).

Selecting Extras

Selecting Extras

You can select Extras for some wash programs.

■ Touch the Extras selection area.



- Select one or more Extras.
- Press the OK symbol.

The display will change to the Overview menu.

Washing

Pre-wash A pre-wash can be added for heavily soiled laundry. Coarse soiling is

loosened and removed before the main wash.

Soak 🗃 For heavily soiled and stained items with protein stains. The soak du-

ration is 10 minutes.

Rinse plus An extra rinse can be activated to achieve a more thorough wash re-

sult.

Rinse hold The laundry is not spun after the final rinse and remains in the rinse

water. This helps prevent creasing if the laundry is not going to be removed from the washing machine drum immediately after the end of

the program.

Filling stop Water is drained out of the machine before the final rinse and the pro-

gram stops. The required starch, dye, proofing agent, etc. is added directly to the drum. The program is continued with the *Start/Stop* sen-

sor control.

Intensive For hard-wearing laundry that is very heavily soiled. Extending the

main wash increases cleaning efficiency.

Water plus The water level in the wash cycle will be increased.


Program start - program end

Starting a program

The program can be started as soon as the *Start/Stop* sensor control is flashing on and off.

■ Touch the *Start/Stop* sensor control.

The door will lock (⊕ symbol) and the wash program will start.



Tip: You can use the pull-down menu to display the selected temperature, spin speed, and any selected Extras.

If a delay start period (Timer) has been selected, this will appear in the display at the bottom left.



The program runtime will appear in the display either straight away or once the delay start period has elapsed. The program sequence is also shown in the display.

End of the program

Depending on the setting selected in the supervisor level or in the program, the machine will switch to the anti-crease action cycle at the end of the program. The door remains locked. The door can be unlocked at any time by touching the *Start/Stop* sensor control.

Removing the laundry

- Pull open the door.
- Remove the laundry.

Items left in the drum could discolor other items in the next wash or become discolored themselves.

Remove all items from the drum.

■ Check the door sealing ring for any foreign objects.

Tip: Leave the door slightly open to allow the drum to dry.

■ Switch the washing machine to Standby with the () button.


Tip: Leave the detergent drawer slightly open to allow it to dry.

Timer


The timer can be used to select a program start date, program start time, or program end time. This mode is also referred to as delay start.

Setting the timer

■ Touch the ① Timer selection area.



■ Select option Finish at, Start date, or Start at.



Set the hours and the minutes or the date and confirm with the OK symbol.

Deleting the timer

The selected delay start period can be canceled before the program starts.

■ Touch the selection area with the selected settings in the timer field, e.g., 01.01. 11:00.

The selected delay start period will appear in the display.

- Touch the Delete selection area.
- Confirm with the OK symbol.

The selected delay start period is deleted.

Starting the timer

■ Touch the *Start/Stop* sensor control.

The door will lock and the time until the program starts will appear in the display.

After the program has started, the selected delay start period can only be changed or canceled by interrupting the program.

The program can be started immediately at any time.

■ Touch the Start immediately selection area.

Special features in the program sequence

Spinning

Final spin speed

When a program is selected, the maximum spin speed for this wash program is shown in the display in the pre-start menu.

You can reduce the final spin speed.

Depending on the program, it may also be possible to increase the speed. The setting options are displayed when you tap the spin speed.

Rinse-spin

There is a spin cycle after the main wash and between the rinse cycles. A reduction in the final spin speed will also reduce the rinse-spin speed as appropriate.

Anti-crease

At the end of the program, the drum continues to turn at intervals for up to 30 minutes to help prevent creasing.

The drum door cannot be opened until the program has ended.

Anti-crease is program-dependent. The option can be switched on or off in the supervisor level.

Changing the program sequence

Changing a program

Altering the wash program

You will need to cancel the current program before you can select a new one.

Interrupting a program

You can interrupt a wash program at any time after it has started.


If the program is locked, the payment programs or the disinfection programs can only be canceled by entering a code.

■ Touch the *Start/Stop* sensor control.

The following will appear in the display:

i Program stopped. Continue with "Start/Stop"

The following will appear in the display:



■ Select Finish.



The suds are not drained so they can be used again in a subsequent program. Once the program has ended, the program end screen is displayed. It is possible to switch to the main menu while the suds are in the drum or to drain the suds by pressing the Start draining control. If permanent automatic water drainage is required, Automatic drainage can be activated at supervisor level.

The drum door remains locked while there is water in the machine.

The door can be opened under the condition Program end without water. If the temperature is too high, wait until it has cooled down so that the door can be opened.

- Wait until the door unlocks.
- Pull open the door.
- Remove the laundry.

Switching on the washing machine after a power failure

If the washing machine is switched off with the \circlearrowleft button during a wash program, the program will be interrupted.

■ Switch the washing machine back on with the 🖒 button.

Changing the program sequence

- Note the message in the display.
- Touch the *Start/Stop* sensor control.

The program continues.

Adding or removing laundry

You can add or remove laundry for a short period immediately after the program has started.



■ Touch the Add laundry selection area.

If the message Add laundry is not visible in the display then it is no longer possible to add items of laundry.

The wash program will stop and the door will unlock.

A Risk of chemical burns from detergent.

When adding or removing laundry, your skin may come into contact with detergent, particularly if the detergent is dispensed externally. Take care when placing your hands inside the drum.

If suds have come into contact with the skin, rinse off immediately with plenty of lukewarm water.

- Pull open the door.
- Add laundry or remove individual items.
- Close the door.
- Touch the *Start/Stop* sensor control.

The wash program will continue.


Frequently asked questions

Troubleshooting

Power failure during the wash process

- Disconnect the machine from the electrical supply (see "Safety notes").
- Close the on-site shut-off valves for water or steam.

If there is water in the machine, first open the drain valve manually and then manually unlock the drum door to remove the laundry.



- Guide the T 40 Torx wrench for the emergency-door release through the eye ① on the front of the machine.
- Open the drain valve by pulling the eye ① using the Torx wrench.
- Keep pulling the eye until the suds have drained away completely.

The suds will drain away.

The emergency drain closes automatically when the Torx wrench is removed from the eye.


■ Push the eye ① back in as far as it will go.

Unlocking the door

The drum door cannot be opened during a power failure.

① Danger from rotating drum and danger of scalding.

Before inserting the Torx wrench, make sure that the machine is disconnected, the drum has stopped, and there is no water in the machine.



■ Using a T 40 Torx wrench, turn the release element with the inner hexagon 2 whole revolutions in the direction of the arrow.

Tip: Pushing on the door at the same time makes it easier to turn the emergency release element.

The release element is opposite the door hinge at the same height as the door handle (see diagram).

The release element must not be turned against the direction of the arrow.

The door lock will be damaged.

The resistance will noticeably decrease. When the release element moves freely, the door is unlocked.

Tip: The release element does not need to be screwed back in.

The door can now be opened.

Suitable protective clothing

Suitable protective clothing must be worn when unloading the drum.

Frequently asked questions

Contact in case of fault

In the event of a fault which you cannot remedy yourself, please contact your Miele dealer or Miele Technical Service.

Contact information for Miele Technical Service can be found at the end of this document.

Please quote the model and serial number of your appliance when contacting Miele. Both pieces of information can be found on the data plate.

The data plate is on the back of the machine at the top and on the inside of the drum door.

Frequently asked questions

The majority of faults and problems that arise during day-to-day use can be remedied without external assistance. You can save time and money in many cases, as you do not need to contact Miele Customer Service.

The following tables are designed to help you to find the cause of a malfunction or an error and to resolve it. However, please note:

Repair work to electrical appliances must only be carried out by an authorized technician. Incorrect repairs can cause considerable danger to users.

The wash program will not start

Problem	Possible cause and solution
The display remains dark, and the <i>Start/Stop</i> sensor control does not light up or flash.	 There is no power to the washing machine. Check whether the washing machine is switched on. Check whether the washing machine is connected to the power supply. Check whether the fuse has tripped.
	The washing machine has switched off automatically to save energy. Switch the washing machine back on with the 🖒 button.
The following appears in the display: F - Door lock fault. You can continue by pressing the "Start/Stop" button	The door has failed to lock. Close the door again. Start the program again. If the fault message appears again, contact Miele Service.
The display is dark and the Start/Stop sensor control is flashing slowly.	If the Standby function has been activated at supervisor level, the display switches off automatically to save energy. Touch any of the controls. The display switches back on.
The program is on the prestart screen and the <i>Start/Stop</i> sensor control is not flashing.	The drum door has been pushed to but is not closed correctly. Check whether the drum door is closed correctly.

Program cancellation and fault message

Problem	Possible cause and solution
F - Water drainage fault. If restart fails. contact Service.	The drain is blocked or restricted. • Check the drain paths and clean them if necessary.
즉F - Water intake fault. If restart fails, contact Miele.	 The water inlet is blocked or restricted. Check whether the water inlet is turned on properly. Check the water inlet hoses for leaks. Check whether the water connection pressure is sufficient. Check whether the water inlet hoses are kinked.
	The water inlet filters are blocked. Clean the filters.
⚠ Disinfection temperature not reached	The required temperature was not reached during the disinfection program. The washing machine has not carried out the disinfection cycle correctly. Restart the program.
⚠ Fault F. If restart fails, contact Service.	 There may be a fault. Disconnect the washing machine from the power supply. Wait at least 2 minutes before reconnecting the washing machine to the power supply. Then switch the washing machine on again. Restart the program. If the fault message appears again, contact Miele Service.
Emergency release. Program stopped. Please close the door and turn the machine off and then back on again.	The door emergency release has been activated. Close the door and switch the machine off and on. The interrupted program can be continued once the machine has been restarted.

The display shows a message

Problem	Possible cause and solution
i Container empty	One of the liquid dispensing detergent containers is empty. • Refill the detergent containers.
i Dispensing container empty. Continuing without automatic dispensing via "Start/Stop" possible.	 One of the liquid dispensing detergent containers is empty; the program is stopped. Refill the detergent container and press the Start/Stop button to continue the wash program. If it is not possible to refill the detergent container, press the Start/Stop button to continue the wash program without detergent.
	Insufficient disinfection Disinfection programs must be canceled as no disinfectant can be added.

Frequently asked questions

Problem	Possible cause and solution
	During the last wash, a wash program with a temperature below 140°F (60°C) was selected. Start a program with a minimum temperature of 140°F (60°C) or the Clean Machine program.

Insufficient wash results

Problem	Possible cause and solution
Liquid detergent is not achieving the required results.	Liquid detergents usually contain no bleaching agents. They do not remove fruit, coffee, or tea stains. Use powder detergent containing a bleaching agent. Pour powder stain remover into drawer in the dispenser compartment and liquid detergent into a dispenser ball. Never put powder stain remover and liquid detergent together in the detergent drawer.
White residues which look like powder detergent are seen on dark textiles after washing.	 The detergent contained compounds (zeolites) to aid water softening which are not soluble in water. These have ended up on the laundry. Try and brush off the residues with a soft brush once the laundry is dry. In the future, wash dark textiles using a detergent which contains no zeolites. Liquid detergents do not usually contain zeolites.
Textiles that were very greasy are not properly clean.	 Select a program with pre-wash. Use liquid detergent for the pre-wash. Continue to use universal powder detergent for the main wash. The use of heavy-duty detergent is recommended in the
	main wash for very heavily soiled workwear. Please seek advice from the detergent and cleaning agent manufacturer.
There are gray, oily particles clinging to washed laundry.	Not enough detergent was dispensed. The laundry was heavily soiled with grease (oils, ointments). Use more detergent or liquid detergent with this type of soiled laundry. Before washing the next load, run a 140°F (60C) program with liquid detergent and no load.

General problems with the washing machine

Problem	Possible cause and solution
The washing machine shakes during the spin cycle.	The machine feet are not level and not secured. The washing machine must be secured to the floor on site according to the instructions on the installation plan.

Frequently asked questions

Problem	Possible cause and solution
residue remain in the deter-	The water flow pressure is too low. Clean the filters in the water intake.
gent drawer.	Powder detergent used in conjunction with water softeners tends to become sticky. Clean the detergent drawer and in future, add detergent first and then the water softener into the compartment.
Fabric softener is not completely dispensed or too much water remains in the ⊗ compartment.	The siphon is not correctly positioned or is clogged up. Clean the siphon (see "Cleaning the detergent drawer" under "Cleaning and care").
The display is in a different language.	A different language has been selected. Switch the washing machine off and on again. The selected supervisor language appears in the display.
	The supervisor language has been changed. Select the language you require (see "Supervisor level – Language").
The laundry has not been spun properly. The laundry is still wet.	The machine detected a high level of imbalance during the final spin and reduced the spin speed automatically. Include both large and small items in the load as this will achieve better distribution.
The drum remains stationary but the program keeps running.	 Fault in the program sequence ■ Switch the washing machine off and then back on with the ① button. ■ Note the message in the display. ■ Touch the Start/Stop sensor control. The drum continues to spin and the program continues.
The door will not open.	There is no power to the washing machine. ■ Check whether the washing machine is switched on. ■ Check whether the washing machine is connected to the power supply. ■ Check whether the fuse has tripped.
	Power failure Open the drum door as described in the next section.
	The water in the washing machine cannot be drained. Check whether the drainage system is blocked. Clean the drainage system as described in the next section.
	For safety reasons, the drum door cannot be opened if the suds temperature is higher than 122°F (50°C).

Frequently asked questions

The door will not open

Problem	Possible cause and solution
The door cannot be opened.	The door is locked during the wash process. Touch the Start/Stop sensor control. Select Program abort or Add laundry. The door will unlock and you will be able to pull it open.
	There is still water in the drum and the machine is unable to drain. Clean the drainage system as described under "Opening the door in the event of a blocked drain outlet and/or power outage".
At the end of a program or when a program is canceled, the following appears in the display: Cooling down.	To protect the user against scalding, the door cannot be opened if the suds temperature is higher than 120°F (50°C). Wait until the temperature in the drum has decreased and the message has gone out in the display.
The following appears in the display: F - Door lock fault. Contact Service.	The door lock has jammed. Contact Customer Service.

Continuing a program after a power failure

If a running program is interrupted, e.g., by a power outage, the program can be continued when power is restored.

- Switch on the washing machine with the 🖒 button.
- Then press the "START" button and follow the instructions on the display.

The program will then continue with the next stage of the last active program sequence.

Cleaning and care

■ Carry out cleaning and maintenance of the washing machine after use if possible.

Do not use a pressure washer or water jet to clean the washing machine.

Clean the machine casing, control panel, and plastic parts with a mild, non-abrasive cleaning agent or with a soft, damp cloth only. Wipe dry with a soft cloth.

Scouring agents will scratch the surface.

- Clean stainless steel parts of the casing with a standard commercial stainless steel cleaner.
- Remove any deposits from the door seal with a damp cloth.

Do not allow cleaning agents to penetrate the electrical components.

■ When disinfecting the surfaces, use a moist cloth only to clean the front and around the door lock. Do not spray any liquids.


Tip: Heavy deposits of dust around the vents housing should be removed with a vacuum cleaner. The fan casing is located on the back of the machine.

Build-up of rust

The drum is made of stainless steel. Water or foreign objects containing ferrous substances (e.g., paper clips, metal buttons, or metal swarf) which are placed in the machine with the laundry can cause a build-up of rust in the drum. Clean the drum regularly in this case and if rust occurs, remove it immediately with a proprietary stainless steel care product. Check the door seals for ferrous residues and clean thoroughly as described above. This must be carried out regularly.

Cleaning the detergent drawer, detergent compartments, and siphons

- Clean the detergent drawer and the detergent compartments thoroughly with hot water as required to remove detergent residues and incrustations.
- If the machine is not going to be used for a long time, leave the flap of the detergent drawer open.
- Also clean the siphons in the compartments for cleaning agents.




■ Remove the siphon. Clean the siphon with hot water and reinsert it.

Cleaning and care


Cleaning the drip channel and siphon

■ Open the flap on the detergent drawer to an angle of 45° and lift out the flap of the detergent drawer on the right side.



If the drip channel and associated drain connection are blocked, clean them.

■ Check the vapor extraction grille on the rear of the machine for soiling from time to time and clean when necessary.



■ The filters in the water intake valves (1) and the inlet hoses (2) must be checked for soiling from time to time and cleaned as necessary.

Installing the washing machine

The washing machine must be installed by Miele Service or by an authorized dealer. Please observe the instructions in the installation plan.

This washing machine is only intended for items of laundry that have not been proofed with dangerous or inflammable substances.

- To avoid the risk of frost damage, the washing machine must not be located in rooms which may be subject to very low temperatures.
- Transport the machine on a pallet truck inside the room.

Machines with feet must not be pushed to move them. This could damage the machine feet.

- Remove the packaging carefully with a suitable tool.
- Lift the machine off the pallet using a lifting device.

Securing the machine

■ The feet of the washing machine must be secured to the floor using the fixtures and fastenings supplied.

The material provided is intended for use in bolting the machine to a concrete floor. If other floor types are present at the installation site, the fastening material must be ordered separately.

General operating conditions

This washing machine is intended only for use in a commercial environment and must only be operated indoors.

Ambient temperature in installation room: 32°F (0°C) to 140°F (40°C) Relative humidity: non-condensing


Depending on the nature of the installation site, sound emissions and vibration may occur.

Tip: Have the machine's installation site inspected and seek the advice of a specialist in instances where increased noise may cause a nuisance.

Performing maintenance

To facilitate future maintenance and servicing by Miele Service, the minimum clearances and distance to the wall must be provided to enable access.

■ You must observe the minimum clearances and distance from the wall.



Minimum safety distance to the wall approx. 15 3/4" (400 mm) to allow for maintenance.


Adjust the washing machine's adjustable feet until the machine is level.


The washing machine must be completely level to ensure smooth operation.

Installation on a base

When installed on a raised base, the machine must be secured to the base and the base must be secured to the floor. When installed on a concrete base, the machine must be secured to the base.

Shipping struts





Removing the shipping struts

The 2 shipping struts in the front are secured with 3 hexagonal screws each. The shipping strut in the back is secured with 4 hexagonal screws. The shipping struts must only be removed at the installation site before the washing machine is commissioned.

- Remove the front and back panel:
- Unscrew the screws at the bottom of the front panel and remove the panel.

Installation

- Unscrew the screws at the bottom of the back panel and remove the panel.
- Loosen the hexagonal screws to remove the shipping struts.

Keep the shipping struts. They must be re-assembled before transporting the machine.

Water connection

Water pressure (flow pressure) of a minimum of 14.5 psi (100 kPa) / maximum of 145 psi (1,000 kPa) is required to guarantee a problem-free program sequence.


The machine must be connected to the water connection using the water inlet hoses provided.

Hoses must be replaced with hoses tested for a burst pressure of at least 1,015 psi (7,000 kPa) overpressure and for water temperatures of a minimum of 105°F (90°C).

This also applies to the associated connection fittings. Original spare parts meet these requirements.

Tip: The hot water supply must not exceed a maximum temperature of 160°F (70°C). For machines with reduced heater rating and external heating, the incoming hot water must not exceed a temperature of 105°F (90°C).


Dispensing-agent connection to the liquid-dispensing mixer compartment



Connections **1** and **2** are provided for viscous agents. These connectors are closed and must be drilled open using an 8 mm bit.

Connections **1** and **2** can also be used for high-pressure dispensing systems with water injection.

The dispensing systems must be equipped with a separate drinkingwater safety feature in accordance with EN 61770 and EN 1717.



Care must be taken to drill through the first wall (1) only, as there is a deflecting wall (2) 3/8" (10 mm) behind it.

If the drilled-out connections are no longer required, they must be resealed.

Connections **3** to **12** are provided for liquid dispensing. These connectors are sealed and must be cut to suit the diameter of the hose with a suitable hacksaw. If opened connectors are no longer required, they must be capped off.

Drainage

Drain valve **DV** on machine side DN 70, on-site socket DN 70. Flow rate temporary 200 l/min.

If the slope for drainage is extremely steep, the piping must be vented to prevent a vacuum from forming in the washing machine's drainage system.

Electrical connection

The electrical connection must only be carried out by a suitably qualified electrician in accordance with local and national regulations.

Tip: Open the machine lid. The connection points are located on the machine frame.

When installing a residual current device (RCD), it must be Type B. The voltage is stated on the data plate.

For hard-wired machines, an all-pole means of deactivation must be provided on site. Switches with a minimum contact gap greater than 1/8" (3 mm) are suitable disconnectors.

The plug connector or isolator switch should be easily accessible at all times.

If the machine is disconnected from the electricity supply, the isolator must be lockable or the point of disconnection must be monitored at all times.

Please check the enclosed wiring diagram. The wiring plan can be called up using the QR code on the machine.

Optional accessories

Only use genuine Miele spare parts and accessories with this machine.

Using parts or accessories from other manufacturers may void the warranty, and Miele cannot accept liability.

Connector Box

The Connector Box allows external hardware from Miele and other suppliers to be connected to the Miele Professional washing machine.

The Connector Box is supplied with voltage by the Miele Professional washing machine.

The separately available set consists of the Connector Box and fasteners for installation on the machine or on the wall.

Peak load/energy management

A peak-load or energy management system can be connected via the Connector Box.

Peak-load negotiation monitors the energy consumption of a system and deactivates individual pieces of equipment temporarily in order to ensure that certain total load limits are not exceeded. Monitoring is externally controlled.

When the peak-load function is activated, the heating is deactivated and the program stopped. A message appears in the display to inform you of this.

The program is resumed automatically when the peak-load function finishes.

Liquid dispensing connection

External liquid dispenser pumps with a "container empty" indicator and/or flowmeters can be used via the Connector Box to dispense liquid detergents.

It is particularly important to observe the manufacturer's instructions when using a combination of cleaning agents and special application products.

Wi-Fi/LAN interface

The washing machine is equipped with a Wi-Fi/LAN interface for exchanging data.

The data interface provided on the LAN connection complies with SELV (Safety Extra Low Voltage). The LAN connection uses a RJ45 connector in accordance with EIA/TIA 568-B.

Connected machines must also comply with SELV.

Base (APWM 031/035)

The washing machine can be installed on a machine base (open or box base, available as an optional Miele accessory).

Elevating the washing machine gives a better ergonomic working position when loading or unloading. At the same time it facilitates the installation of a drain connection.

The washing machine must be secured to the base immediately after installation! The base must be secured to the floor!


There is a risk of the washing machine falling off a raised base during a spin cycle if it is not secured.

Vapor and suds venting kit (APWM 063)

If excessive suds form, suds may escape from the vapor vent. An optional vapor and foam venting kit can be used to remove the foam.

Opening the supervisor level

Switch on the washing machine.



■ Touch the Supervisor ۞ selection area.

The display will change to the Supervisor level menu.

Opening the supervisor level (self-service)

- Switch on the washing machine and open the door.
- 1 Touch the Start/Stop sensor control and hold it down whilst carrying out steps 2-3.
- 2 Close the washing machine door.
- The Start/Stop sensor control will now be flashing quickly; wait until it lights up constantly.
- Release the Start/Stop sensor control when the Start/Stop sensor control lights up constantly.

Code-based access

The supervisor level is accessed using a code.

The code is **000** (factory default).

After entering the code, you will be in the supervisor level. The individual setting options are described in the following sections.

Changing the code

You can alter the supervisor level access code to protect the washing machine from unauthorized access.

Please inform Miele Customer Service if you have forgotten your new code. Customer Service will have to reset the code.

Make a note of your new code and store it in a safe place.

Closing the Settings menu

■ Touch the symbol.

The display will then go back to the previous menu level.

■ Touch the △ symbol.

The display will change to the main menu.

Operation/display

Language

The display contents can be displayed in a variety of languages. To select the permanent supervisor language you want, go to the Languages submenu.

When a program is running, you can change the user language using the ᠳ□⊜ sensor control.

Language menu

The display can be set to one of several different user languages. This setting allows you to determine how languages can be selected.

International

6 languages are available. The 🗷 🗷 sensor control is not active. Note the setting Set languages.

Language setting

The ♥□♥ sensor control can be used to select a language. All languages are available (factory default).

You can change the order of the first 4 languages. These slots are allocated to the most commonly used languages.

Standard language

The user language cannot be changed. The user language is the same as the supervisor language. The ➡□➡ sensor control is not active.

Set languages

The languages for the Language entry International setting can be changed.

6 languages can be selected. All languages are available.

If you wish to add a new language to the language menu:

■ First select the language you want to replace.

All available languages are displayed.

Select and confirm the language to replace the previous language.

The new language appears instead of the old one.

Time

After selecting the clock format, you can set the time of day.

Clock format

- 24 h clock
- 12 h clock
- No clock

Set

- The time can be set.

Date

The date can be set after selecting the date format.

Date format

- DD.MM.YYYY
- YYYY.MM.DD
- MM.DD.YYYY

Date

- The date can be set.

Supervisor level

Display brightness

The brightness of the display can be altered. The setting depends on the various lighting conditions in the place of installation.

It can be set to one of 10 different levels.

Volume

The volume for various sounds can be changed.

It can be set to one of 7 different levels or switched off altogether.

- Finish tone
- Keypad tone
- Welcome tone
- Fault tone

The fault tone can be activated or deactivated.

Visibility parameters

Various parameters, such as the temperature, spin speed, Extras, etc., are displayed when a program is selected. You can decide which parameters should not be displayed. The parameters cannot be changed/are no longer displayed.

Factory default: all parameters are visible (marked in orange)

Sorting extra options

Under the setting Visibility parameters, Sort Extras appears in the bottom line. Touch the sensor control to change the sequence of extra options (see "Supervisor level — Arranging programs").

Display off status

In order to save energy, the display can be set to switch to standby mode automatically after the end of the program or if no further selection is made. In the default setting, the machine will not switch to standby mode automatically.

Changing this setting leads to increased energy consumption.

- Off
- On (10 min.) Not curr.prog.
- Logo (10 min.) Not curr.prog.
- On after 10 min.
- On (30 min.) Not curr.prog.
- Logo (30 min.) Not curr.prog.
- On after 30 min.

Delay start

The delay start (timer) display can be switched on or off.

Factory default: on

Memory

The washing machine will save the settings (temperature, spin speed, and some of the options) which have been selected for a wash program after the program has started.

When the wash program is chosen again, the saved settings will appear in the display.

Factory default: off

Temperature unit

You can select the unit for the temperature display (°C/°F).

Weight unit

You can decide whether load sizes are displayed in "kg" or "lbs".

Supervisor code

You can alter the access code to the supervisor level. The supervisor code is not the same as the expert code.

- Enter the current code.
- Enter a new code.

WiFi

For the use of WiFi / LAN additional Miele digital products are necessary. The ability of Miele digital products depends on the availability of the services in your country.

The different services are not available in all countries.

For information about availability, please visit www.miele.com.

Control the networking of your washing machine.

- Setup

This message only appears if the washing machine has not yet been connected to a WiFi network.

- Deactivate (visible when the network is activated)

The network remains set up; the WiFi function is switched off.

- Activate (visible if the network is deactivated)

The WiFi function is reactivated.

- Connection status (visible when the network is activated)
 - The quality of WiFi reception
 - The network name
 - The IP address
- Set up again (visible if already set up)

Resets the WiFi login (network) to immediately re-establish a new connection.

- Reset (visible if already set up)

The network is no longer set up. A new connection has to be established in order to use the network again.

- The WiFi is switched off
- The WiFi connection will be reset to the factory default

Program selection

Controls

Tip: Start by configuring all necessary settings and changes to the washing machine before selecting any of the options below.

If "Laundromat, basic" or "Laundromat, Logo" is selected, the supervisor level can no longer be opened from the display after the *Supervisor level* is closed. Please follow the instructions below for special access to the supervisor level if you wish to change any other settings.

Standard (factory default).

All functions and programs can be displayed.

Laundromat, basic

Supervisor level

Up to 24 programs are available. Go to Favorite programs to select which programs are to be listed.

Laundromat logo

Up to 24 programs are available. Go to Favorite programs to select which programs are to be listed.

External program selection

Programs are selected using a communication module with Ethernet, e.g., via an external terminal.

Program packages

The selection of programs can be expanded by activating single programs from the target group program packages.

The programs selected from the program packages (marked in orange) are displayed during program selection.

Favorite programs

After switching on, you can also select a program via: \triangle Favorites. 24 programs can be stored as favorites based on your own priorities and requirements.

These favorite programs will also be made available in the control options

- Laundromat logo
- Laundromat, basic control options.

You can specify the control option under Controls.

Tip: You can assign a separate colored frame to each program. In this case, the "Color assign. program setting must be set to *On*.

Changing favorite programs

- Select the program you wish to change or replace.
- Confirm the program or the setting to be changed.

Another menu opens, enabling you to select a new program or change the parameters.

■ Confirm by touching the Save selection area.

Your selection is now active.

Sort programs

Programs can be moved within the program list and in the favorites list.

Factory default: off

Moving programs

- Touch the selection area for the program you want to move.
- Press and hold the selection area until the frame changes.
- Drag the program to the required place.

Program color allocation

You can assign a frame to a favorite program. In the list of favorites, each favorite program is given a colored frame, which can be adjusted.

Factory default: on

Expert code

A code has to be entered to cancel a disinfection program. The code can be modified.

The expert code is not the same as the supervisor level code.

The code is: 0 0 0

Make a note of your new code if you ever change it.

Process technology

Anti-crease

The Anti-crease function helps prevent creasing after the end of the program. At the end of the program, the drum continues to turn for up to 30 minutes.

The washing machine door can be opened at any time during the Anticrease phase.

Factory default: on

Automatic drainage

Automatic water drainage can be switched on or off. Automatic water drainage means that the suds are always drained away after the end of a program. This is also the case for programs that reach the program end with water still in the drum.

Service

Service interval

Service information can appear in the display. You can configure whether a date or the number of operating hours is displayed.

You can select up to 3 messages with their own text.

Your message is displayed at the end of the program and can be acknowledged with *OK*. The same message appears at the end of the next program.

Settings

This setting allows you to determine the interval (by hours or date) at which the message appears.

- Factory default: off
- By time

You can then select a time interval from 1–9,999 hours.

- By date

You can then enter a date.

Message text

Enter your message for your planned maintenance work.

Resetting the display

The message appears until the display is permanently reset. The message then appears again once the next interval is reached.

External applications

Payment system lock

The payment device lock can be switched on or off. When the lock is switched on, the duration until locking can be selected from various time intervals.

Connector box

External hardware is connected via the Connector Box. This can be switched on or off.

Supervisor level

The Connector Box must be selected in order for settings to be made in the Dispensing menu.

Automatic dispensing

Automatic dispensing can be switched on or off.

Automatic dispensing can be activated via the Connector Box or the COM module.

Dosage

The Connector Box must be switched on in order for settings to be adopted in the Dispensing menu.

1–6 dispenser pumps can be switched on.

Further settings can be made after activating the dispenser pump.

- Deactivate disp. pump
- Calibration
- Flow rate (new): ml/min
- Correction factor
- Container size
- Adv. warning level reminder
- Reset adv. warning
- Level reminder
- Flow meter

Peak load prevention

The peak-load prevention function can be switched on or off. With this function, the execution of a wash program is not affected when a peak-load signal is in place. The heater stays switched on.

Machine parameters

Maximum spin speed

Max. adjust. tem-

perature

Legal Information

The maximum spin speed can be set via a keypad.

The maximum temperature can be set via a keypad.

Open source licenses

You can view information here (see WiFi data protection).

Pairing instructions

Follow the steps below to connect the washing machine to your network.

Opening the supervisor level

- Select the Supervisor menu option in the machine display.
- Select the Access via code menu option.
- Enter the 3-digit supervisor code.

Establishing the network connection via WPS

- Select the Supervisor level menu option from the External applications menu.
- Then select the WiFi / LAN menu option.
- Select Set up.
- Select the Via WPS connection method.
- Now press the WPS button on your router and confirm with OK in the machine display.

A timer starts. The network connection via WPS is being established.

The machine is now successfully connected.

■ Tap OK to confirm.

Establishing the network connection via soft AP

- Select the Supervisor level menu option from the External applications menu.
- Then select the WiFi / LAN menu option.
- Select Set up.
- Select the Via Soft AP connection method.
- Confirm by pressing OK and follow the instructions in the external application.

Establishing the network connection using a LAN cable

■ Connect the machine to your router/switch using the network cable. The router/switch must be connected to the Internet.

The machine is now successfully connected.

Technical data

System requirements for WiFi

- WiFi 802.11b/g/n
- 2.4 GHz band
- WPA/WPA2 encryption
- DHCP activated
- MulticastDNS/Bonjour/IGMP snooping activated
- Ports 443, 80, 53, and 5353 open
- IP DNS server = IP standard gateway/router
- Mesh/repeater use: same SSID and password as standard gateway/router
- SSID must be permanently visible

Networking

System requirements for LAN

- DHCP activated
- MulticastDNS/Bonjour/IGMP snooping activated
- Ports 443, 80, 53, and 5353 open
- IP DNS server = IP standard gateway/router

WiFi signal strength - Guide values

The WiFi signal strength is only a rough guide. These details do not provide absolute certainty.

The WiFi signal strength can be read via the MDU or directly on the machine.

WiFi signal strength			
MDU	*	Meaning	
76–100%	3/3**	Deliable eneration possible	
51–75%	2/3	Reliable operation possible	
26-50%	1/3	Operation possible	
1–25%	0/3	Reliable operation not possible	
0%	Ŕ	Operation not possible	

^{*} Displayed on the machine

The signal strength can be disturbed by many influences:

- people in the room
- open or closed doors
- moved objects
- varying radio signal sources or interference
- other machines with Bluetooth or WiFi wireless technology

^{**} Number of bars 🕏 3/3-0/3

Machine data PWM 514

Electrical connection

Connection voltage	See data plate
Frequency	See data plate
Power rating	See data plate
Current	See data plate
Fuse rating	See data plate
Heater rating	See data plate

Installation dimensions

Casing width (without add-on components)	31 5/16" (795 mm)
Casing height (without add-on components)	53" (1347 mm)
Casing depth (without add-on components)	35 1/4" (895 mm)
Overall machine width	31 7/16" (799 mm)
Overall machine height	53 1/8" (1350 mm)
Overall machine depth	43 1/16" (1093 mm)
Minimum width of transport opening	35 7/16" (900 mm)
Minimum distance between wall and front of machine	54 3/8" (1380 mm)
Door opening diameter	16 5/16" (415 mm)
Door opening angle	180°

Weight and floor load

Net weight	see installation plan
Maximum floor load during operation	see installation plan

Emission values

Emission sound pressure level in accordance with EN ISO 11204/11203	< 70 dB(A) re 20 μPa
Sound power level, EN ISO 9614-2	< 80 dB(A)

Product safety

Product safet	y standards	See data plate

WiFi

Frequency range of the WiFi module	2.400-2.4835 GHz
Maximum transmission power of the WiFi module	< 100 mW

Technical details

PWM 520 machine data

Electrical connection

Connection voltage	See data plate
Frequency	See data plate
Power rating	See data plate
Current	See data plate
Fuse rating	See data plate
Heater rating	See data plate

Installation dimensions

Casing width (without add-on components)	36 1/4" (920 mm)
Casing height (without add-on components)	56 15/16" (1447 mm)
Casing depth (without add-on components)	33 3/4" (857 mm)
Overall machine width	36 3/8" (924 mm)
Overall machine height	57 1/16" (1450 mm)
Overall machine depth	41 1/2" (1053 mm)
Minimum width of transport opening	40 9/16" (1030 mm)
Minimum distance between wall and front of machine	54 3/8" (1380 mm)
Door opening diameter	16 5/16" (415 mm)
Door opening angle	180°

Weight and floor load

Net weight	see installation plan
Maximum floor load during operation	see installation plan

Emission values

Emission sound pressure level in accordance with EN ISO 11204/11203	< 70 dB(A) re 20 μPa
Sound nower level EN ISO 9614-2	< 80 dR(A)

Product safety

Product safety standards	See data plate
--------------------------	----------------

WiFi

Frequency range of the WiFi module	2.400–2.4835 GHz
Maximum transmission power of the WiFi module	< 100 mW

ANY CHANGES OR MODIFICATIONS NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

THIS DEVICE COMPLIES WITH PART 15 OF THE FCC RULES AND CONTAINS LICENSE-EXEMPT TRANSMITTER(S)/RECEIVER(S) THAT COMPLY WITH INNOVATION, SCIENCE AND ECONOMIC DEVELOPMENT CANADA'S LICENCE-EXEMPT RSS STANDARD(S). OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRED OPERATION.

Contains FCC ID: 2ACUWEK047

Contains IC: 5669C-EK047

RADIATION EXPOSURE STATEMENT: THIS EQUIPMENT COMPLIES WITH FCC AND WITH ISED RADIATION EXPOSURE LIMITS SET FORTH FOR AN UNCONTROLLED ENVIRONMENT. THIS EQUIPMENT SHOULD BE INSTALLED AND OPERATED WITH A MINIMUM DISTANCE OF 20CM BETWEEN THE RADIATOR AND YOUR BODY. THIS DEVICE AND ITS ANTENNA(S) MUST NOT BE CO-LOCATED OR OPERATION IN CONJUNCTION WITH ANY OTHER ANTENNA OR TRANSMITTER.

Miele hereby declares that this washing machine complies with Directive 2014/53/EU. The complete text of the EU declaration of conformity is available from one of the following Internet addresses:

- Or go to http://www.miele.de/professional/gebrauchsanweisungen-177.htm and enter the name of the product or the serial number

Data protection and data security

When you activate the networking function and connect your machine to the Internet, your machine sends the following data to the Miele Cloud:

- machine serial number
- machine model and technical features
- machine status
- information about the software status of your machine

Initially, this data cannot be assigned to a specific user and is not saved permanently. Data cannot be saved permanently or assigned to a specific user until after you have linked your machine to a user. Data transmission and processing are governed by Miele's strict security standards.

Factory default settings for network configuration

You can reset all of the settings on the communication module or your integrated WiFi module to the factory default settings. The network configuration should be reset whenever a machine is being disposed of or sold, or if a used machine is being put into operation. This is the only way to ensure that all personal data has been removed and the previous owner will no longer be able to access the machine.

Copyrights and licenses

For the purpose of operating and controlling the communication module, Miele uses proprietary or third-party software that is not covered by open source licensing terms. This software/these software components are protected by copyright. The copyrights held by Miele and third parties must be respected.

This communication module contains software components which are distributed under open source licensing terms. The open source components contained in the machine along with the corresponding copyright notices, copies of the licensing terms valid at the time, and any additional information can be accessed locally by IP via a web browser (https://<IP address>/Licenses). The liability and warranty arrangements for the open source licenses displayed in this location only apply in relation to the respective rights holders.



Please have the model and serial number of your machine available when contacting Technical Service.

U.S.A. Miele, Inc.

National Headquarters

9 Independence Way Princeton, NJ 08540 Phone: 800-991-9380 www.mieleusa.com/professional prosales@mieleusa.com

Technical Service & Support

Phone: 800-991-9380 proservice@mieleusa.com

Canada Importer Miele Limited

Professional Division

161 Four Valley Drive Vaughan, ON L4K 4V8 Phone: 1-888-325-3957 www.mieleprofessional.ca professional@miele.ca

Miele Professional Technical Service

M.-Nr. 11 872 032 / 00

Phone: 1-888-325-3957 serviceprofessional@miele.ca



Manufacturer: Miele & Cie. KG

Carl-Miele-Straße 29, 33332 Gütersloh, Germany