

M.-Nr. 12 800 570 / 00

DAP 1627, DAP 1727, DAP 1927

⚠ To prevent accidents and appliance damage, read the Operating and Installation Instructions before installation or use.

The following installation instructions assume that there is a solid surface behind the wall as outlined in the Operating and Installation instructions!

Wall anchors included in the packaging are not for use in USA / CDN.

CAUTION: During the installation process, please be careful of sharp edges that can cause harm.

⚠ Pour prévenir les accidents et éviter d'endommager l'appareil, veuillez lire Instructions d'utilisation et d'installation avant l'installation ou l'utilisation.

Les instructions pour l'installation suivantes exigent qu'il y ait une surface solide derrière le mur, tel qu'indiqué dans les Instructions pour l'utilisation et l'installation!

Les ancrages de cloison compris dans l'emballage ne conviennent pas aux E.U. / CDN.

AVERTISSEMENT : Durant l'installation, veuillez faire attention aux rebords tranchants qui pourraient vous blesser.

⚠ Antes de instalar y usar el aparato y con el fin de prevenir accidentes y daños al mismo, lea el Manual de uso y manejo correspondientes.

Las siguientes instrucciones de instalación suponen que hay una superficie sólida detrás de la pared, tal como se describe en el Manual de uso y manejo. Los taquetes de pared incluidos en el paquete no son para usarse en EE.UU. ni en Canadá.

PRECAUCIÓN: Durante el proceso de instalación, tenga cuidado con los bordes afilados que pudieran ocasionar daños.

1 AE
- Air extraction mode
- Mode d'évacuation
- Modalidad de extracción de aire

2 RM
- Recirculation mode
- Mode de circulation d'air
- Modalidad de recirculación

3 $\phi 1/8"$
 $\phi 3\text{mm}$
8x T30
5x60mm

4 AE

Dimensions:
18 11/16" 475mm
15 3/16" 385mm

5 2x M6

6 5 mm
2x

7 2x

8 2x

9 AE

10 RM
Miele DUW 20

11

12 AE

12 RM

13

14 2x T20
3.9x7.5mm

15 DAP 1627 2x
DAP 1727 2x
DAP 1927 3x

16 RM Miele DKF 12-900

17 DAP 1627 2x
DAP 1727 2x
DAP 1927 3x