

Stop  
Stop  
for the basket guide in the dishwasher

EAN: 4002511508910 / Material number: 02154400 / Old Material Number:



- Stops basket from being pulled out
- for the cutlery tray
- for G1xxx-G6xxx
- for G3xx, G5xx, G6xx, G7xx, G8xx