

## ESW 7110

14 cm high gourmet warming drawer without handle for preheating crockery, keeping food warm and low temperature cooking.

- The ultimate in enjoyment low temperature cooking
- Always at the right temperature 4 functions
- Convenient and easy Touch control
- Opening the drawer couldn't be easier Push2open
- Better safe than sorry timer function with automatic switch-off


EAN: 4002516169918 / Material number: 11093340 / Old Material Number: 30711040GB

Gourmet warming drawer ContourLine Handleless Colour Operating modes Cup warming Plate warming Keeping food warm Low temperature cooking User convenience Miele@home Capacity Push2open mechanism Fully telescopic runners for easy loading and unloading of	Stainless steel/Clean Steel  Stainless steel/Clean Steel  6 place settings
Handleless Colour Operating modes Cup warming Plate warming Keeping food warm Low temperature cooking User convenience Miele@home Capacity Push2open mechanism Fully telescopic runners for easy loading and unloading of	•
Colour  Operating modes  Cup warming  Plate warming  Keeping food warm  Low temperature cooking  User convenience  Miele@home  Capacity  Push2open mechanism  Fully telescopic runners for easy loading and unloading of	•
Operating modes Cup warming Plate warming Keeping food warm Low temperature cooking User convenience Miele@home Capacity Push2open mechanism Fully telescopic runners for easy loading and unloading of	•
Cup warming  Plate warming  Keeping food warm  Low temperature cooking  User convenience  Wiele@home  Capacity  Push2open mechanism  Fully telescopic runners for easy loading and unloading of	•
Plate warming Keeping food warm Low temperature cooking User convenience Wiele@home Capacity Push2open mechanism Fully telescopic runners for easy loading and unloading of	•
Keeping food warm  Low temperature cooking  User convenience  Miele@home  Capacity  Push2open mechanism  Fully telescopic runners for easy loading and unloading of	6 place settings
Low temperature cooking  User convenience  Miele@home  Capacity  Push2open mechanism  Fully telescopic runners for easy loading and unloading of	6 place settings
User convenience Miele@home Capacity Push2open mechanism Fully telescopic runners for easy loading and unloading of	6 place settings
Viele@home Capacity Push2open mechanism Fully telescopic runners for easy loading and unloading of	6 place settings
Capacity Push2open mechanism Fully telescopic runners for easy loading and unloading of	6 place settings
Push2open mechanism  Fully telescopic runners for easy loading and unloading of	6 place settings
Push2open mechanism  Fully telescopic runners for easy loading and unloading of	
, , , , , , , , , , , , , , , , , , , ,	•
the warming drawer	•
Control panel with sensor controls	•
Control panel with symbols	•
Stop programming	•
Timer function	•
Sabbath programme	•
Efficiency and sustainability	
Power rating in off mode in W	0.5
Power rating in standby mode in W	1.0
Power rating in networked standby in W	2.0
Fime until automatic switch to off mode in min	20
Fime until automatic switch to standby in min	20
Fime until automatic switch to networked standby in min	20
Cleaning and care	
Stainless steel/CleanSteel finish	•
Flush control panel	•
Safety	
Cool front	•
Anti-slip mat	•
Safety switch-off	•
Technical data	
Femperatures min. in °C	40
Temperatures max. in °C	85
Appliance width in mm	595
Appliance height in mm	141
Appliance depth in mm	570
Jseable interior height in mm	80
Total rated load in kW	0.70
Voltage in V	230
	•
Frequency in Hz	50-60
Fuse rating in A	10
Number of phases	. 1
Mains cable with plug	•
Length of supply lead in m	2.0
Accessories included Anti-slip mat	1


## Míele

## ESW 7110

14 cm high gourmet warming drawer without handle for preheating crockery, keeping food warm and low temperature cooking.







ESW7010, ESW7110 - installation drawing – Installation – GB, AU

1) Front view, 2) Mains connection cable, L=2,000 mm, 3) ventilation cut-out min. 180 cm $^2$ , 4) no connection in this area