

Ersatzteile Küche
Stop
for the basket guide in the dishwasher

EAN: 4002512425438 / Material number: 05310670 / Old Material Number:



- Stops basket from being pulled out
- for baskets
- for G3xx, G6xx, G7xx, G8xx