

Drain pump Synchronous motor
Drain pump synchronous motor
drain pump for draining water out of the dishwasher

EAN: 4002516283010 / Material number: 11025001 / Old Material Number:



- Type of fault: F11 – water drainage fault, water intake/draining LED flashing
- Type of fault: Water is present in the machine and is not being drained off
- Repair time: approx. 30 minutes
- Tool: T20 screwdriver, towels, protective gloves
- Tool: syringe (optional for residual water)
- for G3xx, G6xx, G8xx, G1xxx, G2xxx, G3xxx, G4xxx, G5xxx up to 2017, G6xxx, G7xxx