

## Hygiene tips

### on using frontloading washing machines

- Make sure that soiled items are collected and delivered to the laundry in colour-coded laundry sacks, preferably sorted by type in self-opening laundry bags
- Load washing machines with the self-opening bags without first removing the bag contents. Self-opening bags unwrap automatically during the wash process if the drawstring has been released
- Select the correct wash cycle (thermal or chemo-thermal disinfection) for hygienic reprocessing
- Make sure when manually dispensing detergent that the prescribed quantity is properly measured and that an appropriate temperature for the detergent is set
- Disinfect the door and its surroundings (door, door gasket, machine front) and the control panel before removing clean laundry from the machine
- Never take workwear home for washing. It should always be reprocessed in the laundry in order to protect the wearer and others. Always use a disinfection wash cycle for this purpose
- Delicate garments require washing at low temperatures. Please contact your detergent supplier in order to ensure the correct choice of detergent and/or disinfectant

