

Detergency booster/Booster

Application:

ProCare Tex 10 B+ is a pH-neutral detergency booster based on special tenside combinations for use on stubborn grease.

ProCare Tex 10 B+ is for use in professional washing machines.





Product properties:

- Effective at temperatures above 40 °C
- Highly effective on laundry soiled with grease
- For use as a detergency booster, wetting agent or emulsifier
- Particularly gentle on fabrics and colours

Dispensing recommendation [ml per kg of laundry]:

ProCare Tex 10 B+ can be used in the pre-wash and, in the case of extreme soiling, as an additive in the main wash.

The dispensing recommendation depends on the application. When used as a fat solvent or detergency booster, please note the dispensing table below.

			
1°dH ≈ 0,18 mmol/l	ml/kg	ml/kg	ml/kg
°dH			
0 – 8,4	2	4	8
8,4 – 14	4	8	10
> 14	8	10	15

Water hardness ranges and figures can be provided by water authorities.

When used as a wetting agent, 2–3 g are dispensed per kg of dry laundry; as an emulsifier on laundry heavily contaminated with pigments, 15–20 g are dispensed per kg of dry laundry.

ProCare Tex 10 B+ is designed to perform best in Miele Professional washing machines.

- Precise and economic dispensing via dispensing pump
- Dispensing recommendation depends on water hardness

Please note:

- Do not mix with other products.
- Operating instructions for Miele Professional washing machines must be observed.
- Before switching products, rinse the dispensing system, including suction hoses, with water.

ProCare Tex 10 B+

Detergency booster/Booster

Technical data:

- Density (20 °C): 1.00 g/ml
- pH value (1 % solution): 7.0–8.0

Ingredients:

Surfactants, solvents

Storage:

ProCare Tex 10 B+ should be stored in a dry and frost-free place. Always re-seal containers once the required amount of product has been removed.

Risks and safety notes:

For safety and environmental information, see the safety data sheets. These are available from the Miele websites listed below.

Dispose of containers only when completely empty and sealed. See safety data sheet regarding disposal of residuals.

All information contained in this leaflet is current and correct to our knowledge and experience. This does not however release users from the obligation of conducting their own checks and tests.

A legally binding assurance of specific product properties cannot be inferred from this.

Available packaging units and accessories:

Designation	Packaging unit
<i>ProCare Tex 10 B+</i>	5 l canister
<i>ProCare Tex 10 B+</i>	10 l canister
<i>ProCare Tex 10 B+</i>	20 l canister
<i>Canister key</i>	For all canisters
<i>DTD 2 drip tray</i>	5 and 10 l canisters
<i>Measuring beaker</i>	250 ml
<i>Drain valve</i>	5 and 10 l canisters

Contact information:

Germany

Miele Vertriebsgesellschaft Deutschland KG
Carl-Miele-Straße 29
33332 Gütersloh
Tel.: +49 (0) 8002244644
vertrieb@miele-professional.de
www.miele.de/professional

United Kingdom

Miele Co. Ltd.
Fairacres, Marcham Road
Abingdon, Oxon, OX14 1TW
Customer Contact Centre
Tel. +44 0330 160 6693
professional.sales@miele.co.uk
www.miele.co.uk/p/



Germany

BÜFA Cleaning GmbH & Co. KG
August-Hanken-Str. 30
26125 Oldenburg
www.buefa.com