

ProCare Tex 10 MA

Detergent for delicates and coloureds

Application:

ProCare Tex 10 MA is a high-performance, liquid, alkaline and phosphate-free concentrated detergent for delicates and coloureds for use in commercial washing machines.





ProCare Tex 10 MA is designed for the professional care of washable outerwear, sportswear and workwear (PPE and uniforms) as well as hotel and restaurant laundry.

Product properties:

- Free from fragrances
- Free from optical brightener, bleaching agents and phosphorous
- Regulates foaming
- Excellent removal of soil
- Can be used at all water hardness levels
- Effective at temperatures above 30 °C
- Meets environmental criteria for award of EU Eco Label
- The use of this product contributes to reducing water pollution, waste and energy consumption, providing dispensing recommendations are heeded.
- Alkaline-free



Dispensing recommendation [ml per kg of laundry]:

			
1°dH ≈ 0,18 mmol/l	ml/kg	ml/kg	ml/kg
°dH			
0 – 8,4	4	6	9
8,4 – 14	6	9	11
> 14	9	11	13

Water hardness ranges and figures can be provided by water authorities.

ProCare Tex 10 MA is designed to perform best in Miele Professional washing machines.

- Precise and economic dispensing via dispensing pump
- Dispensing recommendation depends on water hardness

Please note:

- Do not blend in concentrated form with other products.
- Before switching products, rinse the dispensing system, including suction hoses, with water.
- Operating instructions for Miele Professional washing machines must be observed.

ProCare Tex 10 MA

Detergent for delicates and coloureds

Technical data:

- Density (20 °C): approx. 1.03 g/ml
- pH value (1 % solution): approx. 9.5

Ingredients:

- Surfactants, complexing agents, water softeners, greying inhibitors, colour transfer inhibitors

Storage:

ProCare Tex 10 MA should be stored frost-free. Frozen detergent can however still be used once thawed without any drop in performance. Always re-seal containers once the required amount of product has been removed.

Risks and safety notes:

For safety and environmental information, see the safety data sheets. These are available from the Miele websites listed below.

Dispose of containers only when completely empty and sealed. See safety data sheet regarding disposal of residuals.

All information contained in this leaflet is current and correct to our knowledge and experience. This does not however release users from the obligation of conducting their own checks and tests.

A legally binding assurance of specific product properties cannot be inferred from this.

Available packaging units and accessories:

Designation	Packaging unit
<i>ProCare Tex 10 MA</i>	5 l canister
<i>ProCare Tex 10 MA</i>	10 l canister
<i>ProCare Tex 10 MA</i>	20 l canister
Canister key	For all canisters
DTD 2 drip tray	5 and 10 l canisters
Measuring beaker	250 ml
Drain valve	5 and 10 l canisters

Contact information:

Germany

Miele Vertriebsgesellschaft Deutschland KG
Carl-Miele-Straße 29
33332 Gütersloh
Tel.: +49 (0) 8002244644
vertrieb@miele-professional.de
www.miele.de/professional

United Kingdom

Miele Co. Ltd.
Fairacres, Marcham Road
Abingdon, Oxon, OX14 1TW
Customer Contact Centre
Tel. +44 0330 160 6693
professional.sales@miele.co.uk
www.miele.co.uk/p/



Germany

BÜFA Cleaning GmbH & Co. KG
August-Hanken-Str. 30
26125 Oldenburg
www.buefa.com