

Detergent for woollens

Application:

ProCare Tex 10 W is a slightly acidic, highly active detergent for the gentle washing of woollens in Miele Professional washing machines.





ProCare Tex 10 W is ideal for use in commercial laundry care.

Special-purpose ingredients guarantee reliable colour-fastness. This detergent is gentle on fibres thanks to protective polymers and an integrated buffer system which prevents felting.

Product properties:

- Particularly effective, even at low temperatures of 0–30 °C
- Can be used at all water hardness levels
- No dye transfer
- Prevents redeposition
- No felting of woollens

Dispensing recommendation [ml per kg of laundry]:

			
1°dH ≈ 0,18 mmol/l	ml/kg	ml/kg	ml/kg
°dH			
0 – 8,4	14	17	20
8,4 – 14	17	20	23
> 14	20	23	26

Water hardness ranges and figures can be provided by water authorities.

ProCare Tex 10 W is designed to perform best in Miele Professional washing machines.

- Precise and economic dispensing via dispensing pump
- Dispensing recommendation depends on water hardness

Please note:

- Do not mix with other products.
- Operating instructions for Miele Professional washing machines must be observed.
- Before switching products, rinse the dispensing system, including suction hoses, with water.

Technical data:

- Density: 1.02 g/cm³
- pH value (1 % solution): 4.8–5.8

Ingredients:

- Surfactants, solvents, water softeners, refatting agents, fragrance, colour transfer inhibitors, preservatives

Storage:

ProCare Tex 10 W should be stored in a dry and frost-free place. Always re-seal containers once the required amount of product has been removed.

ProCare Tex 10 W

Detergent for woollens

Risks and safety notes:

For safety and environmental information, see the safety data sheets. These are available from the Miele websites listed below.

Dispose of containers only when completely empty and sealed. See safety data sheet regarding disposal of residuals.

All information contained in this leaflet is current and correct to our knowledge and experience. This does not however release users from the obligation of conducting their own checks and tests.

A legally binding assurance of specific product properties cannot be inferred from this.

Available packaging units and accessories:

Designation	Packaging unit
<i>ProCare Tex 10 W</i>	20 l canister
<i>Canister key</i>	For all canisters
<i>DTD 2 drip tray</i>	5 and 10 l canisters
<i>Measuring beaker</i>	250 ml
<i>Drain valve</i>	5 and 10 l canisters

Contact information:

Germany

Miele Vertriebsgesellschaft Deutschland KG
Carl-Miele-Straße 29
33332 Gütersloh
Tel.: +49 (0) 8002244644
vertrieb@miele-professional.de
www.miele.de/professional

United Kingdom

Miele Co. Ltd.
Fairacres, Marcham Road
Abingdon, Oxon, OX14 1TW
Customer Contact Centre
Tel. +44 0330 160 6693
professional.sales@miele.co.uk
www.miele.co.uk/p/



Germany

BÜFA Cleaning GmbH & Co. KG
August-Hanken-Str. 30
26125 Oldenburg
www.buefa.com