

ProCare

Tex 10 MA

Detergent for delicates and coloureds





as well as hotel and restaurant laundry.

Product properties:

- Free from fragrances
- Free from optical brightener, bleach and phosphorous
- Regulates foaming
- Excellent removal of soil
- Can be used with all water hardness levels
- For washing at temperatures of 30°C and above
- Meets environmental criteria for award of EU Eco Label
- The use of this product contributes to reducing water pollution, waste and energy consumption, providing dispensing recommendations are heeded.



Dispensing recommendation [ml per kg of laundry]:

			
1°dH ≈ 0,16 mmol/l	ml/kg	ml/kg	ml/kg
°dH			
0 – 8,4	4	6	9
8,4 – 14	6	9	11
> 14	9	11	13

ProCare Tex 10 MA is designed to perform best in Miele Professional washing machines.

- Precise and economic dispensing via dispenser pump
- Dispensing recommendation depends on water hardness

Please note!

- Do not blend in concentrated form with other products.
- Before switching products, rinse the dispensing system, including suction hoses, with water.
- Operating instructions for Miele Professional washing machines must be observed.

ProCare

Tex 10 MA


Detergent for delicates and coloureds

Technical data:

- Density (at 20 °C): 1.03 g/ml
- pH value (1% solution): ca. 9,5

Storage:

ProCare Tex 10 MA should be stored frost-free. Frozen detergent can however still be used once thawed without any drop in performance. Always re-seal containers once the required amount of product has been removed.

In the original packaging, the product can be stored for at least 24 months. 

Warning and safety notes:

For safety and environmental information, see EU safety data sheets. These are available from the Miele websites listed below.

Dispose of containers only when completely empty and sealed. See safety data sheet regarding disposal of residual agent.

All information contained in this leaflet is current and correct to our knowledge and experience. This does not however release users from the obligation of conducting their own checks and tests.

A legally binding assurance of specific product properties cannot be inferred from this.

Available packaging units and accessories:

Designation	Packaging unit	Material number
<i>ProCare Tex 10 MA</i>	5 l canister	12442010
<i>ProCare Tex 10 MA</i>	10 l canister	12442020
<i>ProCare Tex 10 MA</i>	20 l canister	12442070
Canister key	For all canisters	11851600
DTD 2 drip tray	5 and 10 l canisters	10695460

Contact information:

Germany

Miele Vertriebsgesellschaft Deutschland KG
Carl-Miele-Straße 29,
33332 Gütersloh
Tel: +49 (0) 8002244644
vertrieb@miele-professional.de
www.miele.de/professional

United Kingdom

Miele Co. Ltd.
Fairacres, Marcham Road
Abingdon, Oxon, OX14 1TW
Customer Contact Centre
Tel: 0330 160 6600
professional@miele.co.uk



Germany

BÜFA Cleaning GmbH & Co. KG
August-Hanken-Str. 30
26125 Oldenburg
www.buefa.com