

ProCare

Tex 10 A

Sole detergent

Use:





ProCare Tex 10 A is a high-performance, liquid, alkaline sole detergent concentrate for use in commercial washing machines. *ProCare Tex 10 A* is ideal for use by commercial laundry and laundrettes. *ProCare Tex 10 A* is also intended for the professional care of washable outerwear, sportswear and laundry from hotels and restaurants.

Product properties:

- Good performance on grease and proteins
- Short exposure times
- High-level detergency combined with sparing use
- Highly effective even at low temperatures
- Phosphorous-free
- Also ideal in areas with hard water
- Meets environmental criteria for award of EU Eco Label
- The use of this product contributes to reducing water pollution, waste and energy consumption, providing dispensing recommendations are heeded.



Dispensing recommendation in ml per kg of laundry:

			
1°dH ≈ 0,16 mmol/l	ml/kg	ml/kg	ml/kg
°dH			
0 – 8,4	4	6	8
8,4 – 14	6	8	10
> 14	8	10	12

ProCare Tex 10 A is designed to perform best in Miele Professional washing machines.

- Precise and economic dispensing via dispenser pump

Please note!

- Before switching products, rinse the dispensing system, including suction hoses, with water.
- Operating instructions for Miele Professional washing machines must be observed.
- Due to natural substances used in the formulation, visible cloudiness towards the bottom of the container may occur. This cloudiness does not have any detrimental effect on wash performance.

ProCare

Tex 10 A


Sole detergent

Technical data:

- Density (20 °C): 1.17 g/cm³
- pH value (1 % solution): 12 – 13

Storage:

ProCare Tex 10 A should be stored in a dry place and frost-free. Always re-seal containers once the required amount of product has been removed.

In the original packaging, the product can be stored for at least 24 months. 

Warning and safety notes:

For safety and environmental information, see EU safety data sheets. These are available from the Miele websites listed below.

Dispose of containers only when completely empty and sealed. See safety data sheet regarding disposal of residual agent.

All information contained in this leaflet is current and correct to our knowledge and experience. This does not however release users from the obligation of conducting their own checks and tests.

A legally binding assurance of specific product properties cannot be inferred from this.

Available packaging units and accessories:

Designation	Packaging unit	Material number
<i>ProCare Tex 10 A</i>	5 l canister	12441960
<i>ProCare Tex 10 A</i>	10 l canister	12441970
<i>ProCare Tex 10 A</i>	20 l canister	12441980
<i>ProCare Tex 10 A</i>	200 l barrel	12306360
Canister key	For all canisters	11851600
DTD 2 drip tray	5 and 10 l canisters	10695460

Contact information:

Germany

Miele Vertriebsgesellschaft Deutschland KG
Carl-Miele-Straße 29,
33332 Gütersloh
Telefon +49 (0) 8002244644
vertrieb@miele-professional.de
www.miele.de/professional

United Kingdom

Miele Co. Ltd.
Fairacres, Marcham Road
Abingdon, Oxon, OX14 1TW
Customer Contact Centre
Tel: 0330 160 6600
professional@miele.co.uk



Germany

BÜFA Cleaning GmbH & Co. KG
August-Hanken-Str. 30
26125 Oldenburg
www.buefa.com