

Multi-purpose detergent

Application:

ProCare Tex 11 is a high-performance, phosphate-free, mildly alkaline multi-purpose powder detergent containing enzymes for use in commercial washing machines.




ProCare Tex 11 is ideal for use in commercial laundry care.

High concentrations of enzymes and oxygen bleach together with highly active tensides make this product fully effective at low temperatures.

Product properties:

- Effective at temperatures of 30–90 °C
- Particularly effective, even at low temperatures
- Very efficient thanks to special-purpose enzymes
- Brilliant whites thanks to selected optical brighteners
- Phosphorous-free
- Contains active oxygen
- Excellent at removing dirt and tackling grease
- Can be used at all water hardness levels

Dispensing recommendation [g (ml) per kg of laundry]:

						
1°dH ≈ 0,18 mmol/l	g/kg	ml/kg	g/kg	ml/kg	g/kg	ml/kg
°dH						
0 – 8,4	6	11	8	14	11	18
8,4 – 14	8	14	11	18	13	21
> 14	12	20	14	24	17	28

ProCare Tex 11 is designed to perform best in Miele Professional washing machines.

- Manual dispensing before each wash cycle
- Dispensing recommendation depends on water hardness

Please note:

- Do not mix with other products.
- Operating instructions for Miele Professional washing machines must be observed.
- Before switching products, rinse the dispensing system, including suction hoses, with water.

ProCare Tex 11

Multi-purpose detergent

Technical data:

- Bulk weight: 0.62 g/cm³
- pH value (1 % solution): 10.0–11.0

Ingredients:

- Surfactants, enzymes, water softeners, complexing agents, fragrance, bleaching agents, optical brightener

Ingredients according to EU Regulation 648/2004 on detergents:

- 5–<15 % zeolites
- Enzymes

Storage:

ProCare Tex 11 should be stored in a dry and frost-free place. Always re-seal containers once the required amount of product has been removed.

Risks and safety notes:

For safety and environmental information, see the safety data sheets. These are available from the Miele websites listed below.

Dispose of containers only when completely empty and sealed. See safety data sheet regarding disposal of residuals.

All information contained in this leaflet is current and correct to our knowledge and experience. This does not however release users from the obligation of conducting their own checks and tests.

A legally binding assurance of specific product properties cannot be inferred from this.

Available packaging units and accessories:

Designation	Packaging unit
<i>ProCare Tex 11</i>	10 kg sack
<i>ProCare Tex 11</i>	20 kg sack
<i>Measuring beaker</i>	250 ml

Contact information:

Germany

Miele Vertriebsgesellschaft Deutschland KG
Carl-Miele-Straße 29
33332 Gütersloh
Tel.: +49 (0) 8002244644
vertrieb@miele-professional.de
www.miele.de/professional

United Kingdom

Miele Co. Ltd.
Fairacres, Marcham Road
Abingdon, Oxon, OX14 1TW
Customer Contact Centre
Tel. +44 0330 160 6693
professional.sales@miele.co.uk
www.miele.co.uk/p/



Germany

BÜFA Cleaning GmbH & Co KG
August-Hanken-Str. 30
26125 Oldenburg
www.buefa.com