

ProCare Tex 10 A

Sole detergent

Application:





ProCare Tex 10 A is a high-performance, liquid, alkaline sole detergent concentrate for use in commercial washing machines. *ProCare Tex 10 A* is ideal for use in commercial laundry care. *ProCare Tex 10 A* is also intended for the professional care of washable outerwear, sportswear and laundry from hotels and restaurants.

Product properties:

- Good performance on grease and proteins
- Short activation time
- High-level detergency combined with sparing dispensing
- Highly effective even at low temperatures
- Phosphorous-free
- Can be used at all water hardness levels
- Meets environmental criteria for award of EU Eco Label
- The use of this product contributes to reducing water pollution, waste and energy consumption, providing dispensing recommendations are heeded.



Dispensing recommendation [ml per kg of laundry]:

			
1°dH ≈ 0,18 mmol/l	ml/kg	ml/kg	ml/kg
°dH			
0 – 8,4	4	6	8
8,4 – 14	6	8	10
> 14	8	10	12

Water hardness ranges and figures can be provided by water authorities.

ProCare Tex 10 A is designed to perform best in Miele Professional washing machines.

- Precise and economic dispensing via dispensing pump
- Dispensing recommendation depends on water hardness

Please note:

- Before switching products, rinse the dispensing system, including suction hoses, with water.
- Operating instructions for Miele Professional washing machines must be observed.
- Due to natural substances used in the formulation, visible cloudiness towards the bottom of the container may occur. This cloudiness does not have any detrimental effect on wash performance.

ProCare Tex 10 A

Sole detergent

Technical data:

- Density (20 °C): 1.17 g/cm³
- pH value (1 % solution): 12–13

Ingredients:

- Surfactants, complexing agents, water softeners, greying inhibitors, optical brighteners

Storage:

ProCare Tex 10 A should be stored in a dry and frost-free place.
Always re-seal containers once the required amount of product has been removed.

Risks and safety notes:

For safety and environmental information, see the safety data sheets. These are available from the Miele websites listed below.

Dispose of containers only when completely empty and sealed. See safety data sheet regarding disposal of residuals.

All information contained in this leaflet is current and correct to our knowledge and experience. This does not however release users from the obligation of conducting their own checks and tests.

A legally binding assurance of specific product properties cannot be inferred from this.

Available packaging units and accessories:

Designation	Packaging unit
<i>ProCare Tex 10 A</i>	5 l canister
<i>ProCare Tex 10 A</i>	10 l canister
<i>ProCare Tex 10 A</i>	20 l canister
<i>ProCare Tex 10 A</i>	200 l drum
Canister key	For all canisters
DTD 2 drip tray	5 and 10 l canisters
Measuring beaker	250 ml
Drain valve	5 and 10 l canisters

Contact information:

Germany

Miele Vertriebsgesellschaft Deutschland KG
Carl-Miele-Straße 29
33332 Gütersloh
Tel.: +49 (0) 8002244644
vertrieb@miele-professional.de
www.miele.de/professional

United Kingdom

Miele Co. Ltd.
Fairacres, Marcham Road
Abingdon, Oxon, OX14 1TW
Customer Contact Centre
Tel. +44 0330 160 6693
professional.sales@miele.co.uk
www.miele.co.uk/p/



Germany

BÜFA Cleaning GmbH & Co. KG
August-Hanken-Str. 30
26125 Oldenburg
www.buefa.com