

## Hygiene tips

on the use of barrier washing machines

- Make sure that soiled items are collected and delivered to the laundry in colour-coded laundry sacks, preferably sorted by type in self-opening laundry bags
- Load washing machines with the self-opening bags without first removing the bag contents. Self-opening bags unwrap automatically during the wash process if the drawstring has been released
- Select the correct wash cycle (thermal or chemo-thermal disinfection cycle) for hygienic reprocessing
- Make sure when manually dispensing detergent that the prescribed quantity is properly measured and that an appropriate temperature for the detergent is set
- Change your protective clothing before relocating to the unclean side of the operation or unloading machines
- Always wash workwear and protective clothing within the laundry in a hygiene programme and dispose of single-use items in the proper way

