

# Installation Plan Washing Machine



### **PWM 908 DP**

**Always** read the operating and installation instructions before setting up, installing, and commissioning the machine. This prevents both personal injury and damage to the machine.

#### Please have the model and serial number of your machine available when contacting Technical Service.

U.S.A. Miele, Inc.

#### **National Headquarters**

9 Independence Way Princeton, NJ 08540 Phone: 800-991-9380 www.mieleusa.com/professional prosales@mieleusa.com

#### Technical Service & Support Phone: 800-991-9380 proservice@mieleusa.com

Canada Importer Miele Limited

#### **Professional Division**

161 Four Valley Drive Vaughan, ON L4K 4V8 Phone: 1-888-325-3957 www.mieleprofessional.ca professional@miele.ca

#### Miele Professional Technical Service Phone: 1-888-325-3957 serviceprofessional@miele.ca



Miele & Cie. KG Carl-Miele-Straße 29, 33332 Gütersloh, Germany

### Legend:

$\bigcirc$	Connection required	$\bigcirc$	Connection optional or required, depending on model
DV	Drain valve	KW	Cold water connection
AW	Drain connection	DP	Drain pump
В	Machine anchoring	PA	Equipotential bonding and grounding
DOS	Dispenser connection	SLA	Peak-load connection
EL	Electrical connection	APCL SST	Closed plinth
F	Machine feet, adjustable	APCL OB	Open plinth
KG	Payment system	APCL 001	Washer-dryer stacking kit
KGA	Payment system connection	WW	Hot water connection
		XKM	Communication module

All rights reserved.

### Machine dimensions -measurements in inches-







### Installation -measurements in inches-





### Washer-dryer stack -measurements in inches-



### Installation -measurements in inches-









### Installation -measurements in inches-





### Machine dimensions -measurements in millimeters-







### Installation -measurements in millimeters-









## Washer-dryer stack -measurements in millimeters-



### Installation -measurements in millimeters-









### Installation -measurements in millimeters-

\* The distances between the machine and the wall are recommendations to help make it easier to carry out service work. If installation space is limited, the machine can also be pushed up against the wall.





> 1000\*

272

544

70.5

### Technical data

	PWM 908 DP	PWM 908 DP
Drum volume	19.3 gal	73 I
Capacity	19.8 lb	9.0 kg
Door opening diameter	11 13/16"	300 mm
Max. spin speed	1,600 rpm	1,600 rpm
g-factor	613	613
Residual moisture (standard load according to DIN 60456)	48 %	48 %
Electrical connection (EL)		
Standard voltage for CDN & USA	2 AC 208–240 V	2 AC 208–240 V
Frequency	60 Hz	60 Hz
Total rated load	4.0–5.2 kW	4.0–5.2 kW
Fuse rating	2 x 30 A	2 x 30 A
Power cord min. cross-section	3 x AWG10	3 x AWG10
Wire with plug NEMA L6–30	•	•
Wire length	78 3/4"	2.000 mm
		_,
Non-standard voltage MAR 208–240 (Marine)	2 AC 208–240 V	2 AC 208–240 V
Frequency	60 Hz	60 Hz
Total rated load	4.0–5.2 kW	4.0–5.2 kW
Fuse ration	2 x 30 A	2 x 30 A
Power cord min cross-section	3 x AWG10	3 x AWG10
Wire with plug NEMA I 6–30		
Wire longth	79.2///"	2,000 mm
whereight	76 3/4	2,000 mm
Cold water (KW)		
Dermissible water flow pressure	14 5-145 PSI	100_1 000 kPa
Populated flow rote (cold water connection only)	2.0 gol/min	11 //min
Derivined flow rate (with a different betweeter engranding)		11 ///////
Required now rate (with additional not water connection)	2.6 gai/min	10 //min
	10.5 gai/n	40 l/h
Connection to be provided on site, external thread according to DIN 44991 (flat seal)	*/4 <sup>*</sup>	
	• 	•
Connection hose length	61"	1,550 mm
Hot water (WW)		
Max water intake temperature	158 °F	70 °C
Parmissible water flow prossure	14.5.145.091	100 1 000 kPa
Pennissible water now pressure	2.9 gol/min	11 l/min
	2.9 gai/iiiii	12 l/b
Average water consumption (or C standard programme)	3.4 gai/n	13 1/11
	74	
	•	4.550
Connection hose length	61"	1,550 mm
	7/01	
Hose connection (external diameter)	7/8"	22 / DN22 mm
Max. drainage temperature	194 °F	90 °C
On-site hose sleeve (int. diameter x length)	22 x 30 mm	22 x 30 mm
Max. transient flow rate	6.8 gal/min	26 l/min
Max. delivery head (from lower edge of machine)	39 3/8"	1,000 mm
Drain hose DN 22 with connector (supplied as standard)	•	•
Connection hose length	59 1/16"	1,500 mm
Potential equalization (PA)		
Machine connection (separate kit required)	0	0
Features available via the XCI-Box accessory		
Peak load/energy management	0	0
Payment system connection	0	0
Liquid dispensing (DOS)	0	0
Possible no. of dispensing pumps	1–6	1–6
•		

 $\bullet$  = standard, O = optional, + = only on request, - not available

Technical data		
nstallation on machine feet (F)		
lo. of machine feet	4 No.	4 No.
Iachine foot, height-adjustable with thread	+5/16"	+8 mm
achine foot diameter	1.57"	40 mm
nchoring (B)		
andard floor anchoring		
oor anchor kit (for 2 machine feet) with anchors	•	•
ood screws according to DIN 571	6 x 50 mm	6 x 50 mm
wl plugs (diameter x length)	8 x 40 mm	8 x 40 mm
nchoring of Miele Plinths		
cessory: Miele Plinth installation (fasteners included)	0	0
equired anchor points	4 No.	4 No.
ood screws according to DIN 571	8 x 65 mm	8 x 65 mm
awl plugs (diameter x length)	12 x 60 mm	12 x 60 mm
inth floor anchoring (to be provided on site)		
achine installation on on-site plinth (concrete or masonry)	0	0
in. plinth installation footprint (W/D)	23 5/8" / 25 9/16"	600/650 mm
ood screws according to DIN 571	6 x 50 mm	6 x 50 mm
awl plugs (diameter x length)	8 x 40 mm	8 x 40 mm
lachine data		
verall machine dimensions (H/W/D)	33 15/32" / 23 13/16" / 28 7/64"	850/605/714 mm
asing dimensions (H/W/D)	33 15/32" / 23 7/16" / 26 11/16"	850/596/678 mm
ite-access dimensions (H/W)		
in. site-access opening (excl. packaging)	35 7/16" / 23 13/16"	900/605 mm
nstallation dimensions		
ide gap	13/16"	20 mm
ecommended side gap – washer-dryer stack	11 13/16"	300 mm
ecommended distance to opposite wall from front of machine	39 3/8"	1,000 mm
/eights and floor loads		
lachine weight (net weight)	227 lb	103 kg
lax. floor load in operation	2,820 N	2,820 N
ax. floor load, static	1,380 N	1,380 N
ax. floor load, dynamic	1,365 N	1,365 N
nissions		
ound pressure level (in accordance with EN ISO 11204/11203)	<70 dB(A)	<70 dB(A)
eat dissipation rate to installation site	250 W	250 W

## Installation and planning notes

#### Installation requirements

The machine should only be connected to a power supply provided in accordance with all appropriate local and national legislation and regulations.

In addition, all regulations issued by the appropriate utilities as well as standards relating to occupational safety and all applicable valid regulations and technical standards must be observed.

#### Transportation and site access

The washing machine must not be moved without the shipping struts in place. Keep the struts in a safe place. They must be refitted if the machine is to be moved again (e.g., when moving house).

#### General operating conditions

Ambient temperature in installation room: +36°F to +95°F (+2°C to +35°C).

Depending on the nature of the installation site, sound emissions and vibration may occur. Miele recommends having the installation site inspected and seeking the advice of a professional in instances where increased noise may cause a nuisance.

#### **Electrical connection**

Depending on the model, the machine will be delivered with a wire with/without a plug.

The machine may only be connected to an electrical system that conforms to national and local codes and regulations. This connection must be made by a qualified electrician.

The data tag indicates the nominal power consumption and the appropriate fuse rating. Compare the specifications on the data tag with those of the electrical power supply.

The machine can either be hard-wired or connected using a plug-andsocket connection in accordance with IEC 60309-1. Miele always recommends connecting the machine via a plug and socket so that electrical safety checks can be carried out easily (during repair or service work, for example).

If the machine is hard-wired, a dual circuit breaker must be provided on site. When switched off, there must be an all-pole contact gap of at least 3 mm in the isolator switch (including circuit breakers, breakers, and relays according to IEC/EN 60947).

The plug connector or isolator switch should be easily accessible at all times. If the machine is disconnected from the electricity supply, the isolator must be lockable or the point of disconnection must be monitored at all times.

New connections, modifications to the system, or servicing of the ground conductor, including determining the correct fuse rating, must be carried out by a qualified electrician, as they are familiar with the pertinent regulations and the specific requirements of the electric utility company.

If converting the machine to an alternative voltage, follow the instructions in the wiring diagram. Conversion must be performed by Miele Technical Service or by an authorized service technician. The heater rating must also be adapted.

References to cable cross-sections in the technical data refer only to the required power cord. Please consult relevant local and national regulations when calculating any other wire gauges.

#### Cold water connection

The washing machine should be connected to a domestic water supply in accordance with current local and national safety regulations.

Connection to the water supply should be carried out by a qualified plumber using a stopcock with a threaded union. If a stopcock is not available, the qualified plumber should connect the machine to the domestic water supply.

A suitable connection hose with a threaded union is supplied with the machine.

#### Hot water connection

The same connection requirements as for cold water also apply to hot water (max.  $158^{\circ}F/70^{\circ}C$ ).

A suitable connection hose with a threaded union is supplied with the machine.

The hot water connection appliance also requires a cold water connection.

In the event that hot water is not available on site, connection of the second hose must be made to a cold water supply.

Alternatively, the hot water connection should be blocked using the enclosed blind stopper and the machine controls set to cold water intake.

The required amount of hot water should be added to the cold water volume.

#### Drain valve (depending on model)

The machine is drained using a motorized drain valve. It can be connected directly to the on-site drainage system (without a siphon) or via a floor drain (gully with odor trap).

A vented drainage system is vital for unimpeded drainage. If on-site venting is insufficient, a vent kit (mat. no. 05 239 540) is available from your Miele dealer or Miele Technical Service.

If several machines are connected to a single drain pipe, this should be sufficiently large to allow all machines to drain simultaneously.

#### Drain pump (depending on model)

The suds are drained through a drain pump with a 1 m delivery head. For the water to drain freely, the hose must be installed free of kinks.

#### Drainage options:

- 1. Connected securely to a plastic drain pipe with a rubber nipple (there is no need to use a siphon).
- 2. Connected securely to a sink with a plastic nipple.
- 3. Connected securely to a floor drain.

#### Connecting the drain hose to a sink drain outlet

The drain hose can be connected securely to a suitable sink drain outlet.



If required, the hose can be extended to a length of up to 16.4 ft (5 m). Accessories are available from your Miele dealer or Miele Technical Service.

For a drain height of more than 3' 3 3/8" (1 m) up to a max. of 1.6 m), a replacement drain pump is available from Miele Technical Service or your Miele dealer.

#### Equipotential bonding and grounding

If necessary, an equipotential bond with good contact connection must be provided in accordance with all appropriate national and local regulations.

Material for equipotential bonding and grounding must be provided on site or using a kit available from Miele Technical Service.

#### Peak load/Energy management

The machine can be connected to a peak-load or energy management system using an optional kit.

When the peak-load function is activated, the heating is deactivated. A message appears in the display to inform you of this.

#### Liquid dispensing connection

External liquid dispenser pumps with a "container empty" indicator can be used to dispense liquid detergents.

The dispenser pumps can only be programmed with MDU.

It is particularly important to follow the manufacturer's instructions when using a combination of detergents, additives, and special-purpose products.

#### Payment system

This washing machine can be equipped with a single-machine payment system as an optional accessory using an optional kit (XCI-Box / XCI-AD).

The programming required for connecting a payment system can be carried out during the initial commissioning process. After initial commissioning, changes may only be carried out by your Miele dealer or Miele Technical Service.

#### Interface

The machine can be retrofitted with an XKM 3200 WL PLT communication module.

This module can be used as a WiFi or LAN interface.

The LAN interface provided via the module complies with SELV (Safety Extra Low Voltage) in accordance with EN 60950. Connected appliances must also comply with SELV. The LAN connection uses a RJ45 connector in accordance with EIA/TIA 568-B.

#### Installation

The machine must be installed on a perfectly smooth, level, and firm surface which is able to withstand the quoted loads.

The floor load created by the machine is concentrated and transferred to the installation footprint via the machine feet.

The machine should be leveled in both directions with the aid of the adjustable feet.

#### **Plinth installation**

The washing machine can be installed on a machine plinth (open or box plinth, available as an optional Miele accessory) or on a concrete plinth to be provided on site.

The quality of the concrete and its strength must be assessed according to the machine load. Ensure that any raised concrete plinth is adequately bonded to the floor below.

If the washing machine is installed on a concrete or masonry plinth, it must be secured using the anchors supplied with the machine. Otherwise, there is a risk of the washing machine moving about during spinning and falling off the plinth.



The anchors provided can be used to bolt the machine to the floor by both front feet. The fasteners provided are intended for use in bolting the machine to a concrete floor.

#### Washer-dryer stack

The washing machine can be installed as a washer-dryer stack together with a Miele Tumble Dryer. A stacking kit (optional accessory) is required for this.

Installation of the stacking kit must be performed by Miele Technical Service or an authorized Miele service technician.