

## PT 8303 SL

34 lbs. / 15 kg



Electric Heating



### FEATURES

- SlimLine Design – fits in the smallest spaces
- Large capacity
- Patented Honeycomb drum
- Intelligent dryer – gentle and uniform drying
- PerfectDry system – residual moisture sensors
- Short program cycles
- Low consumption values



#### SlimLine Design

The slim design of only 711 mm width allows placement in the smallest space.



#### SoftLift drum ribs ensure gentle fabric care

The SoftLift drum ribs allow laundry to be dried gently and evenly.



#### PerfectDry System

The PerfectDry system consistently measures the residual moisture of the laundry, thereby achieving precise drying results - even when the water quality differs widely.



#### Perfect Anti-Crease

The laundry is tumbled regularly after the end of the program to protect it from creasing.

Mat. No.	Model	Heat Type	Electrical	Finish
11772780	PT 8303	Electric dryer	3 AC 220-240 V, 60 Hz, 40 A	Iron-Grey

# PT 8303 SL

34 lbs. / 15 kg

Model	PT 8303 SL
Heated Option (EL)	Electric
Finish	Iron-Grey
Load Size	34 lbs. (15 kg)
Drum Capacity	10.59 cu.ft. / 300 liter
Width	28 in. (711 mm)
Depth	42 <sup>7</sup> / <sub>8</sub> in. (1,089 mm)
Height	70 <sup>7</sup> / <sub>8</sub> in. (1,800 mm)
Height to the bottom of the door	29 <sup>3</sup> / <sub>4</sub> in. (755 mm)
Door opening diameter	20 <sup>1</sup> / <sub>2</sub> in. (520 mm)
Door hinging	Left
Net Weight	307 lbs. (139 kg)
Shipping Width	31 <sup>1</sup> / <sub>2</sub> in. (800 mm)
Shipping Depth	46 <sup>7</sup> / <sub>16</sub> in. (1,180 mm)
Shipping Height	71 <sup>1</sup> / <sub>4</sub> in. (1,810 mm)
Shipping Weight	351 lbs. (159 kg)
Standard electrical connection	3 AC 220-240 V, 60 Hz
Possible voltage variant 1	3 AC 208 V, 60 Hz
Possible voltage variant 2	2 AC 208 V, 60 Hz
Heating Power	15.4 kW
Fuse	3 x 40 A