

Miele

ProCare

Tex 11 COL

Detergent for coloured items





Use

ProCare Tex 11 COL is a highly concentrated alkaline and phosphate-free detergent in powder form which contains enzymes for washing coloured items made from cotton or mixed fibres and is designed for use in commercial washing machines. *ProCare Tex 11 COL* is formulated for the professional care of washable outerwear, sportswear and workwear as well as hotel and restaurant laundry.

Product properties

- Free from optical brighteners, bleaching agents and phosphates
- Excellent in removing soil and tackling grease
- Can be used at all water hardness levels
- For washing at temperatures of 30°C and above
- Very efficient thanks to special-purpose enzymes
- Excellent colour care
- Very good protection against dye transfer

Dispensing recommendation [ml per kg of laundry]:

						
1°dH ≈ 0,18 mmol/l	g/kg	ml/kg	g/kg	ml/kg	g/kg	ml/kg
°dH						
0 – 8,4	10	13	12	15	16	20
8,4 – 14	13	16	13	17	17	21
> 14	14	18	14	18	18	23

*Water hardness ranges and figures can be provided by water supply companies.

ProCare Tex 11 COL is designed to perform best in Miele Professional washing machines.

- Manual dispensing before each wash cycle.
- Dispensing recommendation depends on water hardness.

Please note!

- Do not mix with other products.
- Operating instructions for Miele Professional washing machines must be observed.

Miele

ProCare

Tex 11 COL

Detergent for coloured items

Technical data

- Bulk weight: ca. 0,8 g/cm³
- pH value (1 % solution): ca. 11

Ingredients

Surfactants, enzyme, water softener, complexing agent, fragrance.

Storage

ProCare Tex 11 COL should be stored in a dry and frost-free place. Always re-seal containers once the required amount of product has been removed.

Warning and safety notes

For safety and environmental information, see EU safety data sheets. These are available from the Miele websites listed below. Dispose of containers only when completely empty and sealed. See safety data sheet regarding disposal of residual agent. All information contained in this leaflet is current and correct to our knowledge and experience. This does not however release users from the obligation of conducting their own checks and tests. A legally binding assurance of specific product properties cannot be inferred from this.

Designation	Packaging unit
<i>ProCare Tex 11 COL</i>	5 kg bucket
<i>ProCare Tex 11 COL</i>	20 kg sack

Contact information

Germany

Miele Vertriebsgesellschaft Deutschland KG
Carl-Miele-Straße 29
33332 Gütersloh
Tel. +49 8002244644
vertrieb@miele-professional.de
www.miele.de/professional

United Kingdom

Miele Italia G.m.b.H.
Umfahrungsstr. 27
39057 Eppan (BZ)
Tel. +39 0471 666319
professional@miele.it
www.miele.it/it/professional

Producer

Chemische Fabrik Kreussler & Co. GmbH
Rheingastr. 87-93
65203 Wiesbaden
Tel. +49 611 9271-0
info@kreussler.com
www.kreussler.com

Kommentiert [KP1]: Gewünschte Adresse?