



Electric Heating



**7** Years  
Warranty



## PRI 210 | 39 in. wide roller

### Features

- Flexibly positioned heater plate for perfect rotary ironing performance
- State-of-the-art controls: Touch display
- Durable long-lasting roller cover
- Convenient return feed
- Variable roller speed
- Finger guard for ultimate safety
- 20,000 hours of operation



### Perfect Laundry Finish

Uniform pressure over the entire working width guarantees a perfect laundry finish.



### FlexControl Foot Switch

Feed in items flawlessly by activating the FlexControl foot pedal switch that can be positioned where needed.



### Easy and Convenient Operation

A large touch display is used to easily and precisely select settings such as temperature and rotational speed.



### Easy Cleaning and Care of the Heater Plate

To maintain a consistent finish quality, cleaning and waxing programs are available for easy cleaning and care of the heater plate.

Mat. No.	Model	Heat Type	Electrical	Finish
11741330	PRI 210	Electric	240 V/ 50-60Hz/ 1 Ph, 2 x 20 A	Iron-Grey

Model	PRI 210
Heated Type (EL)	Electric
Roller diameter	8 <sup>3</sup> / <sub>8</sub> in. (210 mm)
Working width	39 in. (1000 mm)
Heater plate material	Aluminum
Throughput at 15% residual moisture (kg/h)	35
Throughput at 25% residual moisture (kg/h)	26
Width	62 <sup>3</sup> / <sub>16</sub> in. (1,579 mm)
Depth	18 <sup>3</sup> / <sub>4</sub> in. (476 mm)
Height	40 <sup>5</sup> / <sub>8</sub> in. (1,032 mm)
Weight	269 lbs. (122 kg)
Shipping Width	69 <sup>7</sup> / <sub>16</sub> in. (1,763 mm)
Shipping Depth	26 in. (660 mm)
Shipping Height	54 <sup>1</sup> / <sub>16</sub> in. (1,374 mm)
Shipping Weight	300 lbs. (136 kg)
Minimum ironer speed, can be set in ft/min	1.5
Maximum ironer speed, can be set in ft/min	4.0
Standard electrical connection	240 V, 50-60 Hz, 1 Ph
Possible voltage variant 1	220 V, 50-60 Hz, 1 Ph
Possible voltage variant 2	208 V, 50-60 Hz, 1 Ph
Heating Power	2.90 kW
Fuse	2 x 20 A



## Miele APRI 319 Trough Cleaning Set

APRI 319 Ironer cleaner starter package with cleaning cloth, waxing cloth and wax.

Article number 59530319EU / Material number 11923830