

PRI 210

39 in. wide roller



Electric Heating



FEATURES

- Flexibly positioned heater plate for perfect rotary ironing performance
- State-of-the-art controls: Touch display
- Durable long-lasting roller cover
- Flexibly positioned heater plate for perfect rotary ironing performance
- Convenient return feed
- Variable roller speed
- Finger guard for ultimate safety
- 20,000 hours of operation



Perfect Laundry Finish

Uniform pressure over the entire working width guarantees a perfect laundry finish.



Exclusive to Miele

FlexControl Foot Switch

Feed in items flawlessly by activating the FlexControl foot pedal switch that can be positioned where needed.



Exclusive to Miele

Easy and Convenient Operation

A large touch display is used to easily and precisely select settings such as temperature and rotational speed.



Easy Cleaning and Care of the Heater Plate

To maintain a consistent finish quality, cleaning and waxing programs are available for easy cleaning and care of the heater plate.

Mat. No.	Model	Heat Type	Electrical	Finish
11741330	PRI 210	Electric	240 V/ 50-60Hz/ 1 Ph, 2 x 20 A	Iron-Grey

PRI 210

39 in. wide roller

Model	PRI 210
Heated Type (EL)	Electric
Roller diameter	8 ^{3/8} in. (210 mm)
Working width	39 in. (1000 mm)
Heater plate material	Aluminum
Throughput at 15% residual moisture (kg/h)	35
Throughput at 25% residual moisture (kg/h)	26
Width	62 ^{3/16} in. (1,579 mm)
Depth	18 ^{3/4} in. (476 mm)
Height	40 ^{5/8} in. (1,032 mm)
Weight	269 lbs. (122 kg)
Shipping Width	69 ^{7/16} in. (1,763 mm)
Shipping Depth	26 in. (660 mm)
Shipping Height	54 ^{1/16} in. (1,374 mm)
Shipping Weight	300 lbs. (136 kg)
Minimum ironer speed, can be set in ft/min	1.5
Maximum ironer speed, can be set in ft/min	4.0
Standard electrical connection	240 V, 50-60 Hz, 1 Ph
Possible voltage variant 1	220 V, 50-60 Hz, 1 Ph
Possible voltage variant 2	208 V, 50-60 Hz, 1 Ph
Heating Power	2.90 kW
Fuse	2 x 20 A



Miele APRI 319 Trough Cleaning Set

APRI 319 Ironer cleaner starter package with cleaning cloth, waxing cloth and wax.

Article number 59530319EU / Material number 11923830