



Programme overview Commercial washing machine PWM 909

Always read the operating instructions before setting up, installing and commissioning the machine. This prevents both personal injury and damage to the machine.

en-GB

Contents

Programme summary	3
Selectable extras	3
Selectable extras for liquid dispensing.....	3
Basic programmes	4
Whites programmes.....	4
Delicates/Shirts/Woollens programmes	6
Separate rinse programme.....	7
Spin.....	7
Drain	7
Starch programme.....	7
Clean machine	8
Programme chart - Hotel/Restaurant/Catering.....	9
Bed linen/towelling programme	9
Mattress protectors programme	9
Spa towelling programme	10
Bathrobes programme	10
Kitchen linen	11
Table linen programme.....	11
Bedding/Curtains.....	12
Curtains.....	12
Bedding	13
Bedding load sizes.....	13
Disinfection - general information.....	14
What is disinfection?	14
Thermal disinfection.....	14
Chemo-thermal disinfection	14
RKI list (Robert Koch Institute)	14
Disinfection process according to areas of impact	14
VAH list	15
Avoidance of contamination or recontamination	15
Cleaning dispensing drawers and siphons.....	15
Water connection for variants with reduced heater rating (RH).....	15
Water connection for variants with external heating (EH).....	15
Disinfection	16
Buildings maintenance	19
Mop	20
Mats/Pads programmes.....	25
Cloths programmes.....	26
Fire brigade programme overview	30
Protective clothing programmes	30
Masks programmes.....	32
Rescue clothing programmes	33
WetCare.....	37
Outerwear programme overview	38
Equestrian.....	39
Sport.....	41
Workwear	42
Sluice programme overview (Healthcare HTM 01-04)	43
Programme sequence Sluice	44
Programme overview: ECO programmes	45

Selectable extras

Extra	Symbol	Description
Pre-rinse		Pre-rinse before the wash processes start
Pre-wash		Pre-wash before starting the main wash
Soak		Block to start main wash, 30 °C, little movement
Water plus		Increase amount of water in main wash
Intensive		Extension of the main wash after the temperature stop
Rinse plus		Additional rinse block
Fill stop		Stop at the start of the last rinse, before water is supplied
Rinse hold		Hold at the end of the last rinse, before water is drained

Selectable extras for liquid dispensing

Selecting these extras may deselect the relevant detergent component for the next wash cycle.

Extra	Symbol	Description
Detergent		Detergent component is deselected
Additives		No dispensing of the additive component (e.g. stain booster)
Care product		No dispensing of the care product component (e.g. fabric conditioner, proofing agent)

Programme summary

Basic programmes

The **wash time** is the minimum main wash time after the set temperature is reached. The times for water intake, dispensing, heating, intermediate spinning, etc. are not included.

Whites programmes

Whites		90 °C (70 °C to 90 °C)	Load ratio/Load size
Fabric	Cotton, linen and mixed fibre fabrics, e.g. bed linen and towelling		1:9 PWM 909 – 9 kg
Programme sequence	Main wash up to 90 °C, wash time 11 min Cool down can be activated in the Miele Benchmark Programming Tool 2 rinse cycles Last rinse cycle hot* Final spin		
Extras	Pre-wash, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		

* The standard programmes **Whites** and **Coloured items** are programmed with hot water rinse cycles. If hot water is available, we recommend using hot water for the final rinse:

- There is less residual moisture in the laundry after spinning.
- The laundry is already warmed.
- This saves time and energy if the laundry is immediately either dried in a tumble dryer or ironed with an ironer.

Coloured items programmes

Coloured items		60 °C (Cold to 60 °C)	Load ratio/load size
Fabric	Normally soiled cotton, linen and mixed fibre fabrics, e.g. bed linen and towelling		1:9 PWM 909 – 9 kg
Programme sequence	Main wash up to 60 °C, wash time 11 min 2 rinse cycles Last rinse cycle hot* Final spin		
Extras	Pre-wash, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		
Colours intensive		60 °C (Cold to 60 °C)	
Fabric	Heavily soiled cotton, linen or mixed fibre fabrics, e.g. bed linen and towelling, workwear		
Programme sequence	Main wash up to 60 °C, wash time 8 min 2 rinse cycles Last rinse cycle hot* Final spin		
Extras	Pre-wash, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		
Colours Eco short		50 °C (Cold to 60 °C)	Load ratio/load size
Fabric	Lightly soiled cotton, linen and mixed fibre fabrics, e.g. bed linen and towelling		1:9 PWM 909 – 9 kg
Programme sequence	Main wash up to 60 °C, wash time 5 min 2 rinse cycles Final spin		
Extras	Pre-wash, Water plus, Rinse plus, Fill stop, Rinse hold		

* The standard programmes **Whites** and **Coloured items** are programmed with hot water rinse cycles. If hot water is available, we recommend using hot water for the final rinse cycle:

- There is less residual moisture in the laundry after spinning.
- The laundry is already warmed.
- This saves time and energy if the laundry is immediately either dried in a tumble dryer or ironed with an ironer.

Minimum iron programmes

Minimum iron		40 °C (Cold to 60 °C)	Load ratio/Load size
Fabric	Normally soiled synthetic and mixed fibre fabrics		1:20 PWM 909 – 4 kg
Programme sequence	Main wash up to 60 °C, wash time 7 min 2 rinse cycles Final spin		
Extras	Pre-wash, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		

Programme summary

Delicates/Shirts/Woollens programmes

Delicates		30 °C (Cold to 60 °C)	Load ratio/Load size
Fabric	Synthetic and artificial fibre fabrics		1:25 PWM 909 – 3.2 kg
Programme sequence	Main wash up to 60 °C, wash time 12 min Wash rhythm “gentle” 2 rinse cycles Final spin		
Extras	Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		
Shirts		40 °C (Cold to 60 °C)	
Fabric	Shirts and blouses made of cotton and mixed fibre		
Programme sequence	Main wash up to 60 °C, wash time 7 min 2 rinse cycles Final spin		
Extras	Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		
Woollens		30 °C (Cold to 40 °C)	
Fabric	Machine washable woollens and wool mixtures with a woollens care label		
Programme sequence	Main wash up to 40 °C, wash time 6 min Wash rhythm “very gentle” 2 rinse cycles Final spin		
Extras	Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		
Handwash. woollens		30 °C (Cold to 40 °C)	
Fabric	Washable woollens and wool mixtures with a wool-lens care label		
Programme sequence	Main wash up to 40 °C, wash time 6 min Wash rhythm “extra gentle” 2 rinse cycles Final spin		
Extras	Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		

Separate rinse programme

Separate rinse		Load ratio/Load size
Fabric	Items which only need to be rinsed and spun	1:9 PWM 909 – 9 kg
Programme sequence	1 rinse cycle Final spin	
Extras	Fill stop, Rinse hold	

Spin

Spin		Load ratio/Load size
Fabric	Items which have been washed and only need to be spun in the machine	1:9 PWM 909 – 9 kg
Programme sequence	Final spin	

Drain

Drain		
Programme sequence	Drainage	

Starch programme

Starch		30 °C (Cold to 40 °C)	Load ratio/Load size
Fabric	For starching freshly laundered items such as table cloths, serviettes and workwear		1:10 PWM 909 – 8 kg
Programme sequence	1 rinse cycle* Final spin		
Extras	Rinse hold		

* Starch concentrates can be added to the front right and/or back right dispenser drawer compartment  before the programme starts. Large quantities of starch solution can be added manually with the water using the dispenser compartments  or .

Programme summary

Clean machine

Clean machine 70 °C (70 °C to 90 °C)		
Fabric	No load	
Programme sequence	+  Intensive button: additional main wash up to 90 °C, wash time 6 min 2 rinse cycles Drainage	
Extras	Soak, Water plus, Intensive, Rinse plus, Fill stop	

Programme chart - Hotel/Restaurant/Catering

A multitude of textiles with widely varying degrees of soiling fall into this area. These programmes are suitable for washing lightly soiled bedding and towels, through heavily soiled table linen to very heavily soiled kitchen linen.

Bed linen/towelling programme

Bed linen/towelling		60 °C (Cold to 90 °C)	Load ratio/Load size
Fabric	Linen and mixed fibre coloured and white bed linen and towelling		1:10* PWM 909 – 8 kg
Programme sequence	Main wash up to 90 °C, wash time 10 min Cool down can be activated in the Miele Benchmark Programming Tool 2 rinse cycles Final spin		
Extras	Pre-wash, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		

* Wash with maximum load.

Mattress protectors programme

Mattress protectors		60 °C (Cold to 90 °C)	Load ratio/Load size
Fabric	Synthetic waterproof mattress protectors		1:13 PWM 909 – 6.2 kg
Programme sequence	Main wash up to 90 °C, wash time 6 min 2 rinse cycles Final spin		
Extras	Pre-wash, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		

Programme summary

Spa towelling programme

Spa towelling		50 °C (Cold to 90 °C)	Load ratio/Load size
Fabric	Coloured and white cotton, linen and mixed fibre fabrics, e.g. bed linen and towelling, with heavy oil and grease stains		1:13* PWM 909 – 6.2 kg
Programme sequence	Main wash up to 90 °C, wash time 6 min Extra main wash 75 °C** 2 rinse cycles Final spin		
Extras	Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		

* Wash with maximum load.

** In case of heavy soiling, e.g. by creams, massage oils, a second main wash at 75 °C can be added via the “Intensive” extra. In the case of coloured stains, additional bleach can be dispensed.

Bathrobes programme

Bathrobes		60 °C (Cold to 90 °C)	Load ratio/Load size
Fabric	Cotton and mixed fibre bathrobes (select Pre-wash 40 °C for heavily soiled items)		1:13* PWM 909 – 6.2 kg
Programme sequence	Main wash up to 90 °C, wash time 6 min 2 rinse cycles Final spin		
Extras	Pre-wash, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		

* Wash with maximum load.

Kitchen linen

Kitchen linen		90 °C (Cold to 90 °C)	Load ratio/Load size
Fabric	Cotton, linen and mixed fibre kitchen linen		1:13 PWM 909 – 6.2 kg
Programme sequence	Pre-rinse Main wash up to 90 °C, wash time 10 min Cool down can be activated in the Miele Benchmark Programming Tool 3 rinse cycles Final spin		
Extras	Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		

Table linen programme

Table linen		60 °C (Cold to 90 °C)	Load ratio/Load size
Fabric	White and coloured cotton, linen and mixed fibre table linen		1:10 PM 909 – 8 kg
Programme sequence	Main wash up to 90 °C, wash time 10 min Cool down can be activated in the Miele Benchmark Programming Tool 2 rinse cycles Final spin		
Extras	Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		

Programme summary

Bedding/Curtains

Curtains

Curtains		40 °C (Cold to 60 °C)	Load ratio/Load size
Fabric	Synthetic and artificial fibre fabrics		1:25 PWM 909 – 3.2 kg
Programme sequence	Main wash up to 60 °C, wash time 14 min 3 rinse cycles Final spin		
Extras	Pre-rinse, Pre-wash, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		
Lightweight curtains		40 °C (Cold to 60 °C)	
Fabric	Synthetic and artificial fibre fabrics		
Programme sequence	Pre-rinse Main wash up to 60 °C, wash time 6 min 3 rinse cycles Final spin		
Extras	Pre-rinse, Pre-wash, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		

Programme sequence without spin:

- Press the  “Rinse hold” button.

Bedding

These programmes are suitable for washing down, natural fibre and synthetic filling quilts, unquilted and quilted duvets.

These wash programmes are only suitable for washing items with a care label stating that they are suitable for machine washing.

Down duvets		40 °C (Cold to 60 °C)	Load ratio/Load size
Fabric	Normally to heavily soiled down and feather-filled duvets and pillows		See “Bedding load sizes”
Programme sequence	De-aerating Main wash up to 60 °C, wash time 8 min 2 rinse cycles Final spin		
Extras	Pre-wash, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		
Synthetic duvets		40 °C (Cold to 90 °C)	
Fabric	Normally to heavily soiled synthetic duvets and pillows		
Programme sequence	Main wash up to 90 °C, wash time 8 min 2 rinse cycles Final spin		
Extras	Pre-wash, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		
Natural hair bedding		25 °C (Cold to 40 °C)	
Fabric	Machine-washable natural fibre quilts and blankets		
Programme sequence	Main wash up to 40 °C, wash time 6 min, wash rhythm “extra gentle” 2 rinse cycles Final spin		
Extras	Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		

Bedding load sizes

The maximum load sizes are set out in the chart below. The loads given are approximate only and vary depending on the size and thickness of the bedding.

Model	Quantity*
PWM 909	1–2 pillows

Programme summary

Disinfection - general information

What is disinfection?

Deactivation and reduction in number of pathogens transmitting diseases to such an extent that the transmission of diseases and infection is no longer to be anticipated.

Thermal disinfection

Thermal disinfection is carried out by the action of a defined temperature over a holding time. In the list, according to § 18 of the German infection control legislation, this is 90 °C over 10 min or 85 °C over 15 min. With a load-to-liquor ratio of 1–4 to 1–5 with the activity range AB (see “Disinfection process according to areas of impact”).

The thermal disinfection is independent of the detergent used, which does not have to be classified.

Chemo-thermal disinfection

Chemo-thermal disinfection differs from thermal disinfection by a lower liquor temperature during the disinfection phase. A compensation for the low temperature is ensured by the correspondingly listed washing and disinfecting components.

It is important that these products are used exactly according to the listings. The liquor temperature, the load-to-liquor ratio and the time of dispensing must be strictly adhered to. For disinfection wash programmes there are two lists in which the necessary process parameters with regard to cleaning agents and disinfectants are listed.

RKI list (Robert Koch Institute)

Describes procedures for disinfection according to § 18 German infection control legislation. These processes are only required when a health authority prescribes the use of disinfection in the event of the outbreak of an epidemic relating to a notifiable, transferable disease where there is a risk of items being contaminated. The RKI lists thermal disinfection processes as well as chemo-thermal methods.

Disinfection process according to areas of impact

Disinfection procedure is divided into areas of impact A, B and C.

- Area of impact A:
Suitable for the destruction of vegetative germs, including mycobacteria, mould fungi and fungal spores.
- Area of impact B:
Suitable for deactivating viruses.
- Area of impact C:
To deactivate anthrax spores.

VAH list

VAH = Association for Applied Hygiene
(previously DGHM = German Society for Hygiene and Microbiology)

The VAH/DGHM list describes the procedures required for routine prophylactic disinfection, and in particular for the prevention of infection in hospitals, doctors' offices, public areas and other areas where there may be the risk of infection spreading.

With respect to an officially directed disinfection, § 18 of the Infection Protection Act is invoked.

Special validated procedures and machines are to be used for surgical textiles as medical devices. The procedures and machines listed here are **not** medical devices.

Avoidance of contamination or recontamination

- Disinfect your hands before using the machine.
- Use clean/disinfected transport containers.
- Dispense cleaning agents and disinfectants in accordance with instructions.
- Observe regulations regarding the wearing of protective clothing.
- Ensure that water is bacteria-free when using water from water treatment units.
- Clean detergent drawers, detergent compartments and siphons before use.

Cleaning dispensing drawers and siphons

The detergent drawer is subject to constant moisture. It needs to be cleaned regularly to prevent the build-up of water-borne bacteria.

- Clean the detergent drawer, detergent compartments and siphon thoroughly with hot water as required to remove detergent residues and encrustation.

It is the supervisor's responsibility to ensure that the standard of disinfection in thermal as well as chemo thermal procedures is maintained (from the list, in accordance with § 18 German infection control legislation) by carrying out suitable validation tests. The procedures should be checked at regular intervals, thermoelectrically by means of loggers or bacteriologically using bio-indicators. The supervisor must pay particular attention to observing the process parameters temperature and, in the case of chemo-thermal programmes, the concentration. Disinfection programmes must not be interrupted, as this can have a limiting effect on the disinfection result.

Water connection for variants with reduced heater rating (RH)

The appliance should be connected to cold and hot water supplies. A minimum hot water temperature of 80 °C is recommended in order to use all programmes. Lower temperatures may result in longer programme running times or cause programmes to be interrupted. Water inlet temperatures below 60 °C are not permitted, as they can lead to significantly longer programme running times.

Water connection for variants with external heating (EH)

The appliance should be connected to cold and hot water supplies. A minimum hot water temperature of 80 °C is recommended. The use of disinfection programmes is not possible due to the absence of additional heating. The permissible wash temperatures are determined by the inlet temperature.

Programme summary

Disinfection

Thermal disinfection and **chemo-thermal disinfection** are programmes for disinfecting textiles.

Thermal or chemo-thermal disinfection is carried out. Suitable detergents are to be used for the chemo-thermal disinfection.

All programmes are **locked**. This means that after 1 minute into a programme, they can only be cancelled, stopped or have parts skipped by entering the “Expert code” (see operator level).

To avoid recontamination, the water inlet for the rinse cycles in the disinfection programmes is not supplied via the detergent drawer.

To disinfect contaminated mains water, a **disinfection rinse** can be activated instead of the last rinse cycle. In this rinse, the rinse water is heated to 65 °C to deactivate water-borne bacteria. The programme running time is extended and the door can only be opened once the temperature in the machine has fallen below 50 °C.

If “Pre-wash” is selected, place the detergent directly in the drum. If necessary, the  and  compartments can be used to add detergent in the main wash cycle.

Thermal disinfection		90 °C	Load ratio/load size
Fabric	Cotton, linen e.g. bed linen, towelling		1:9 PWM 909 – 9 kg
Programme sequence	Disinfection 90 °C, holding time 10 min Cool down and/or disinfection rinse can be activated in the Miele Benchmark Programming Tool 2 rinse cycles Final spin		
Extras	Pre-wash, Soak, Intensive, Rinse plus, Fill stop, Rinse hold		
Ch.-thermal disin. 10 min		70 °C	1:10 PWM 909 – 8 kg
Fabric	Cotton, linen e.g. bed linen, towelling		
Programme sequence	Disinfection 70 °C*, holding time 10 min 2 rinse cycles (optional disinfection rinse can be activated) Final spin		
Extras	Pre-wash, Soak, Intensive, Rinse plus, Fill stop, Rinse hold		
Ch.-thermal disin. 20 min		60 °C	
Fabric	Cotton, linen e.g. bed linen, towelling		
Programme sequence	Disinfection 60 °C*, holding time 20 min 2 rinse cycles (optional disinfection rinse can be activated) Final spin		
Extras	Pre-wash, Soak, Intensive, Rinse plus, Fill stop, Rinse hold		

* The disinfection parameters for chemo-thermal disinfection (temperature, temperature holding time and dispensing quantities) must be set on site to suit detergents and disinfectants.

Programme summary

If “Pre-wash” is selected, place the detergent directly in the drum. If necessary, the  and  compartments can be used to add detergent in the main wash cycle.

Programme summary

Ch-th. disin. gentle 20 min		40 °C	Load ratio/load size
Fabric	Cotton, mixed fibre, curtains		1:25 PWM 909 – 3.2 kg
Programme sequence	Disinfection 40 °C*, holding time 20 min Wash rhythm “gentle” 2 rinse cycles (optional disinfection rinse can be activated) Final spin		
Extras	Pre-wash, Soak, Intensive, Rinse plus, Fill stop, Rinse hold		
Incontinence		90 °C	
Fabric	Washable incontinence nappy systems		1:13 PWM 909 – 6.2 kg
Programme sequence	Pre-rinse bath Pre-wash up to 40 °C Disinfection 90 °C, holding time 10 min Cool down and/or disinfection rinse can be activated in the Miele Benchmark Programming Tool 3 rinse cycles Final spin		
Extras	Pre-rinse, Soak, Intensive, Rinse plus, Fill stop, Rinse hold		
Incontinence laundry		90 °C	
Fabric	Heavily soiled personal clothing, cotton		
Programme sequence	2 pre-rinse baths Pre-wash up to 40 °C Disinfection 90 °C, holding time 10 min 3 rinse cycles (optional disinfection rinse can be activated) Final spin		
Extras	Soak, Intensive, Rinse plus, Fill stop, Rinse hold		

* The disinfection parameters for chemo-thermal disinfection (temperature, temperature holding time and dispensing quantities) must be set on site to suit detergents and disinfectants.

If “Pre-wash” is selected, place the detergent directly in the drum. If necessary, the  and  compartments can be used to add detergent in the main wash cycle.

Buildings maintenance

These programmes are suitable for washing, disinfecting and finishing (at different humidity levels) cotton or mixed fibre mops, floor mats, polishing pads and cleaning cloths used in facility management.

Cleaning textiles can even come out of the machine finished and ready for use (ready to use – rtu).

To avoid recontamination, the water for the rinse cycles in the disinfection programmes is not supplied via the detergent drawer.

With the **Mops . . . + ready to use (rtu)** programme, the mops are ready to use and already impregnated with cleaning agent or detergent and disinfectant. To achieve this, following washing or disinfection there is a finishing stage and then a final spin. The desired humidity level of the mops can vary by setting the residual moisture via the extra “Δ – ΔΔΔΔ” (moist, damp, wet, dripping wet).

The dispensing quantities must be set on site and the standard of disinfection must be checked.

Programme summary

Mop

- To prevent coarse soiling in the machine, shake out the mops before putting them in.

Standard mops		60 °C (Cold to 90 °C)	Load ratio/load size
Fabric	Cotton, viscose, polyester and microfibre mops		1:9 PWM 909 – 9 kg For number, see “Mops load size” chart
Programme sequence	Pre-spin Pre-rinse bath 2nd pre-rinse bath can be activated via extra  “Pre-rinse” Main wash up to 90 °C, wash time 6 min Cool down can be activated in the Miele Benchmark Programming Tool 2 rinse cycles Final spin		
Extras	Pre-rinse, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		
Standard mops + rtu		60 °C (Cold to 90 °C)	
Fabric	Cotton, viscose, polyester and microfibre mops		
Programme sequence	Same programme sequence as Mops standard then set the residual moisture via the extra “  –    ” (moist, damp, wet, dripping wet) The pre-set residual moisture is 2 drops (damp)		
Extras	Pre-rinse, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		

Programme summary

Mops thermal disinfection		90 °C	Load ratio/load size
Fabric	Cotton, viscose, polyester and microfibre mops		1:9 PWM 909 – 9 kg For number, see “Mops load size” chart
Programme sequence	Pre-spin Pre-rinse bath 2nd pre-rinse bath can be activated via extra  “Pre-rinse” Disinfection 90 °C, holding time 10 min Cool down and/or disinfection rinse can be activated in the Benchmark Tool 3 rinse cycles Final spin		
Extras	Pre-rinse, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		
Mops thermal disinf + rtu			
90 °C			
Fabric	Cotton, viscose, polyester and microfibre mops		
Programme sequence	Same programme sequence as Mops thermal disinfection, then set the residual moisture via the extra “δ – ∞∞∞” (moist, damp, wet, dripping wet) The pre-set residual moisture is 2 drops (damp)		
Extras	Pre-rinse, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		

If “Pre-wash” is selected, place the detergent directly in the drum. If necessary, the  and  compartments can be used to add detergent in the main wash cycle.

Programme summary

Mops ch-th disinf 10 min		70 °C	Load ratio/load size
Fabric	Cotton, viscose, polyester and microfibre mops		1:10 PWM 909 – 8 kg
Programme sequence	Pre-spin Pre-rinse bath 2nd pre-rinse bath can be activated via extra  “Pre-rinse” Disinfection* 70 °C, holding time 10 min 3 rinse cycles (optional disinfection rinse can be activated) Final spin		
Extras	Pre-rinse, Soak, Intensive, Rinse plus, Fill stop, Rinse hold		
Mops ch-th disinf 20 min		60 °C	
Fabric	Cotton, viscose, polyester and microfibre mops		
Programme sequence	Pre-spin Pre-rinse bath 2nd pre-rinse bath can be activated via extra  “Pre-rinse” Disinfection* 60 °C, holding time 20 min 3 rinse cycles (optional disinfection rinse can be activated) Final spin		
Extras	Pre-rinse, Soak, Intensive, Rinse plus, Fill stop, Rinse hold		
Mops ch-th dis 10 min+rtu		70 °C	
Fabric	Cotton, viscose, polyester and microfibre mops		
Programme sequence	Programme sequence as for Mops chemo-thermal disinfection*, then set the residual moisture via the extra “δ – δδδδ” (moist, damp, wet, dripping wet) The pre-set residual moisture is 2 drops (damp)		
Extras	Pre-rinse, Soak, Intensive, Rinse plus, Fill stop, Rinse hold		

* The disinfection parameters for chemo-thermal disinfection (temperature, temperature holding time and dispensing quantities) must be set on site to suit detergents and disinfectants.

If "Pre-wash" is selected, place the detergent directly in the drum. If necessary, the  and  compartments can be used to add detergent in the main wash cycle.

Programme summary

Mops ch-th dis 20min+rtu		60 °C	Load ratio/load size
Fabric	Cotton, viscose, polyester and microfibre mops		1:10 PWM 909 – 8 kg
Programme sequence	Programme sequence as for Mops chemo-thermal disinfection*, then set the residual moisture via the extra “δ – δδδδ” (moist, damp, wet, dripping wet) The pre-set residual moisture is 2 drops (damp)		
Extras	Pre-rinse, Soak, Intensive, Rinse plus, Add agent, Rinse hold		
Mops rtu			
Fabric	Cotton, viscose, polyester and microfibre mops		1:9 PWM 909 – 9 kg For number, see “Mops load size” chart
Programme sequence	1 rinse cycle then set the residual moisture via the extra “δ – δδδδ” (moist, damp, wet, dripping wet) The pre-set residual moisture is 2 drops (damp)		
Extras	Fill stop, Rinse hold		
New mops		60 °C (Cold to 90 °C)	
Fabric	For washing new mops		
Programme sequence	Main wash up to 90 °C, wash time 4 min Cool down can be activated in the Miele Benchmark Programming Tool 2 rinse cycles Final spin		
Extras	Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		

* The disinfection parameters for chemo-thermal disinfection (temperature, temperature holding time and dispensing quantities) must be set on site to suit detergents and disinfectants.

If “Pre-wash” is selected, place the detergent directly in the drum. If necessary, the  and  compartments can be used to add detergent in the main wash cycle.

Programme summary

The **Mops rtu** programme is suitable for the subsequent finishing of clean and dry mops. A disinfecting agent is applied during finishing. Dispensing quantities must be set on site and the standard of disinfection must be checked.

Mop load size (cotton) applies to the load ratio 1:9

Mop size/ weight	40 cm 190 g/ mop	50 cm 220 g/ mop	60 cm 280 g/ mop	80 cm 360 g/ mop	110 cm 510 g/ mop	130 cm 610 g/ mop	160 cm 720 g/ mop
PWM 909	47	41	32	25	18	15	13

Tip: When using microfibre mops, the load size is higher due to the lower mop weight.

Mop load size (microfibre) applies to the load ratio 1:9

Mop size/weight	40 cm 120 g/mop	50 cm 170 g/mop
PWM 909	75	53

A reduced number may apply to particularly high-volume, light-weight mops.

Mats/Pads programmes

Mats		40 °C (Cold to 60 °C)	Load ratio/Load size
Fabric	Door mats		1:15 PWM 909 – max. 5.4 kg
Programme sequence	Pre-rinse Main wash up to 60 °C, wash time 8 min 3 rinsing baths Final spin		
Extras	Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		
Heavily soiled mats 60 °C (Cold to 60 °C)			
Fabric	Heavily soiled door mats		
Programme sequence	Pre-rinse Pre-wash up to 40 °C Main wash up to 60 °C, wash time 12 min 3 rinsing baths Final spin		
Extras	Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		
Pads 40 °C (Cold to 60 °C)			
Fabric	Polishing pads		1:50 PWM 909 – 1.6 kg
Programme sequence	Pre-rinse bath 2nd pre-rinse bath can be activated via extra  “Pre-rinse” Main wash up to 60 °C, wash time 10 min 3 rinse cycles Final spin		
Extras	Pre-rinse, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		

Tip: The mats load size may vary depending on the size, stiffness and thickness of the mats.

Programme summary

Cloths programmes

These programmes are suitable for washing, disinfecting and finishing (at different humidity levels) cleaning cloths made of cotton, mixed fibre or microfibre fabric used in facility management.

Standard cloths		60 °C (Cold to 90 °C)	Load ratio/load size
Fabric	Cotton, viscose, polyester and microfibre cleaning cloths		1:18 PWM 909 – 4.6 kg For number, see “Cloths load size” chart
Programme sequence	Pre-rinse Pre-wash up to 30 °C Main wash up to 90 °C, wash time 6 min 3 rinsing baths Final spin		
Extras	Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		
Standard cloths + rtu		60 °C (Cold to 90 °C)	
Fabric	Cotton, viscose, polyester and microfibre cleaning cloths		
Programme sequence	Same programme sequence as Cloths standard then set the residual moisture via the extra “δ – δδδδ” (moist, damp, wet, dripping wet) The pre-set residual moisture is 2 drops (damp)		
Extras	Pre-wash, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		

Programme summary

Cloths therm. disinfection		90 °C	Load ratio/load size
Fabric	Cotton, viscose, polyester and microfibre cleaning cloths		1:18 PWM 909 – 4.6 kg For number, see “Cloths load size” chart
Programme sequence	Pre-rinse Pre-wash up to 30 °C Disinfection 90 °C, holding time 10 min Cool down and/or disinfection rinse can be activated in the Miele Benchmark Programming Tool 3 rinsing baths Final spin		
Extras	Soak, Intensive, Rinse plus, Fill stop, Rinse hold		
Cloths therm. disinf + rtu		90 °C	
Fabric	Cotton, viscose, polyester and microfibre cleaning cloths		
Programme sequence	Same programme sequence as Cloths thermal disinfection then set the residual moisture via the extra “δ – ∆∆∆” (moist, damp, wet, dripping wet) The pre-set residual moisture is 2 drops (damp)		
Extras	Pre-wash, Soak, Intensive, Rinse plus, Fill stop, Rinse hold		
Cloths ch-th disinf 10 min		70 °C	
Fabric	Cotton, viscose, polyester and microfibre cleaning cloths		
Programme sequence	Pre-rinse Pre-wash up to 30 °C Disinfection 70 °C, holding time 10 min 3 rinsing baths (optional disinfection rinse can be activated) Final spin		
Extras	Soak, Intensive, Rinse plus, Fill stop, Rinse hold		
If “Pre-wash” is selected, place the detergent directly in the drum. If necessary, the  and  compartments can be used to add detergent in the main wash cycle.			

Programme summary

Cloths ch-th disinf 20 min		60 °C	Load ratio/load size
Fabric	Cotton, viscose, polyester and microfibre cleaning cloths		1:18 PWM 909 – 4.6 kg For number, see “Cloths load size” chart
Programme sequence	Pre-rinse Pre-wash up to 30 °C Disinfection 60 °C, holding time 20 min 3 rinsing baths (optional disinfection rinse can be activated) Final spin		
Extras	Soak, Intensive, Rinse plus, Add agent, Rinse hold		
Cloths ch-th dis 10min+rtu		70 °C	
Fabric	Cotton, viscose, polyester and microfibre cleaning cloths		
Programme sequence	Programme sequence as for Cloths chemo-thermal disinfection, then set the residual moisture via the extra “δ – δδδδ” (moist, damp, wet, dripping wet) The pre-set residual moisture is 2 drops (damp)		
Extras	Pre-wash, Soak, Intensive, Rinse plus, Fill stop, Rinse hold		
Cloths ch-th dis 20min+rtu		60 °C	
Fabric	Cotton, viscose, polyester and microfibre cleaning cloths		
Programme sequence	Programme sequence as for Cloths chemo-thermal disinfection, then set the residual moisture via the extra “δ – δδδδ” (moist, damp, wet, dripping wet) The pre-set residual moisture is 2 drops (damp)		
Extras	Pre-wash, Soak, Intensive, Rinse plus, Fill stop, Rinse hold		

If “Pre-wash” is selected, place the detergent directly in the drum. If necessary, the  and  compartments can be used to add detergent in the main wash cycle.

Programme summary

Cloths rtu		Load ratio/load size
Fabric	Cotton, viscose, polyester and microfibre cleaning cloths	1:18 PWM 909 – 4.6 kg For number, see “Cloths load size” chart
Programme sequence	1 rinse cycle then set the residual moisture via the extra “δ – δδδδ” (moist, damp, wet, dripping wet) The pre-set residual moisture is 2 drops (damp)	
Extras	Fill stop, Rinse hold	

Cloths load size applies to the load ratio 1:18

Cloths size/weight	16 g/cloth	22 g/cloth	43 g/cloth
PWM 909	290	210	105

The programme **Standard cloths** is also suitable for cleaning cloths that are not to be used immediately after washing, but are to be stored after drying.

With the **Cloths . . . + rtu** programmes, the cloths are ready to use and already impregnated with detergent and disinfectant. To achieve this, following washing or disinfection there is a finishing stage and then a final spin. The desired moisture level of the cloths can vary by setting the residual moisture via the extra “δ – δδδδ” (moist, damp, wet, dripping wet). Dispensing quantities must be set on site and the standard of disinfection must be checked.

The **Cloths rtu** programme is suitable for the subsequent finishing of clean and dry cleaning cloths. A disinfecting agent is applied during finishing. Dispensing quantities must be set on site and the standard of disinfection must be checked.

Programme summary

Fire brigade programme overview

These programmes are suitable for washing and proofing Nomex fire-fighting apparel, jackets and trousers, breathing masks and chemical protective suits.

Protective clothing programmes

Protective clothing		60 °C (Cold to 60 °C)	Load ratio/Load size
Fabric	Nomex fire-fighting apparel, jackets, trousers		See “Protective clothing load size” chart
Programme se- quence	Pre-cleaning up to 40 °C Main wash up to 60 °C, wash time 6 min 3 rinse cycles, Final spin		
Extras	Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		
Protective cloth. + proof		60 °C (Cold to 60 °C)	
Fabric	Nomex fire-fighting apparel, jackets, trousers		
Programme se- quence	Pre-cleaning up to 40 °C Main wash up to 60 °C, wash time 6 min 2 rinse cycles Proofing bath 40 °C Final spin		
Extras	Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		
Proof protect. clothing		40 °C	
Fabric	Nomex fire-fighting apparel, jackets, trousers		
Programme se- quence	1 rinsing bath Reproofing bath 40 °C Final spin		
Extras	Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		

Protective clothing load size

Model	Quantity
PWM 909	Approx. 1 suit (or 2 jackets)

Preparing Protective clothing for washing

- Do not staple labels to the items.
- Remove carabiner hooks if possible, or enclose them in a side pocket.
- Close Velcro fasteners or cover them with Velcro tape.
- Wash sheepskin linings separately.
- Do not wash garments inside out.
- Observe the load sizes.

Protective clothing is a programme for washing fire-fighting apparel. It is not suitable for washing garments containing wool as lining material.

Tip: Detergent: We recommend using a liquid detergent with reduced pH that is particularly effective for dissolving grease and pigmentation stains.

The proofing agent must be suited to the special requirements of this area of use.

Programme summary

Masks programmes

Masks are programmes for washing and disinfecting breathing masks with head straps.

- Put the head bands over the masks to protect the visors before loading the machine.
- Put each mask into its own protective bag and fasten it.

The protective bags are available to order from the Miele Customer Service Department.

- Remove the masks from the bags after reprocessing.
- Spin damp, empty protective bags using the **Spin bags** programme.

Masks		60 °C	Load ratio/load size
Load	Breathing masks with head straps		PWM 909 – 4 masks
Programme sequence	Disinfection* 60 °C, holding time 20 min 4 rinse cycles (optional disinfection rinse can be activated)		
Extras	Soak, Intensive, Rinse plus, Fill stop, Rinse hold		
Masks with pre-wash		60 °C	
Load	For heavily soiled breathing masks with head straps		
Programme sequence	Pre-cleaning 30 °C Disinfection* 60 °C, holding time 20 min 4 rinse cycles (optional disinfection rinse can be activated)		
Extras	Soak, Intensive, Rinse plus, Fill stop, Rinse hold		
Spin wash bags			
Load	Mask bags		1:20
Programme sequence	Spinning		

* The disinfection parameters for chemo-thermal disinfection (temperature, temperature holding time and dispensing quantities) must be set on site to suit detergents and disinfectants.

If “Pre-wash” is selected, place the detergent directly in the drum. If necessary, the  and  compartments can be used to add detergent in the main wash cycle.

To avoid recontamination, the water inlet for the rinse cycles in the disinfection programmes is not supplied via the detergent drawer.

Do not wash masks with connections for helmet-mask combinations.
The clasps are likely to scratch visors.

Use a suitable detergent. Observe the manufacturer’s instructions.

Rescue clothing programmes

Helmets*		60 °C (Cold to 60 °C)	Load ratio/load size
Fabric	Firefighter helmets		PWM 909 – 3 helmets
Programme sequence	Pre-wash up to 40 °C Main wash up to 60 °C, wash time 16 min 3 rinse cycles		
Extras	Soak, Rinse plus		

* The safety helmet manufacturer must allow the helmet to be washed or dried by machine.

Before loading the machine, push the sliding visor, if applicable, into the safety helmet. Place one helmet in each of the padded protective bags provided and close them.

The protective bags are available to order from the Miele Customer Service Department.

Remove easily removable attachments from the helmet and wash in a separate washing net.

Gloves		40 °C (Cold to 40 °C)	Load ratio/load size
Fabric	Gloves with and without leather trim		PWM 909 – 17 gloves
Programme sequence	Main wash up to 40 °C, wash time 9 min 3 rinse cycles Final spin Leather care 40 °C Final spin		
Extras	Soak, Water plus, Rinse plus		

After washing, air-dry the gloves with and without leather trim. Before drying, roll the leather gloves or gloves with leather trim through your hands to maintain the elasticity of the leather.

Belts*		40 °C (Cold to 40 °C)	Load ratio/load size
Fabric	Fire brigade belts also with aluminium components and leather trim		PWM 909 – 6 belts
Programme sequence	Main wash up to 40 °C, wash time 8 min 3 rinse cycles Final spin		
Extras	Pre-wash, Rinse plus		

* The belt manufacturer must allow the belt to be washed by machine.

If there are aluminium attachments on the belts, we recommend using a liquid delicates detergent with reduced pH value which is particularly effective for dissolving pigmentation stains.

Place 2–3 belts (safety belts) in each of the padded protective bags provided and close them.

The protective bags are available to order from the Miele Customer Service Department.

After washing, air-dry the belts. Before drying, roll the leather components through your hands and, if necessary, treat them with a suitable leather refatting agent to maintain the elasticity of the leather.

Programme summary

Emergency services clothing is a programme for disinfecting. It is not suitable for washing garments containing wool as lining material.

Do not wash garments inside out.

Disin. rescue clothing*		60 °C	Load ratio/load size
Fabric	Nomex and cottons		See “Emergency ser- vices clothing load size” chart
Programme se- quence	Pre-wash up to 40 °C Disinfection* 60 °C, holding time 20 min 2 rinse cycles Final spin		
Extras	Soak, Rinse plus		
Dis./proof rescue cloth.* / **		60 °C	
Fabric	Nomex and cottons		
Programme se- quence	Pre-wash up to 40 °C Disinfection* 60 °C, holding time 20 min 2 rinse cycles Proofing bath** 40 °C Final spin		
Extras	Soak, Rinse plus		

* The disinfection parameters for chemo-thermal disinfection (temperature, temperature holding time and dispensing quantities) must be set on site to suit detergents and disinfectants.

** The proofing agent must be suited to the special requirements of this area of use.

If “Pre-wash” is selected, place the detergent directly in the drum. If necessary, the  and  compartments can be used to add detergent in the main wash cycle.

Emergency services clothing load size

Model	Quantity
PWM 909	Approx. 3 suits

Programme summary

Protective clothing		40 °C (Cold to 60 °C)	Load ratio/load size
Fabric	Lightly to heavily soiled protective clothing with a polyester or polyester-cotton mixed fibre (also with elastane or Cordura content) cut protection insert for protective clothing in protection classes 0 to 3		1:20 PWM 909 – 4 kg
Programme sequence	Pre-wash up to 30 °C Main wash up to 60 °C 3 rinse cycles Final spin		
Extras	Pre-rinse, 2nd pre-wash, Soak, Intensive, Water plus, Rinse plus, Fill stop, Rinse hold		

Recommendations for caring for protective clothing with cut protection inserts:

- Follow the clothing manufacturer's care recommendations.
- Close all zips and velcro fasteners.
- Use liquid detergent for delicates and coloureds.
- Only wash items of similar colours together.
- Select the "Protective clothing" special programme.
- Do not use multi-purpose detergents, bleaching agents and/or fabric conditioners.
- For heavy soiling, dispense an additional booster.
- After washing, gently pull the protective clothing into shape. Air-dry the clothing or dry it in a drying cabinet at temperatures up to 50 °C.
- Do not use a tumble dryer.
- Store the protective clothing in a dry place away from light.

Programme summary

Wetsuits		30 °C (Cold to 40 °C)	Load ratio/load size
Fabric	Lightly to heavily soiled wet, semi-dry and dry suits made of neoprene, nylon, polyester or (breathable) laminate. The textiles can also have permanently attached footies/boots, parts made of Cordura or stretchy material.		1:20 PWM 909 – 4 kg
Programme sequence	Pre-wash up to 30 °C Main wash up to 40 °C 3 rinse cycles Spin cycle		
Extras	2nd pre-wash, Soak, Intensive, Water plus, Rinse plus, Fill stop, Rinse hold		

Recommendations for caring for wetsuits and diving suits:

- Follow the clothing manufacturer's care recommendations.
- Close all zips and velcro fasteners.
- Select the "Wetsuits" special programme.
- Use liquid detergent for delicates and coloureds.
- If disinfection is required, add an additional disinfectant, e.g. Kreussler Lanadol ABAC, and follow the disinfection requirements.
- For heavy soiling, dispense an additional booster.
- After washing, air-dry the suit or hang it in a drying cabinet at temperatures up to 40 °C.
- Tumble dry suits with non-detachable footwear/footies upside down in the air or in (heated) air-flow hangers.
- Do not use a tumble dryer.
- Store the suits away from light and hang them on a hanger with a wide shoulder support in a dry room.

WetCare

WetCare “wet cleaning” is a very gentle cleaning process using water and special care products for clothing that could previously only be cleaned chemically.

WetCare sensitive		25 °C (Cold to 30 °C)	Load ratio/Load size
Fabric	Non-washable outerwear		1:15 PWM 909 – 5.4 kg
Programme sequence	Main wash up to 30 °C, wash time 2 min Waterproof finish 25 °C Final spin		
Extras	Pre-wash, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		
WetCare silks		30 °C (Cold to 30 °C)	
Fabric	For non-washable outerwear which creases easily		1:20 PWM 909 – 4 kg
Programme sequence	Main wash up to 30 °C, wash time 6 min Waterproof finish 25 °C Final spin		
Extras	Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		
WetCare intensive		40 °C (Cold to 40 °C)	
Fabric	Washable outerwear		1:15 PWM 909 – 5.4 kg
Programme sequence	Main wash up to 40 °C, wash time 6 min Rinse cycle Waterproof finish 25 °C Final spin		
Extras	Pre-wash, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		

In the textile cleaning programmes, no hot water valves are activated. The incoming water must not exceed a temperature of 30 °C.

Programme summary

Outerwear programme overview

Outerwear		40 °C (Cold to 40 °C)	Load ratio/Load size
Fabric	Polyamide and membrane items		1:15 PWM 909 – 5.4 kg
Programme sequence	Main wash up to 40 °C, wash time 6 min 2 rinse cycles Final spin		
Extras	Pre-wash, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		
Wash/proofing 40 °C			
Fabric	Polyamide and membrane items		
Programme sequence	Main wash up to 40 °C, wash time 6 min 2 rinse cycles Proofing up to 40 °C Final spin		
Extras	Pre-wash, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		
Rinse/proofing 40 °C			
Fabric	Polyamide and membrane items		
Programme sequence	2 rinse cycles Proofing 40 °C Final spin		
Extras	Rinse plus, Fill stop, Rinse hold		
Down jackets		40 °C (Cold to 60 °C)	
Fabric	Down-filled items		1:25 PWM 909 – 3.2 kg
Programme sequence	Main wash up to 60 °C, wash time 7 min 2 rinse cycles Final spin		
Extras	Pre-rinse, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		

Equestrian

This programme is suitable for washing and proofing horse blankets, saddle cloths, gaiters, hoof boots, bandages, textile halters.

Horse blankets		60 °C (Cold to 60 °C)	Load ratio/Load size
Fabric	Horse blankets, saddle cloths, gaiters, hoof boots, bandages, textile halters		1:13 See “Horse blankets load size” chart
Programme sequence	Pre-rinse 2nd pre-rinse can be activated via extra  “Pre-rinse” Pre-wash up to 40 °C Main wash up to 60 °C, wash time 6 min 3 rinse cycles Final spin		
Extras	Pre-rinse, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		
Woollen horse blankets		30 °C (Cold to 40 °C)	
Fabric	Horse blankets containing wool		
Programme sequence	Pre-rinse Pre-wash up to 30 °C Main wash up to 40 °C, wash time 8 min Wash rhythm “Gentle+” 2 rinse cycles Final spin		
Extras	Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		
Horse blank. + proofing		60 °C (Cold to 60 °C)	
Fabric	Horse blankets, saddle cloths, gaiters, hoof boots, bandages, textile halters		
Programme sequence	Pre-rinse 2nd pre-rinse can be activated via extra  “Pre-rinse” Pre-wash up to 30 °C Main wash up to 60 °C, wash time 6 min 2 rinse cycles Proofing 30 °C Final spin		
Extras	Pre-rinse, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		

Pre-treatment

Remove coarse soiling from very heavily soiled blankets with a strong water jet or a vacuum cleaner.

Programme summary

Detergent

For washing, a detergent without bleaching agent and optical brighteners should be used. For woollen blankets, products with slightly reduced pH should be used. It is also possible to add enzyme-containing products.

It needs to be ensured that no proteases are used as these enzymes attack and damage the wool.

Horse blankets load size

Model	Load, maximum $\frac{3}{4}$ of the total recommended load		
	Saddle cloths	Summer blankets	Winter blankets
PWM 909	4	1	-

Buckles

Metal buckles, hooks and eye fasteners must be covered to protect the drum.
Special bags for this purpose are available to order from Miele.

Sport

Sportswear		40 °C (Cold to 60 °C)	Load ratio/Load size
Fabric	Polyester or polyamide with and without spandex		1:20 PWM 909 – 4 kg
Programme sequence	Main wash up to 60 °C, wash time 6 min 3 rinse cycles Final spin		
Extras	Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		
Sport Microfibre		40 °C (Cold to 60 °C)	
Fabric	Polyester, polyamide		
Programme sequence	Main wash up to 60 °C, wash time 6 min 2 rinse cycles Final spin		
Extras	Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		
Trainers		40 °C (Cold to 60 °C)	
Fabric	Washable trainers (no leather shoes), shin pads, elbow protectors and similar items		
Programme sequence	Main cleaning up to 60 °C, wash time 6 min 2 rinse cycles Final spin		
Extras	Pre-rinse, Pre-wash, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		

Programme summary

Workwear

Oil/fat		60 °C (Cold to 90 °C)	Load ratio/Load size
Fabric	Cotton or mixed fibre workwear, table cloths or cleaning cloths soiled with oil or grease		1:10 PWM 909 – 8 kg
Programme sequence	Pre-wash up to 40 °C Main wash up to 90 °C, wash time 10 min 3 rinse cycles Final spin		
Extras	Pre-rinse, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		
Dust/flour		60 °C (Cold to 90 °C)	
Fabric	Cotton or mixed fibre workwear, table cloths or cleaning cloths soiled with dust or flour		
Programme sequence	Pre-wash up to 40 °C Main wash up to 90 °C, wash time 10 min 2 rinse cycles Final spin		
Extras	Pre-rinse, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold		

Sluice programme overview (Healthcare HTM 01-04)

The sluice programmes are for extremely heavily soiled personal clothing, as well as heavily soiled towelling and bed linen.
Disinfection according to provisions of British National Health Service (GB). There are two different disinfection options: 65 °C for 10 min or 71 °C for 3 min.

Sluice low*		65 °C	Load ratio/Load size
Fabric	Heavily soiled personal clothing, towelling and bed linen		1:15 PWM 909 – 5.4 kg
Programme sequence	2 pre-rinse cycles Pre-wash 60 °C, 5 min Disinfection 65 °C, holding time 10 min 3 rinse cycles Final spin		
Extras	Soak, Intensive, Rinse plus, Fill stop, Rinse hold		
Sluice high*		71 °C	
Fabric	Heavily soiled personal clothing, towelling and bed linen		
Programme sequence	2 pre-rinse cycles Pre-wash 60 °C, 5 min Disinfection 71 °C, holding time 3 min 3 rinse cycles Final spin		
Extras	Soak, Intensive, Rinse plus, Fill stop, Rinse hold		

* Only included in the DV (drain valve) model

Programme summary

Programme sequence Sluice

Sluice low 65 °C					
Programme stage	Load-to-liquor ratio *	Thermostop	Temperature	Temperature holding time (wash time 2)	Programmed wash time approx.
Pre-rinse 1	1:7	No	Cold	-	5 min
Pre-rinse 2	1:7	No	Cold	-	4 min
Pre-wash	1:7	Yes	60 °C	5 min	-
1-minute spin at 500 rpm					
Disinfection	1:5	Yes	65 °C	10 min	- **
2-minute spin at 800 rpm					
Rinse 1	1:5	No	Cold	-	5 min
1-minute spin at 800 rpm					5 min
Rinse 2	1:5	No	Cold	-	5 min
1-minute spin at max. speed					
Rinse 3	1:4	No	Cold	-	5 min
5-minute spin at max. speed					
Sluice 71 °C					
Pre-rinse 1	1:7	No	Cold	-	5 min
Pre-rinse 2	1:7	No	Cold	-	4 min
Pre-wash	1:7	Yes	60 °C	5 min	-
1-minute spin at 500 rpm					
Disinfection	1:5	Yes	71 °C	3 min	- **
2-minute spin at 800 rpm					
Rinse 1	1:5	No	Cold	-	5 min
1-minute spin at 800 rpm					5 min
Rinse 2	1:5	No	Cold	-	5 min
1-minute spin at max. speed					
Rinse 3	1:4	No	Cold	-	5 min
5-minute spin at max. speed					

* Depending on load and fabric type

** Depending on type of heating and, with hot water connection, the hot water temperature

Programme overview: ECO programmes

Colours Eco 40 °C (Cold to 40 °C)		Load ratio/load size
Fabric	Lightly soiled cotton, linen and mixed fibre fabrics, e.g. bed linen and towelling	1:9 PWM 909 – 9 kg
Programme sequence	Main wash up to 40 °C, wash time 11 min 2 rinse cycles Last rinse cycle cold Final spin	
Extras	Pre-wash, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold	
Colours Eco intensive 40 °C (Cold to 40 °C)		Load ratio/load size
Fabric	Normally soiled cotton, linen and mixed fibre fabrics, e.g. bed linen and towelling	1:9 PWM 909 – 9 kg
Programme sequence	Main wash up to 40 °C, wash time 26 min 2 rinse cycles Last rinse cycle cold Final spin	
Extras	Pre-wash, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold	

Programme summary

Minimum iron Eco 30 °C (Cold to 30 °C)		Load ratio/load size
Fabric	Lightly soiled synthetic and mixed fibre fabrics	1:20 PWM 909 – 4 kg
Programme sequence	Main wash up to 30 °C, wash time 7 min 2 rinse cycles Final spin	
Extras	Pre-wash, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold	
Minimum iron Eco intensive 30 °C (Cold to 30 °C)		Load ratio/load size
Fabric	Lightly soiled synthetic and mixed fibre fabrics	1:20 PWM 909 – 4 kg
Programme sequence	Main wash up to 30 °C, wash time 22 min 2 rinse cycles Final spin	
Extras	Pre-wash, Soak, Water plus, Intensive, Rinse plus, Fill stop, Rinse hold	

United Kingdom

Miele Co. Ltd., Fairacres, Marcham Road
Abingdon, Oxon, OX14 1TW
Professional Sales, Tel: 0845 365 6608
E-mail: professional@miele.co.uk
Internet: www.miele.co.uk/professional

Australia

Miele Australia Pty. Ltd.
ACN 005 635 398, ABN 96 005 635 398
Level 4, 141 Camberwell Road, Hawthorn East, VIC 3123
Tel: 1300 731 411
Internet: www.miele.com.au/professional
E-mail: professional.sales@miele.com.au

China Mainland

Miele Electrical Appliances Co., Ltd.
1-3 Floor, No. 82 Shi Men Yi Road
Jing' an District, 200040 Shanghai, PRC
Tel: +86 21 6157 3500, Fax: +86 21 6157 3511
E-mail: info@miele.cn, Internet: www.miele.cn

Hong Kong, China

Miele (Hong Kong) Ltd.
41/F - 4101, Manhattan Place
23 Wang Tai Road, Kowloon Bay, Hong Kong
Tel: (852) 2610 1025, Fax: (852) 3579 1404
Email: customerservices@miele.com.hk
Website: www.miele.hk

India

Miele India Pvt. Ltd.
1st Floor, Copia Corporate Suites,
Commercial Plot 9, Mathura Road, Jasola,
New Delhi - 110025
E-mail: customercare@miele.in, Website: www.miele.in

Ireland

Miele Ireland Ltd.
2024 Bianconi Ave., Citywest Business Campus,
Dublin 24
Tel: (01) 461 07 10, Fax: (01) 461 07 97
E-Mail: info@miele.ie, Internet: www.miele.ie

Malaysia

Miele Sdn Bhd
Suite 12-2, Level 12
Menara Sapura Kencana Petroleum
Solaris Dutamas No. 1, Jalan Dutamas 1
50480 Kuala Lumpur, Malaysia
Phone: +603-6209-0288
Fax: +603-6205-3768

New Zealand

Miele New Zealand Limited
IRD 98 463 631
8 College Hill
Freemans Bay, Auckland 1011, NZ
Tel: 0800 464 353
Internet: www.miele.com.au/professional
E-mail: professional.sales@miele.com.au

Singapore

Miele Pte. Ltd.
29 Media Circle, #11-04 ALICE@Mediapolis
Singapore 138565
Tel: +65 6735 1191, Fax: +65 6735 1161
E-Mail: info@miele.com.sg
Internet: www.miele.sg

South Africa

Miele (Pty) Ltd
63 Peter Place, Bryanston 2194
P.O. Box 69434, Bryanston 2021
Tel: (011) 875 9000, Fax: (011) 875 9035
E-mail: info@miele.co.za
Internet: www.miele.co.za

United Arab Emirates

Miele Appliances Ltd.
Showroom 1, Eiffel 1 Building
Sheikh Zayed Road, Umm Al Sheif
P.O. Box 114782 - Dubai
Tel. +971 4 3044 999, Fax. +971 4 3418 852
800-MIELE (64353)
E-Mail: info@miele.ae
Website: www.miele.ae



Manufacturer: Miele & Cie. KG, Carl-Miele-Straße 29, 33332 Gütersloh, Germany