

ProCare

Tex 11

Multi-purpose detergent

Use:

ProCare Tex 11 is a high-performance general-purpose alkaline detergent with enzymes and without phosphates for white and coloured items for use in commercial washing machines.

ProCare Tex 11 is ideal for use by commercial laundry and laundrettes.

High concentrations of enzymes and oxygen bleach together with highly active tensides make this product fully effective at low temperatures.

Product properties:

- Effective at temperatures of 30 °C to 90 °C
- Particularly effective, even at low temperatures
- Very efficient thanks to new, special-purpose enzymes
- Brilliant whites thanks to selected optical brighteners
- Phosphorous-free
- Contains active oxygen
- Excellent in removing soil and tackling grease
- Can be used at all water hardness levels

Dispensing recommendation [ml per kg of laundry]:

Water hardness* Hardness range	Light soiling	Average soiling	Heavy soiling
0 – 8,4 Soft	6 (11)	8 (14)	10 (18)
8,4 – 14 Medium	8 (14)	10 (18)	12 (21)
> 14 Hard	11 (20)	13 (24)	15 (28)

*Water hardness ranges and figures can be provided by water supply companies.

ProCare Tex 11 is designed to perform best in Miele Professional washing machines.

- Manual dispensing before each wash cycle
- Dispensing recommendation depends on water hardness

Please note!

- Do not mix with other products.
- Operating instructions for Miele Professional washing machines must be observed.

ProCare

Tex 11

Multi-purpose detergent

Technical data:


- Bulk weight: 0.64 g/cm³
- pH value (1 % solution): 10.0 – 11.0

Ingredients according to EU Regulation 648/2004 on detergents:

- 5 – <15 % zeolites
- Enzymes

Storage:

ProCare Tex 11 should be stored in a dry and frost-free place. Always re-seal containers once the required amount of product has been removed.

In the original packaging, the product can be stored for at least 24 months. 

Warning and safety notes:

For safety and environmental information, see EU safety data sheets. These are available from the Miele websites listed below.

Dispose of containers only when completely empty and sealed. See safety data sheet regarding disposal of residual agent.

All information contained in this leaflet is current and correct to our knowledge and experience. This does not however release users from the obligation of conducting their own checks and tests.

A legally binding assurance of specific product properties cannot be inferred from this.

Available packaging units and accessories:

Designation	Packaging unit	Material number
<i>ProCare Tex 11</i>	10 kg sack	11520420
<i>ProCare Tex 11</i>	20 kg sack	11520440

Contact information:

Germany

Miele & Cie. KG
Carl-Miele-Straße 29,
33332 Gütersloh
Tel: +49 (0) 8002244644
vertrieb@miele-professional.de
www.miele.de/professional

United Kingdom

Miele Co. Ltd.
Fairacres, Marcham Road
Abingdon, Oxon, OX14 1TW
Customer Contact Centre
Tel: 0330 160 6600
professional@miele.co.uk



Germany

BÜFA Reinigungssysteme GmbH & Co. KG
August-Hanken-Str. 30
26125 Oldenburg
www.buefa.com