

ProCare

Tex 10 W

Detergent for woollens

Application:





is a slightly acidic, highly active detergent for the gentle washing of woollens in Miele Professional washing machines. is ideal for use in commercial laundries and launderettes.

Special-purpose ingredients guarantee reliable colour-fastness. This detergent is gentle on fibres thanks to protective polymers and an integrated buffer system which prevents felting.

Product properties:

- Particularly effective, even at low temperatures of 0°C to 30°C
- Can be used at all water hardness levels
- No dye transfer
- Prevents redeposition
- No felting of woollens

Dispensing recommendation [ml per kg of laundry]:

			
1°dH ≈ 0,16 mmol/l			
°dH	ml/kg	ml/kg	ml/kg
0 – 8,4	14	17	20
8,4 – 14	17	20	23
> 14	20	23	26

Water hardness ranges and figures can be provided by water supply companies.

Please note!

- Do not mix with other products.
- Operating instructions for Miele Professional washing machines must be observed.

Technical data:

- Bulk weight: 1.02 g/cm³
- pH value (1 % solution): 4.8 – 5.8

Ingredients according to EU Regulation 648/2004 on detergents:

- 5 – <15 % zeolites
- Enzymes

Storage:

should be stored in a dry and frost-free place. Always re-seal containers once the required amount of product has been removed. In the original packaging, the product can be stored for at least 24 months.

Risks and safety warnings:

For safety and environmental information, see the safety data sheets. These are available from the Miele websites listed below. Dispose of containers only when completely empty and sealed. Disposal of residues: see safety data sheet. All information contained in this leaflet is current and correct to our knowledge and experience. This does not however release users from the obligation of conducting their own checks and tests. A legally binding assurance of specific product properties cannot be inferred from this.

Available packaging units and accessories:

Designation	Packaging unit	Material number
ProCare Tex 10 W	20 l canister	12338960



Germany

BÜFA Reinigungssysteme GmbH & Co. KG
August-Hanken-Str. 30
26125 Oldenburg
www.buefa.com

Contact information:

Germany

Miele & Cie. KG
Carl-Miele-Straße 29,
33332 Gütersloh
Tel: +49 (0) 8002244644
vertrieb@miele-professional.de
www.miele.de/professional

United Kingdom

Miele Co. Ltd.
Fairacres, Marcham Road
Abingdon, Oxon, OX14 1TW
Customer Contact Centre
Tel: 0330 160 6600
professional@miele.co.uk