

**Miele**

---

Minimum space.  
Maximum power.

---

**The new generation Little Giants**

Compact washing machines and tumble dryers for commercial use.



**The perfect appliances  
for your daily working life**

The commercial washing machines from Miele Professional guarantee the best results at a low cost. All specifications and features such as speed, hygiene, performance, innovation and reliability address real needs, and our machines set standards in terms of optimizing cost-efficiency and environmental impact.

Whatever the demands made of our appliances, the powerful performance and durability of our robust machine constructions cannot fail to impress. Our customers can concentrate on their business, confident that our appliances will deliver top quality results time and time again. Miele's guiding principle, 'Immer Besser' aims to set a standard of 'Forever Better' products that combine fascinating technology, sustainable innovations and outstanding performance. Founded in 1899, Miele is celebrating 120 years of innovation and is now in the fourth generation of family ownership.

**Miele's Quality Pledge**

Voted one of Germany's Top 3 manufacturers, all Miele Professional machines are rigorously tested, with our washing machines tested to 30,000 cycles. In Australia, our customers deal direct with the manufacturer, and Miele's own team of fully trained service technicians.



Washing machines  
are tested to:

**30,000  
cycles**



Tumble dryers  
are tested to:

**40,000  
cycles**



on/off switches  
tested to:

**100,000  
presses**



Dryers' central  
bearings tested to:

**20,000  
hours**



Dryers' fluff flap  
open and closed:

**10,000  
times**





## Stackability

### ALL MODELS

When you think of an on-premise laundry, the first objection is usually related to the space you think you'll need. The new generation Little Giants machines take up less than 0.5m<sup>2</sup> when stacked and are perfect where space is minimal.

## Performance range

### PWM 507 + PDR 507

The efficient Performance range includes a plethora of innovative features which make laundry care as simple as possible. Thanks to their exemplary short washing and drying cycles, laundry is ready for use again in only 95 minutes, whilst the precise use of water, energy and detergent is evidence of the sustainable use of resources and low running costs. Rising to the specific challenges for small businesses, hotels, restaurants, healthcare and aged care facilities in every respect, the Performance range meets the demand for excellent results, economy, reliability and longevity.

- 7kg load capacity
- Cottons 60°C cycle lasting only 49 minutes
- Short 46-minute drying cycle
- Wash up to 6 cycles per day
- High-performance wash programmes
- Stackable design
- Tested for intensive use for unparalleled Miele quality
- Patented Miele honeycomb drum with sculptured surface, protecting fibres and ensuring perfect wash results
- EcoSpeed – optimum wash rhythm enabling intensive cleaning performance with less water
- PerfectDry – Mineral sensors monitor water quality and adjust drying cycle accordingly, preventing under or overdrying







## Performance plus range

### PWM 908 + PDR 908

The high-end Performance Plus model range is ideal for reprocessing textiles in a fast and uncomplicated way. Conveniently select wash programmes and machine functions with a fingertip via the clear-text touch display, or customize controls and programme options to your liking. The compact dimensions are ideal for installation in small rooms, yet the large capacity drum can accommodate a king size duvet. With uncompromising quality and top-class efficiency, the new generation Little Giants surpass all demands placed on commercial laundry systems.

- 8kg load capacity
- One-touch operation
- Fully programmable
- Wash king size duvet
- Machine hygiene wash reminder
- Thermal and chemo-thermal disinfection programmes
- Remove stubborn stains reliably with high-performance wash programmes
- Experience maximum durability with the powerful, quiet, and maintenance-free synchronous motor
- Expect high temperature consistency with the temperature of the washing water monitored constantly for maximum hygiene
- Simple networking via WiFiConn@ct: connect via smartphone/tablet and app and retrieve status updates

### Heat-pump dryers: minimal energy consumption

Miele offers a choice between vented and heat-pump dryers. While vented dryers offer slightly quicker cycles, the Miele Professional heat-pump dryers are true masters of energy conservation. Thanks to heat-pump technology, these appliances save more than 50% energy in comparison to vented dryers, helping protect the environment. In addition, they do not require connection to an external duct system, and their short running times make them perfectly suited to the demands of professional laundry care.



## Hygiene

### PWM 507

Rising to the specific challenges of care and nursing homes in every respect, the 'Hygiene' washing machine model offers special-purpose disinfection programmes for the reliable reprocessing of contaminated textiles.



- 7kg load capacity
- Special disinfection programmes provide the basis for reliable hygiene
- Tested for intensive use, 30,000 programme cycles
- Programmable controls
- Easy connection for external dispensing
- Comes standard with dump valve for heavily soiled linen and sluicing
- Installation as space-saving washer-dryer stack possible

## MopStar

### PWM 508

Intuitive programme controls and greater innovation with the introduction of imbalance monitoring with 3D sensor, the new MopStar washing machine from Miele Professional is set to continue a decades-old tradition.



- 8kg load capacity
- Capacity of 46 mops per load
- Special purpose programmes for contract cleaners and facility managers
- Disinfection programmes for critical hygiene requirements
- Mop controls with rotary selector and touch display
- Ready-to-use: washing and conditioning of mops and cleaning cloths in a single cycle
- Installation as space-saving washer-dryer stack possible





# Marine Range

## PWM 908 + PDR 908 MAR

Tailored solutions for every need.

Miele Marine caters to the specific requirements of off-shore customers, including superyachts, cruise ships and commercial vessels.

Product performance, exceptional service and availability are crucial requirements for ocean vessels and Miele delivers on all accounts, providing a wide range of incomparable German engineered products. As a high quality appliance manufacturer, Miele Marine accommodates various voltage requirements.

Cruise ships, yachts and commercial vessels all around the world rely on Miele appliances and its service. For cruise ships, Miele offers small footprint commercial laundry appliances for the crew and guest launderettes. No matter if you're in need of a standard sized model or one of our larger capacity professional washing machines, you can always expect your individual washing needs to be fulfilled with Miele.

Apart from outstanding capacities, all machines can be freely programmed and customised, including time and temperature settings. Fast cycle times and durable industrial technology help to prevent unplanned issues with the Laundry System onboard.

Short running times guarantee a quick turnaround.

Miele Marine appliances are well known all around the world and the first choice on-board!



- 8kg load capacity
- full-touch colour display
- Thorough cleaning with professional wash programmes
- Gentle fabric care with patented Honeycomb drum





## Marine

**PWM 908 DP MAR**  
Washer

**PDR 908 HP MAR**  
Dryer

**PDR 908 EL MAR**  
Dryer

Front panel colour	Lotus white	Lotus white	Lotus white
Load capacity	8kg	8kg	8kg
Drum volume	73L	130L	130L
Max spin speed	1600rpm	na	na
g-factor/ residual moisture [%]	704 / 48	na	na
Cycle time [min]	49 <sup>*</sup>	88	52
Drainage	Drain pump or Drain valve, 75mm	na	na
Water connection	CW + HW max 70°C		
Drying system	na	Heat pump	Vented
Languages	32	32	32
DelayStart	96	24	24
Programmable	•	•	•
Stackable	•	•	•
WifiConn@ct	•	•	•
Electrical connection	3AC 400-480V, 50-60Hz or 3AC 230V, 50-60Hz	3AC 230V, 50-60Hz	3AC 400-480V, 50-60Hz
External dimensions [mm]	H850/ W596/ D714	H850/ W596/ D777	H850/ W596/ D717

<sup>\*</sup> Cycle time in Cottons 60°C, hot water, 5.5kw

## PERFORMANCE

## PERFORMANCE-PLUS



### Range

**PWM 507**  
Dryer

**PWM 507**  
Hygiene  
Washer

**PWM 508**  
Mopstar  
Washer

**PDR 507**  
Dryer

**PWM 908**  
Washer

**PDR 908**  
Dryer

<b>Front panel colour</b>	Lotus white	Lotus white	Lotus white	Lotus White	Stainless Steel or Lotus white	Stainless steel
<b>Load capacity</b>	7kg	7kg	8kg	7kg	8kg	8kg
<b>Drum volume</b>	64L	64L	73L	130L	73L	130L
<b>Max spin speed</b>	1600rpm	1600rpm	1400rpm	na	1600rpm	na
<b>g-factor/ residual moisture [%]</b>	704 / 48	704 / 48	532/ 20*	na	704 / 48	na
<b>Cycle time [min]</b>	49 <sup>^</sup>	49 <sup>^</sup>	49 <sup>^</sup>	Vented 46 mins Heat pump 67 mins	49 <sup>^</sup>	Vented 52 mins Heat pump 79 mins
<b>Drainage</b>	Drain pump	Drain valve, 75mm	Drain valve, 75mm	na	Drain pump or Drain valve, 75mm	na
<b>Water connection</b>	CW + HW max 70°C	CW + HW max 70°C	CW + HW max 70°C		CW + HW max 70°C	
<b>Drying system</b>	na	na	na	Vented or heat pump	na	Vented or heat pump
<b>Languages</b>	29	29	29	29	32	32
<b>DelayStart</b>	96	96	96	24	96	24
<b>Programmable</b>	Limited	Limited	Limited	Limited	•	•
<b>Stackable</b>	•	•	•	•	•	•
<b>WifiConn@ct</b>						
<b>Electrical connection</b>	230V 50Hz 2.8kW (15A plug included)	230V 50Hz 5.5kW (25A plug not included)	230V 50Hz 5.5kW (25A plug not included)	Heat pump 230V 50Hz 1.44kW (10A plug included) Vented 230V 50Hz 5.47kW (25A plug not included)	230V 50Hz 2.8kW, (15A plug included) or 230V 50Hz 5.5kW, (25A plug not included)	Heat pump 230V 50Hz 1.44kW, (10A plug included) Vented 230V 50Hz 5.47kW, (25A plug not included)
<b>External dimensions [mm]</b>	850/596/714	850/596/714	850/596/714	Vented 850/596/717 Heat pump 850/596/777	H850/ W605/ D714	Vented H850/ W605/ D717 Heat pump H850/ W605/ D777

\* 20% residual moisture when reprocessing cleaning cloths

<sup>^</sup> Cycle time in Cottons 60°C, hot water, 5.5kw