

**Miele**

Miele Professional Washers and Dryers

# Product Overview

## Laundry Machines

Miele Professional. Immer Besser.





## Little Giants

### PWM 908 Washer

20 lbs. capacity

2.6 cu.ft | 73 liters

Electric Drain Pump (1 ph)

### PDR 908 Dryer

18 lbs. capacity

4.6 cu.ft | 130 liters

Heat pump (1 ph)

Electric (1 ph)

## Octoplus

### PW 6080 Washer

18 lbs. capacity

2.8 cu.ft | 80 liters

Electric Drain Pump (1 ph)

Electric Drain Valve (1 ph)

### PT 7186 Dryer

18 lbs. capacity

6.4 cu.ft | 180 liters

Electric (1 ph)

### PW 5105 Washer

23 lbs. capacity

3.5 cu.ft | 100 liters

Electric Drain Valve (1 ph)

### PWT 6089 / PT 7189 Stacked Washer & Dryer

18 lbs. capacity

**Washer:** 2.8 cu.ft | 80 liters

Electric Drain Pump (1 ph)

**Dryer:** 6.4 cu.ft | 180 liters

Electric (1 ph)

## SlimLine

### PT 8303 Dryer

34 lbs. capacity

10.6 cu.ft | 300 liters

Electric (3 ph)

**LW** Available in Lotus White

**SS** Available in Stainless Steel

**OB** Available in Octoblu

**IG** Available in Iron Grey



## Performance Plus

### PWM 912 Washer

25 lbs. capacity

3.9 cu.ft | 110 liters

Electric (3 ph)

### PWM 916 Washer

35 lbs. capacity

4.9 cu.ft | 140 liters

Steam (3 ph)

Electric (3 ph)

### PWM 920 Washer

45 lbs. capacity

6.7 cu.ft | 180 liters

Steam (3 ph)

Electric (3 ph)



## Large Laundry

### PW 6241 Washer

55 lbs. capacity

8.5 cu.ft | 240 liters

Steam (3 ph)

Electric (3 ph)

### PW 6321 Washer

75 lbs. capacity

11.3 cu.ft | 320 liters

Steam (3 ph)

Electric (3 ph)



## Performance Plus

### PDR 918 Dryer

40 lbs. capacity

11.5 cu.ft | 325 liters

Electric (3 ph)

### PDR 922 Dryer

50 lbs. capacity

14.1 cu.ft | 400 liters

Steam (1 ph)

Electric (3 ph)

### PDR 928 Dryer

60 lbs. capacity

17.7 cu.ft | 500 liters

Steam (1 ph)

Electric (3 ph)

### PDR 944 Dryer

100 lbs. capacity

28.2 cu.ft | 800 liters

Steam (3 ph)

Electric (3 ph)

## Unmatched Quality & Trusted Cleaning Performance

Uncompromising quality and continuous improvement are fundamental to the high standards Miele Professional sets as part of its Immer Besser (“Forever Better”) commitment. All appliances from Miele Professional undergo comprehensive quality tests and a rigorous final inspection before entering the market. Additionally, Miele Professional manufactures many laundry machine components, including electric motors and printed circuit boards, to achieve the highest possible levels of production quality control. The only manufacturer to test its products for a service life of up to 30,000 operating hours, Miele Professional delivers laundry solutions that offer customers consistent, high-quality cleaning results with every wash and dry cycle.

## Gentle Laundry Care with Patented **Honeycomb Drum Technology**

Miele Professional’s industry-leading honeycomb drum technology differentiates its laundry machines from the competition. The convex, web-like surface structure of the honeycomb drum in Miele washers creates a thin layer of water between the drum and the laundry. This unique design ensures effective wetting, protects fibers and extends fabric life. Similarly, the concave, sculptured honeycomb structure utilized in Miele dryers creates an air cushion between the drum wall and laundry. Cushioning the laundry in this way ensures gentle fabric care and high-quality drying results.

## Efficient, Sustainable Performance that Reduces Costs and Conserves Natural Resources

Miele Professional appliances are designed to optimize each wash and dry cycle, conserving water and electricity. In addition to being more sustainable, reducing natural resource consumption lowers the total cost of machine ownership and improves the overall profitability of an end-user’s operation. Long service life, reliable work processes, and convenient, easy-to-use control interfaces are additional advantages of selecting Miele washers and dryers for your operation.

### Miele Inc., Princeton, NJ

**P** +1 800 991 9380

**E** [prosales@mieleusa.com](mailto:prosales@mieleusa.com)

[mieleusa.com/professional](http://mieleusa.com/professional)

### Miele Ltd., Vaughan, ON

**P** +1 888 325 3957 (Option #3)

**E** [professional@miele.ca](mailto:professional@miele.ca)

[mieleprofessional.ca](http://mieleprofessional.ca)