

Miele

The new tank dishwashers:
Top-class cleaning results combined with shortest cycles.

Miele Professional. Immer Besser.





Tackles soil fast and powerfully whilst being gentle on loads

Spotless glassware, perfectly clean crockery and sparkling cutlery – top-flight hospitality visible at a glance. But the new tank dishwashers from Miele Professional inspire not just by virtue of the first-class results they produce. With their short cycles, their sparing use of resources and their gentle wash action, these new products are set to become dependable workhorses in hotels, restaurants and canteens.

Strong and adaptable

Tank dishwashers come into their own wherever large mountains of crockery need to be washed in a short space of time. Their insatiable appetite for hard work is now about to be taken to the next level by a new model generation from Miele Professional. Newly developed spray arms guaranteeing full coverage also cut water consumption by up to 25%. This also minimises energy and detergent requirements on tank dishwashers and ensures excellent efficiency in continuous operation. Load-specific programmes, variable pump pressure and a smooth gentle-start mechanism adapt programmes perfectly to the needs of workaday life in a commercial environment.

Capacities to meet all requirements

From compact glass washers for behind-the-bar use and classic 60 cm models through to tray washers with a particularly deep chamber for bulky items, for example for standard containers: The new tank dishwashers offer matching capacities for restaurants, bars, guesthouses, bakers, cafés and butchers. Clients can also choose from a broad range of baskets for the perfect reprocessing of all types of loads.

The new full-touch display is as simple to use as your smartphone. This allows programmes to be selected fast and error-free, even during rush hours.

Sparkling results in any environment

To meet the highest of demands, glass and bistro washers feature the reverse osmosis option. This water treatment method achieves perfect dishwashing results without the need to polish items after washing. This cuts down on personnel costs, avoids costly breakages and offers guests the ultimate in hygiene.

Powerful, reliable, efficient:
The new tank dishwashers from Miele Professional



Benefits that pay off on a daily basis



Perfect dishwashing results in every situation

The new tank dishwashers from Miele Professional feature specific programmes for all load types and degrees of soiling. All key parameters (e.g. cycle duration, temperature and spray pressure) are carefully set ex works but can nevertheless be reconfigured by users. This ensures delicate champagne flutes are cleaned just as reliably and gently as plates with dried-on food residue.



Excellent user convenience

They are operated in a similar way to a smartphone, making them exceptionally simple to use. On a day-to-day basis, they are convenient to use as they are operated with just one button. The remaining time display in colour provides you with information on the machine's current status and programme sequence. When needed, additional information can be called up and settings modified from the display. The display is even easy to operate when wearing gloves.



Economical and efficient

Compared with the previous series, the new undercounter tank dishwashers save between 15% and 25% water. This conservation of resources is achieved using an innovative, streamlined spray arm with improved final rinse nozzles. At the same time, this reduces energy and chemical consumption and has a positive effect on a dishwasher's operating costs.



Wide range of dispensing options

Whatever the situation on site: The new tank dishwashers are geared to the best possible dispensing method. The range with its various models comprises versions with integrated dispenser pumps and siphons for external canisters to models with integrated tanks and dispenser pumps – ideal for kitchens without the space for storing canisters.



PTD 701

BRILLIANTcompact

Commercial tank dishwashers	PTD 701
Max. theoretical capacity [baskets/h]	77
Shortest cycle [secs]	47
Max. water circulation capacity [l/min]	200
Standard and additional programmes	3 + 4
Integrated tanks for detergent and rinse aid (DOS)	Optional
Integrated water softener (WES)	-
Exterior dimensions H/W/D [mm] incl. height-adjustable feet, without detergent tanks	725-760/460/617
Basket dimensions [mm]	400 x 400
Water connection	CW or HW, max. 60°C
Total rated load (3-phase/1-phase) [kW]	9.7/4.1

PTD 701

- Glass washer with tank system
- Perfect for behind-the-counter use

Plus

- Shortest cycle: 47 seconds
- Max. theoretical capacity: 1,532 glasses/h
- Integrated dispenser pumps and siphons for external supply of detergent and rinse aid
- Load-specific programmes
- For undercounter installation
- Optional: Integrated RO - For sparkling glasses without the need for polishing



PTD 702

UNIVERSALcompact

Commercial tank dishwashers	PTD 702
Max. theoretical capacity [baskets/h]	65
Shortest cycle [secs]	55
Max. water circulation capacity [l/min]	200
Standard and additional programmes	3 + 4
Integrated tanks for detergent and rinse aid (DOS)	Optional
Integrated water softener (WES)	-
Exterior dimensions H/W/D [mm] incl. height-adjustable feet, without detergent tanks	725-760/600/617
Basket dimensions [mm]	500 x 500/500 x 530
Water connection	CW or HW, max. 60°C
Total rated load (3-phase/1-phase) [kW]	9.7/4.1

PTD 702

- Versatile, multi-purpose tank dishwasher
- Perfect for behind-the-counter use
- **Plus**
- Shortest cycle: 55 seconds
- Max. theoretical capacity: 3,207 glasses/h or 1,170 plates/h (in shortest 55-second cycle)
- Integrated dispenser pumps and siphons for external supply of detergent and rinse aid
- Load-specific programmes
- For undercounter installation
- Optional: Integrated RO - For sparkling glasses without the need for polishing



Commercial tank dishwashers	PTD 703
Max. theoretical capacity [baskets/h]	65
Shortest cycle [secs]	55
Max. water circulation capacity [l/min]	200
Standard and additional programmes	3 + 4
Integrated tanks for detergent and rinse aid (DOS)	Optional
Integrated water softener (WES)	Optional
Exterior dimensions H/W/D [mm] incl. height-adjustable feet, without detergent tanks	820-855/600/617
Basket dimensions [mm]	500 x 500/500 x 530
Water connection	CW or HW, max. 60°C
Total rated load (3-phase/1-phase) [kW]	9.7/4.1

PTD 703

- Versatile, multi-purpose tank dishwasher

Plus

- Shortest cycle: 55 seconds
- Max. theoretical capacity:
1,170 plates/h
- Integrated dispenser pumps and siphons
for external supply of detergent and rinse
aid
- Optional: BASIC version
without dispensing equipment
- Load-specific programmes
- For undercounter installation
- With integrated water softener



PTD 704

UNIVERSALplus

Commercial tank dishwashers	PTD 704
Max. theoretical capacity [baskets/h]	65
Shortest cycle [secs]	55
Max. water circulation capacity [l/min]	200
Standard and additional programmes	3 + 4
Integrated tanks for detergent and rinse aid (DOS)	–
Integrated water softener (WES)	–
Exterior dimensions H/W/D [mm] incl. height-adjustable feet, without detergent tanks	820–855/600/651
Basket dimensions [mm]	500 x 500/500 x 530/500 x 540
Water connection	CW or HW, max. 60°C
Total rated load (3-phase/1-phase) [kW]	9.7/4.1

PTD 704

- Tank dishwasher with deeper chamber
- Particularly suited to the cleaning of trays and EN crates

Plus

- Shortest cycle: 55 seconds
- Max. theoretical capacity: 1,170 plates/h
- Integrated dispenser pumps and siphons for external supply of detergent and rinse aid
- Load-specific programmes
- For undercounter installation



Accessories from Miele Professional – for top-class performance across the entire system

Miele Professional stands for high-quality dishwashers with innovative process technology. But Miele's proverbial quality is also reflected in a comprehensive range of accessories guaranteeing even simpler, even faster and even more efficient dishwashing. Carefully formulated detergents and rinse aid and a fast response on the part of Miele Service complete the offer to make up a unique system: System4Shine from Miele Professional.



Baskets and inserts

Accessories from Miele Professional comprise a wide range of baskets and inserts which perfectly accommodate all types of loads for optimum cleaning.

- Baskets and basket sets for glassware
- Baskets and holders for cutlery
- Baskets for plates and cups
- Bistro and multi-purpose baskets
- Baskets and carriers for trays

Further accessories

- Open/box plinths in various heights
- Drip trays
- Steam protection sets
- CN rear panel
- Water softener, demineralisation cartridges

ProCare Shine

The detergents and rinse aid from the ProCare Shine series were developed from the outset for use in Miele dishwashers. With their finely tuned ingredients, these products form the bedrock of professional and economic crockery care.

- Alkaline and mildly alkaline liquid detergent
- Rinse aid
- Dishwasher salt

Miele & Cie. KG, Gütersloh
www.miele-professional.com

Immer besser

Since 1899, Miele – a family-run company – has subscribed to a clear corporate philosophy condensed into the two words 'Immer Besser' (Forever better). This overarching claim is the foundation of Miele's proverbial quality and sustainability and the power of innovation of a brand 'Made in Germany'. A brand promise which gives commercial users the certainty of having chosen the right product.

Award-winning

Uncompromising product reliability and service dependability is the reason why customers have repeatedly voted Miele the best and most trustworthy brand. Coveted awards such as the MX Award, the iF and reddot Design Awards and the German Sustainability Prize confirm the distinguished position Miele enjoys with respect to design, quality management and the sparing use of resources.

Proficient

Miele Professional has been developing and manufacturing a broad range of high-quality laundry machines, dishwashers, washer-disinfectors and sterilisers for decades. Carefully selected accessories, comprehensive advisory services and a Miele service operation which guarantees fast response times ensure that appliances perform to perfection and offer the ultimate in capacity and efficiency.

Miele Professional on the web

- For detailed information on technical data, features and accessories
- Brochures covering all product groups and applications available as downloads
- Detailed information, instructions and product presentations on Miele Professional's YouTube channel