






**Miele**

# Only **SmartBiz** can do it!

Miele Professional. Immer Besser.

 Only 79 minutes per cycle  
 A+++ energy efficiency  
 Plug & Play  
 15,000 operating hours  
 100% Miele quality  
**SmartBiz.**  
Enter into the world of  
commercial washing and drying.







**New from Miele Professional:**

# Enter into the world of commercial laundry care

Whatever your business your customers have high expectations. They expect immaculately clean textiles whether that's towels in a hairdressers or table linens in a restaurant. Economical washing machines and dryers from the new SmartBiz entry-level model range were specifically developed for commercial use, boast short cycles, extreme durability and first class results. Both models are Plug & Play, ready for use, and are the products of choice in providing reliable washing and drying results for up to three times a day.

**100% Miele quality for professionals like you**

More powerful, faster and more durable than domestic appliances: SmartBiz products are designed to cope with up to three cycles a day in a commercial environment and rise to the strain and duress over time in a way domestic appliances are unable to do.

## **SmartBiz PWM 300 washing machine**

# Clean laundry in the shortest of times

In the hustle and bustle of a working day, it is crucial that textiles are immaculately clean and ready for use again in next to no time. The PWM 300 SmartBiz washing machine guarantees perfect cleanliness and offers extremely short cycle time of only 79 minutes, ensuring that your laundry is ready for use again. This makes it the ideal proposition for up to 3 cycles a day.



## **SmartBiz PDR 300 HP heat-pump dryer**

# Gentle drying for beautifully soft laundry

Commercial textiles are often used to their maximum each day, every day, and therefore require specialist gentle care. The energy-efficient PDR 300 HP SmartBiz heat-pump dryer is the ideal counterpart to a SmartBiz washing machine. Thanks to the patented Miele honey-comb drum it protects fabrics and with PerfectDry, sports an intelligent system for exact drying results. As a result, your textiles are dried much faster and much more gently.





# Only **Smart-Biz** can do it!

## Fast wash programmes



**ONLY 79 MINUTES**  
for perfect results

On days when you have your work cut out for you, your laundry has to be ready for use again quickly and without any fuss. SmartBiz washing machines achieve very short cycles of only 79 minutes\*, washing faster than comparable commercial machines. Even if you have to wash several times a day, you can always count on a fresh supply of laundry.

## Robust materials



**TESTED FOR 15,000 HOURS**  
of heavy operation

Domestic appliances are not up to the rigours of commercial laundry care. Thanks to high-quality materials and a robust design, SmartBiz units are designed for 10,000 cycles or 15,000 hours of operation. Whether one or three washing or drying cycles a day: SmartBiz still produces top-class results even after many years.

## Choice materials



Plan ahead with confidence  
with products that last

Key components subject to wear and tear are made from durable, hard wearing materials, not plastic. Examples of this include the outer drum and drum ribs are made from stainless steel, cast iron and counterweights, the drum suspension and a pulley wheel made from die-cast aluminium.

\*SmartBiz heat-pump dryers boast short cycles lasting only 125 minutes.



Patented technologies



## **CLEAN LAUNDRY** and **GENTLE FABRIC CARE**

The patented honeycomb drum ensures that laundry is gently washed. And thanks to the innovative PerfectDry system, your laundry is dried faster, more evenly and more gently. This way, your textiles remain in great condition, even after many washing and drying cycles.

A+++ energy efficiency



## **SAVE ON DAILY COSTS** **AND RESOURCES**

Running costs, maintenance and servicing of your machines all have a cost impact on your business. Smartbiz has a A+++ energy efficiency rating, and with their durability and reliability credentials you have total peace of mind. What's more, with innovative heat-pump technology the dryers consume around 60% less energy than conventional condenser dryers.

Plug & Play system



## **SIMPLY PLUG IN AND SWITCH ON**

Both SmartBiz models are supplied fitted with a supply lead and plug, ready for operation, so that machines only need to be installed, plugged in and switched on. Things couldn't be simpler or faster.





## Further SmartBiz features

# 2 machines that rise above themselves

With SmartBiz, it's about much more than perfect cleaning performance: designed for every day use, flexible and ease of use are key aspects on both machines. That is why SmartBiz models offer additional features which make your work more efficient, safer and ultimately more convenient.

### **Simple, intuitive operation**

thanks to a rotary selector with plain text and a display providing further information

### **More laundry per cycle**

large drum volume of 64 l for a 7 kg load capacity

### **Perfectly washed laundry**

with a variety of washing and drying programmes for various textiles, e.g. 'Cottons', 'Minimum iron', 'Intensive', 'Woolens', 'Cleaning textiles' and many more

### **Considerable energy and resource savings**

thanks to efficient and fast programmes and an A+++ energy efficiency rating

### **Increased flexibility**

through matching accessories and the opportunity to use both models in a washer-dryer stack with a drawer or with a drawer and a plinth

### **Total peace of mind**

thanks to Miele's excellent award-winning after-sales service

## SmartBiz for small businesses

# The right solution for every job

With SmartBiz, Miele Professional offers perfect entry-line models for professional laundry care. Whether aprons, towels or sports shirts, the SmartBiz duo of machines was designed with the following clients in mind:

- Bakeries, pastry shops, catering businesses
- Hairdressers and beauticians
- Child-care centres and schools
- Smaller hotels, B&Bs, guesthouses
- Sports clubs, fitness centres



## Wherever you work, we can help!

Simply contact us – and we will work with you to ensure you have the perfect laundry solution for your business.



## Data, facts, specifications

# Added value in detail



Washing machine	PWM 300
User interface	DirectSensor
Load capacity [kg]	7
Drum volume [l]	64
Max. spin speed [rpm]	1,400
g-factor/Residual moisture** [%]	526/49
Cycle time* [mins.]	79
Type of heating	EL
Drainage [LP DN 22]	LP
Front colour / material	LW
External dimensions H/W/D [mm]	850/596/636

Heat-pump dryer	PDR 300
User interface	DirectSensor
Drying system	Heat pump, integrated condensate drainage
Load capacity [kg]	7
Drum volume [l]	120
Cycle time Cottons/Mixed fabrics* [mins.]	125/99
Front colour / material	LW
External dimensions H/W/D [mm]	850/596/636

LW = Lotus white, enamelled, \* Cycle time in Normal Dry programme.

EL = Electric, LP = Drain pump, LW = Lotus white, enamelled, \* Duration in Cottons 60°C, cold water, \*\* Residual moisture presuming hot rinse in last rinse cycle

If your requirements exceed three washes a day, we have a range of innovative, high-end washing machines and dryers. Our expert team will work with you to establish the right products and services for you and your business.







Miele UK  
Miele (GB) Head Office  
Fairacres  
Marcham Road  
Abingdon  
OX14 1TW

[www.miele.co.uk/professional](http://www.miele.co.uk/professional)  
0345 3656636  
[professional.info@miele.co.uk](mailto:professional.info@miele.co.uk)