

**Miele**

**CHALLENGE.**

**MASTERED.**



**Makes ironing a pleasure:**  
The professional PIB 100 steam ironing system.

**Miele Professional. Immer Besser.**



# PROFESSIONAL IRONING

**HAS NEVER BEEN SIMPLER**

Is laundry care and ironing part of your daily work? Miele can now offer a professional solution in the form of the Miele PIB100 Steam Ironing System.

The compact combination of iron, steam generator, handheld steamer and ironing board brings together the best of two worlds: as practical as a domestic appliance and yet powerful, fast and durable to perfectly master the challenges of commercial use.

# A SYSTEM OF MANY TALENTS

The PIB 100 Steam Ironing System is an indispensable colleague wherever neat attire and immaculate clothing is called for, and where nicely finished laundry should not tie up too much time and staff. Its use pays off particularly in hotels, restaurants and aged care.

Thanks to its precise and efficient steam technology, the Steam Ironing System keeps on ironing to perfection for at least three hours. Delicate evening dresses or jackets are put back in shape by the high-performance steamer.

Why not take the ironer upstairs to do your work? The compact light-weight unit follows obediently at your heels on its low-noise wheels and is set up and ready for work again in next to no time thanks to its patented 1-2-Lift System\*.

It's worth noting that the PIB 100 Steam Ironing System is so simple to use it can be entrusted to untrained staff or even guests thanks to an intuitive display.

Don't be surprised if ironing turns out to be one of your company's favourite pastimes in the future!



# EVERY CHALLENGE IS MASTERED WITH THE PIB 100

When conventional domestic appliances are stretched to the limit in the face of hours of continuous use, the PIB 100 proves to be a strong and enduring all-rounder. Its many features are bound to impress in three respects: convenience, efficiency and durability.



## PRACTICAL CONVENIENCE

### 1-2-Lift System – Set up and folded away in a matter of seconds

Two movements, no effort – thanks to the patented 1-2-Lift System\*, the PIB 100 is ready for use in next to no time and folded together just as fast.

### Large water tank – Greater capacity for more laundry

The 4.5l capacity tank allows for at least 3 hours of uninterrupted ironing.

### ComfortZone – Large ironing table

Save time with a large 120x40 cm ironing board. This allows the entire front of a shirt to be ironed without needing to be repositioned.

No worries: If you need to interrupt your ironing, the PIB 100 provides smart assistance, thanks to its safe **AutoOff** function. The entire system switches itself off automatically after 25 minutes.



## TECHNOLOGY FOR PROFESSIONAL RESULTS

### Clear and concise display – Assistance at a glance

With the integrated display on the PIB 100, you will always have all the important information you need at your fingertips, for instance the current machine status, descaling intervals and water levels.

### Automatic rinsing for unrivalled results

The automatic rinse function removes mineral residue from the steam generator to guarantee full performance at all times.



## TROUBLE-FREE OPERATION AND MAINTENANCE

### SoftCare hand iron with honeycomb soleplate – Gentle on fabrics

The patented honeycomb soleplate\* ensures that the steam is distributed lightning-fast through the small channels of the honeycomb structure across the entire soleplate. The film of steam produced allows the SoftCare iron to glide effortlessly and gently over the laundry.

### Powerful steam – Professional quality at the touch of a button

With 4 bar steam pressure and 100g/minute delivery, even the thickest of materials are perfectly ironed.

\*Patent EP 2 169 108 B1  
\*\*Patent EP 2 233 632 B1





## FACTS, NOT HOT AIR

# MIELE PROFESSIONAL QUALITY IN DETAIL



### Steam ironing system

Display
Water tank [l]
Steam
Ironing surface [W/D mm]
External dimensions [H/W/D mm]
External dimensions (folded) [H/W/D mm]

### PIB 100

Single-line, plain text
4.5
4.0 bar, 100 g/minute
1,190/405
970/470/1,510
1,200/470/402

### User interface

- Simple commissioning routine with instructions in plain text
- Operating status and service indicators in plain text in display
- Automatic descaling at the touch of a button, depending on the water hardness
- User interface language selectable to cater for different users

### Operational safety

- CoolDown - iron switches off automatically after 3 minutes
- AutoOff - steam ironing system switches off automatically after 25 minutes

### Simple handling

- Practical rollers for ease of transportation
- Ready for use in two moves with patented\* 1-2 Lift System
- ErgoLift - infinite height adjustment for perfect working height (83-102 cm)
- Two storage compartments for FashionMaster iron and accessories

### Highlights

- Large water tank with 4.5 l capacity for long, uninterrupted ironing
- High-quality, particularly permeable ironing table cover
- Iron with patented honeycomb soleplate\*\* for rapid steam distribution and ease of ironing
- Efficient working on large ironing table with ComfortZone for garment shoulders
- Active ironing table – blower and suction function ensures optimum use of steam and positioning of garments
- Large volume of steam and high pressure for a perfect finish on multi-ply textiles
- Integrated heating reduces any build-up of condensate in the table.
- Convenient handheld steamer to smooth and freshen up garments on hangers

### Optional accessories

- Clip-on non-stick soleplate to protect sequin and appliqués and avoid glossy patches on dark textiles



\*Patent EP 2 169 108 B1  
\*\*Patent EP 2 233 632 B1

Miele Professional  
Australia and New Zealand  
AUS 1300 731 411  
NZ 0800 002 593  
[www.miele.com.au/professional](http://www.miele.com.au/professional)