



# Miele

## Octopus Washer & Dryer For Veterinary Applications

Miele Professional. Immer Besser.



### The Ultimate Veterinary Tool

Miele's Octopus laundry equipment is perfect for veterinarians who process small animal bedding and towels, as well as large equine blankets and accessories. The 20 pound capacity Octopus machines can hold 1 blanket, 6 saddle pads or 15 towels. Offering short cycle wash programs, high temperature disinfection and high spin extraction, the Octopus washer and dryer provide vets with a superior hygienic clean. In addition, Miele's Honeycomb™ drum cradles accessories, towels and blankets while washing, ensuring a gentle and thorough clean while further protecting your practices' textiles.

German engineered with high performance heater elements, intelligent water intake controls and short cycle times, Octopus machines are the ultimate tool for veterinarian facilities with high throughput laundry demands.

### Octopus Laundry Equipment at a Glance

- 20 lbs capacity
- High temp. disinfection programs (200° F)
- High spin speed - 1300 rpms
- Patented Miele Honeycomb™ drum
- Sensor for load control
- Bearing designed for 30,000 operating hours
- Automatic detergent pumps
- Special programs for horse blankets

### Trust the Experts

Miele Professional leads the way in the development of innovative technology and meets the highest demands in washing, dishwashing, cleaning and disinfection in commercial applications. Providing true commercial cleaning systems with outstanding speed, capacity, and performance, Miele is the definitive source for precision commercial cleaning equipment trusted by hospitals, pharmaceutical companies, educational facilities and many more around the world.

Our product line includes: laboratory glassware washers, medical and dental washer-disinfectors, commercial dishwashers and laundry equipment.

**Why trust anyone else to clean your pet bedding, horse blankets and surgical scrubs?**



Miele, Inc. Princeton, NJ



800.991.9380



proinfo@mieleusa.com



www.mieleusa.com/professional

# Miele

## Octoplus Washer & Dryer For Veterinary Applications

Miele Professional. Immer Besser.



Installation Type	Side-by-Side		Stacked	
Machine	Washer PW 6080	Dryer PT 7186	Washer PWT 6089	Dryer PT 7189*
Load Capacity	20 lbs	20 lbs	20 lbs	20 lbs
Machine Exterior	Octoblu	Octoblu	Octoblu	Octoblu
Machine Dimensions	27.6" W x 40.2" H x 28.7" D	27.6" W x 40.2" H x 28.7" D	27.6" W x 76" H x 30.1" D	
Drum Volume	21 gallon / 80 liter	48 gallon / 180 liter	21 gallon / 80 liter	48 gallon / 180 liter
Drum Type	Honeycomb™ Drum	Honeycomb™ Drum	Honeycomb™ Drum	Honeycomb™ Drum
Spin Speed	1300 rpm		1300 rpm	
G-force	520		520	
Control Type	Profitronic L	Profitronic L	Profitronic L Plus Vario	Profitronic L Plus Vario
Languages	32	32	32	32
24-hour Delay Start	Yes	Yes	Yes	Yes
Weight	310 lbs	167 lbs	298 lbs	165 lbs
Standard Electrical Connection	2-pole 220V-240V 60Hz (convertible to 208V)	2-pole 208V 60Hz or 2-pole 240V 60Hz	2-pole 220V-240V 60Hz (convertible to 208V)	2-pole 208V 60Hz or 2-pole 240V 60Hz
Standard Fuse Rating	2-pole 30 A	2-pole 30 A	2-pole 30 A	2-pole 30 A
Plug Type	NEMA L6-30P	NEMA L6-30P	NEMA L6-30P	NEMA L6-30P
Total Rated Load	4.0 kW at 208V or 5.2 kW at 240V	4.8 kW at 208V or 5.7 kW at 240V	4.0 kW at 208V or 5.2 kW at 240V	4.9 kW at 208V or 5.7 kW at 240V
High Temperature Disinfection Programs	Yes		Yes	
Cold Water Connection	1 line, ½" hose with ¾" threaded union		1 line, ½" hose with ¾" threaded union	
Hot Water Connection	1 line, ½" hose with ¾" threaded union		1 line, ½" hose with ¾" threaded union	
Dump Valve Drain Option	3" OD connection		N/A	
Drain Pump Option	7/8" connection		7/8" connection	
Vent Diameter		4"		4"
Dispensing Adapter for 6 Liquid Chemicals	Yes		Yes	
"Container empty" Sensors for 6 Pumps	Yes		Yes	

Miele, Inc. Princeton, NJ



800.991.9380



proinfo@mieleusa.com



www.mieleusa.com/professional