



Professional dishwashers ideal for senior care facilities

Miele's freshwater dishwashers, featuring high throughput and short cycle times, meet the highest demands for cleaning quality and hygiene requirements. Whether you need the ability to wash up to 152 plates per hour, require final rinse temperatures of 185°F for maximum hygiene, or you value the ability to use glasses straight from the dishwasher without polishing, our freshwater dishwasher PG 8061 is ideal. With a 15-minute wash cycle, 6 programs, simple to use controls and a range of configurable baskets, including the option to accommodate 19 3/4" x 19 3/4" plastic racks on 2 levels, this dishwasher impresses on day one.



Fresh water system

Miele Professional freshwater circulation dishwashers ensure consistently high levels of cleaning performance by taking in fresh water between individual phases of a program cycle. A thorough final rinse is carried out at a temperature adjusted to the washed items, significantly exceeding commercial dishwasher hygiene requirements.

Short cycles

Connections for hot water, intelligent dishwashing technology and a powerful heater pump ensure optimum program durations and cleaning results.

Low consumption values

Miele Professional dishwashers are acclaimed for consumption efficiency. From the product design stage, they are engineered to achieve perfect dishwashing results by using no more water, energy and detergent than necessary.

Perfect integration under kitchen countertops

For a perfect appearance, the dishwasher can be easily installed and adjusted as needed to suit the height of the countertop.



Modifiable wash programs

For extraordinary dishwashing results and hygiene, temperature, holding time and water volume can be precisely tailored to on-site requirements.

User convenience

The 3-line display control panel provides information on the selected program and the current program status. Important program parameters can be conveniently changed using the intuitive touch controls.

Integrated filter system

Miele Professional dishwashers feature permanent filtering of the wash water, to help protect the machine from damage and provide optimum cleaning results.

Plastic baskets on two levels

19 3/4 x 19 3/4" (500mm x 500 mm) plastic baskets can be used on 2 levels. The standard supplied basket is used as the carrier on the lower level. Three spray arms allow perfect cleaning results to be achieved on both washing levels.

Connection for dispenser module

To simplify the use of liquid detergents and rinse aid, up to 2 liquid dispensing modules can be optionally connected, depending on the model. Precise and automatic dispensing ensures perfect cleaning results and easier handling.

NSF/ANSI 3 certified for sanitization

For senior care and other healthcare facilities that require a NSF/ANSI 3 certified dishwasher, the PG 8061 features a final rinse temperature of 185°F (85°C) with a one-minute holding time.



HYGIENE



Dishwasher	PG 8061 (208V)	PG 8061 (240V)
Theoretical capacity per hour (plates/baskets)	152/8	152/8
Shortest cycle	15 mins.	15 mins.
Programs	6	6
External dimensions, excl. lid H, W, D	32 5/16, 23 5/8, 23 1/2"	32 5/16, 23 5/8, 23 1/2"
External dimensions, excl. lid H, W, D	820, 600, 600 mm	820, 600, 600 mm
Height adjustable machine feet	+ 2 1/4" + 60 mm	+ 2 1/4" 60 mm
Water connections	CW and HW, max. 149°F 65°C	CW and HW, max. 149°F 65°C
Aerosol steam condenser	•	•
Integrated water softener, max. 60 gr/gal	•	•
Electrical connection	3AC 208V 60Hz	3AC 240V 60Hz
Total rated load	5.8 kW	5.8 kW
Max. final rinse temperature	185°F 85°C	185°F 85°C
Material number	09799780	09801160
Article number	61806120CDN	61806125CDN

ProCare Shine – Perfectly formulated detergents and rinse aid



The detergents and rinse aid from the ProCare Shine series were developed specifically for use in Miele dishwashers. Their special formulation guarantees ideal machine compatibility and economic efficiency, while achieving spotless results.

- Perfect match for Miele Professional dishwashers
- Machine compatibility endorsed
- Top-class results with economical use of resources
- Liquid detergent for automatic dispensing
- Powder detergent and tablets for manual dispensing



Miele Inc.,
Princeton, NJ

P | 800.991.9380

E | prosales@mieleusa.com

mieleusa.com/e/professional-dishwashers



Miele Ltd.,
Vaughan, ON

P | 888.325.3957

E | professional@miele.ca

miele.ca/en/professional/contact-37.htm

Product	Properties
ProCare Shine 12 GC	<ul style="list-style-type: none"> • Detergent tablets wrapped in water-soluble foil • Universal cleaning agent with good cleaning performance for light to medium soiling • Awarded EU Eco label (AT/038/006)
ProCare Shine 10 MA <i>Requires DOS G80 Flex dispenser</i>	<ul style="list-style-type: none"> • Mildly alkaline liquid detergent • Universal cleaning agent with good cleaning performance for light to medium soiling • Very simple handling
ProCare Shine 40	<ul style="list-style-type: none"> • Liquid rinse aid • Universal applications
ProCare Universal 61	<ul style="list-style-type: none"> • Reactivation salt for integrated water softeners
DOS G 80/1 Dispensing Pump	<ul style="list-style-type: none"> • For 5 liter Canister